Service Manua

Portable MD Recorder





SJ-MR100

MD unit: RAE1620Z Mechanism Series

Colour

(S).....Silver Type

Areas

EB.....Great Britain.

EG.....Europe.

GH.....Hong Kong.

Specifications

●Audio

System:

MiniDisc digital audio system

Laser:

Coding:

Semiconductor laser (=780 nm)

Sampling frequency:

44.1 kHz

Adaptive Transform Acoustic Coding

(ATRAC)

No. of channels:

2 (left and right, stereo)

1 (monaural)

Frequency response:

20 Hz-20 kHz (+0 dB, -8dB)

Wow and flutter:

Below measurable limit

General

Input terminal

OPT/LINE IN jack

Impedance:

47kO

Input level:

SENS H: 178mV

SENS L: 500mV

MIC jack

Impedance:

600Ω

Input level:

0.4mV

Output terminal

Output Jack:

Phones, 14Ω

Power output:

5 mW+5 mW

Power supply

Rechargeable battery: DC 1.2V

(included rechargeable battery)

Battery:

DC 1.5V (One LR6, AA, UM-3 battery)

AC adaptor:

DC 1.8V (included AC adaptor)

Dimensions (WxHxD)

Cabinet dimensions:

84x77x18.9 mm

incl.projecting parts:

84.9x78.3x20.5 mm

Weight:

161 g (with battery)

136 g (without battery)

●Play time

(When used in hold mode, at 25°C, on a flat, stable surface)

Battery type:

Play time

Record time

Rechargeable:

About 8.5 hours

About 4.5 hours

Panasonic alkaline:

About 10.5 hours

About 2.0 hours

Both together:

About 20 hours

About 9.5 hours

Charger

Input:

AC 220 V (GH) / AC230 V (EG) / AC

240V (EB), 50/60 Hz 8W

Recharging time:

About 3 hours

nason

© 1999 Matsushita Electric Industrial Co., Ltd. All rights reserved. Unauthorized copying and distribution is a violation of law.



Notes:

- The play time may be less depending on the operating conditions
- Specifications are subject to charge without notice. Weight and dimensions are approximate.

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

CONTENTS

	Page
1 Precation of Laser Dlode ·····	2
2 Accessories ·····	3
3 Operating Instructions	3
4 Handling Precautions for Traverse Deck (Mechanism Un	it) - 20
4.1. Mechainsm Unit (optical pickup)	
4.2. Caution for repairing of MD mechanism (optical picku	p) 20
4.3. Grounding for electrostatic breakdown prevention	20
5 Operation Checks and Main Component Replacement	
Procedures ····	21
6 Operating Procedures	28
6.1. Operating Procedures	28
6.2. Block Diagram ·····	29
7 Measurements and Adjsutments	30
7.1. Laser Power Adjustment ·····	31
7.2. Self-diagnosis Function	33
B Troubleshooting Guide ·····	34
Checking Procedures of Main Components Parts on the	Main
P.C.B. (B side)	43
) Schematic Diagram Notes	44
10.1. Schemtic Diagram Notes	44
10.2. Type Illustration of IC's, Transistors and Diodes	45

Pa	ge
11 Schematic Diagram ·····	46
2 Printed Circuit Board and Wiring Connection Diagram	55
3 Block Diagram	59
4 Wiring Connection Diagram	65
5 Terminal Function of IC's	
15.1. IC1 (AN8772FHKEBV) : RF AMP	65
15.2. IC101 (M6616RB1): ATRAC ENCORDER/DECORDER,	
SERVO SIGNAL PROCESSOR	66
15.3. IC301 (BD6604KVT) : FOCUS/TRACKING COIL,	
TRAVERSE MOTOR DRIVE, SPINDLE MOTOR DRIVE,	,
ROTARY DETECTOR	67
15.4. IC501 (MN101CF32GCA) : SYSTEM CONTROL	68
6 Caution in Use of Rechargeable Battery Ass'y	69
7 Supply of Rechargeable Battery Ass'y as Replacement Parts	3
	69
8 Resolution Procedure and Parts Format of Remote	
Controller's Clip Unit	69
9 Replacement Parts List	70
0 Cabinet Parts Location	74
1 Packaging ·······	75

1 Precation of Laser Diode

CAUTION:

This product utilizes a laser diode with the unit turned "on", invisible laser radiation is emitted from the pickup lens. Wave length:780 nm

Maximum output radiation power from pickup: 100 μ W/VDE

Laser radiation from the pickup lens is safety level, but be sure the followings:

- Do not disassemble the optical pickup unit, since radiation from exposed laser diode is dangerous.
- 2. Do not adjust the variable resistor on the pickup unit. It was already adjusted.
- 3. Do not look at the focus lens using optical insturments.
- 4. Recommend no to look at pickup lens for a long time.

ACHTUNG:

Dieses Produkt enthält eine Laserdiode. Im eingeschalteten Zustand wird unsichtbare Leserstrahlung von der

Laserinheit adgestrahit.

Wellenlänge: 780 nm

Maximale Strahlungsleistung der Lasereinheit: 100 μ W/VDE

Die Strahlungan der Lasereinheit ungefährlich, wenn folgende Punkte beachtet werden:


- Die Lasereinheit nicht zerlegen, da die Strahlung an der freigelegten Laserdiode gefährlich ist.
- Den werkseitig justierten Einstellregler der Lasereinhit nicht verstellen.
- Nicht mit optischen Instrumenten in die Fokussierlines blicken.
- 4. Nicht über längere Zeit in die Fokussierlines blicken.

Accessories

Rechargeable battery with carrying case1pc.	 Line cable
(RFKFBP140HSY)	(RJL2P007X)
Battery case1pc.	For EB area
(RFA1320-S)	 AC adaptor
Carrying case1pc.	(RFEA003B-
(RFC0056-K)	For EG area
Wired remote control1pc.	 AC adaptor
(RFEV023P-SM)	(RFEA002E-
Stereo earphones1pc.	For GH area
(RFEV319P-SA)	 AC adaptor

• Line cable	1pc.
(RJL2P007X08)	
For EB area	
AC adaptor	1pc.
(RFEA003B-S)	
For EG area	
AC adaptor	1pc.
(RFEA002E-S)	
For GH area	
AC adaptor	1pc.
(RFEA004H-S)	

Operating Instructions



Location of controls

Main unit 🛮

- Stop/power off/edit cancel button (M, POWER OFF)
- Play/record/pause/power on/ character type button (>/II, CHARA)
- Display Volume/cursor buttons
- Volume/cursor buttons
 (--,+-, VOL/CURSOR)
 Display, capital/lower case button (DISPLAY, CAPS LOCK)
 Changing edit mode, changing track merk mode, completing edit button (EDIT, MARK MODE)
 Jog dial (I◄, ►►, ENTER △)
 Tone/recording sensitivity/space button (EQ/REC SENS, SPACE)
 Open switch (OPEN)
 Play and record mode/character delete button (MODE, DELETE)

- delete button (MODE, DELETE) Hold switch (← HOLD)
- Recording pause/power switch (REC PAUSE)
- Headphone jack (())
 Optical digital in/line in jack
 (OPT/LINE IN)

- (OPT/LINE IN)


 Microphone jack
 [(PLUG IN POWER) MIC]


 Rechargeable battery compartment cover (◀ OPEN)

 Connection terminal for battery
- ① DC in jack (DC IN 1.8 V ♦-ⓒ-♦)

Stereo earphones E

Slide up to prevent tangling the cord when the earphones are not in use.





Location of controls

Wired remote control

- A Earphone jack

 Display
- Play/record/stop button Function selector/hold switch

Function selector/hold switch
(MAIN, SUB, HOLD)
The operation depends on the position of
this switch. Ensure the switch is in the
correct position before using the remote
control. These symbols are used to indicate the position of this switch in the instructions.

- Volume control/tone control/ track mark button (VOL +, EQ, T.MARK)
- Volume /play mode/recording pause button (VOL -, PLAY MODE, REC PAUSE)
- Sklp/search(forward)/light/dis-

Skip/search(forward)/light/display button

(▶▶, *LIGHT - DISP)

Skip/search (backward) button


(◄◄)

An operation tone sounds when buttons on the remote control are pressed. This tone is represented in these instructions by "♣".

Display information E

- Synchronized recording display
- Recording display Monaural play/record display Battery indication
- Play mode
- Remaining recording time

 Text
- Sound quality Disc mark
- Level meter



Power source

The rechargeable battery (included)

Put the battery into the unit.
The unit cannot recharge batteries other than the one supplied or recommended replace-

- 2 Connect the AC adaptor.

 ⑤ DC IN jack (DC IN 1.8 V ♦-C-♦)

 ⑥ Back panel of the unit

 ③ AC adaptor(included)

 ⑥ Household mains socket

Scrolls

"CHARGE" disappears when the battery is fully charged. It takes approximately 3 hours to recharge the supplied battery.

Disconnect the AC adaptor from and the household mains socket.

Note

The unit can only be recharged while it is

off.

The AC adaptor and battery may become warm during recharging but this is normal.

■ Recharging time and duration.
(When using the included rechargeable bat-

- Charging: Approx. 3 hours
 Playback: Approx. 8.5 hours
 Recording: Approx. 4.5 hours
 Duration may be reduced under some conditions.
- If the unit is to be used for long periods, such as during recording, use the AC adaptor to power it.


■ Rechargeable number times

The battery has reached the end of its useful life if play time dramatically reduces after recharging.

■ Replacement

Nickel-metal hydride rechargeable battery (RFKFBP140HSY).
Please inquire at a Panasonic dealer for a re-

placement.



Power source Dry cell battery

(not included)

Use one LR6 alkaline battery. Use long-life Panasonic alkaline batteries.

- 1 Put the battery into the battery case. External battery case (included) One LR6,AA,UM-3 battery (not included)

- 2 Attach the case to the unit.

 © Bottom of the unit

Note Insert the rechargeable battery when recording on dry cell batterles.

The battery indicator

The illustration shows how the indicator on the remote control display appears as battery power runs down.

② Full

④ Empty

When the indicator starts flashing The battery is almost flat and should be re-placed or recharged.

For longer use


- You will be able to playback for 20 hours and record for 9.5 hours if the two types of batteries are used together.
- •We recommend using long-life Panasonic alkaline batteries.


Using the AC adaptor (included)

Connect the AC adaptor.
Refer to the step 2 of "The rechargeable battery" for connection instructions.

The unit is in the standby condition when the AC adaptor is connected. The primary circuit is always "live" as long as the AC adaptor is connected to an electrical outlet.
Use only the supplied AC adaptor. Use of other adaptors can damage the unit. If the

other adaptors can damage the unit. If the unit is not to be used for a long time disconnect the AC adaptor from the household mains socket and turn the unit off to save





The HOLD function

This function stops the player and remote control from responding when a button is

(a) Hold mo(b) Release Hold mode

■ Guards against the following

- The unit is powered on accidentally when not in use, causing the batteries to run
- A button is accidentally pressed during play or recording, interrupting the operation.

Note
There is a HOLD switch on both the player and remote control, each of which works independent of the other.

■ The "HOLD" display

This is displayed for about 2 seconds on the main unit s and the remote control s display

- main unit a and the remote control s display panels when the following occurs.

 The main unit is on hold and a button is pressed. (If off, display appears only if [▶/II, CHARA] or [REC PAUSE] is op-
- The remote control s switch is moved to hold. The display also lights for about 5 seconds at this time.

Before recording

The two methods of recording

This method records the digital signals from CDs. Compared to analogue recording, this method makes it possible to make recordings of higher quality. Purchase an optical fiber cable (RP-CA2120 or RP-CA2220, sold separately) to record digitally.

Analogue

Analogue
Use this method to make analogue recordings of digital material, CDs and MDs, and to record analogue sources such as the radio.
Use the included line cord to make analogue recordings.

The recording modes

Normal

This method allows you to start and stop recording manually.

Synchronized

This method starts and stops recording at the same time as the source being record. Available with both digital and analogue recording.

One track synchronized

The first track on a CD is recorded and then the unit goes to recording standby. Recording starts again automatically when the first track on another CD is played. Available only when recording CDs digitally.

This function only works with tracks numbered "1".

Monaural

This mode allows you to record approximately double the amount of material normally possible. (For example, it is possible to record about 148 minutes worth of material onto a 74 minute MD.) Available only when

Before recording

Track marks

Track marks and track numbers

Like CDs, it is possible to select and play a track on an MD by selecting its track number. There are marks at the beginning of each track, called track marks, that make this possible. The period between each track mark is called a track.

Putting track marks on an MD

Auto mark mode


The unit automatically decides where track marks are to be put.

Manual mark mode

You can manually put the track marks where you want them to go.

Time mark mode (3 MIN, 5 MIN, 10 MIN)

Track marks are put at a preselected distance from each other.



Recording

Digital recording Connect this unit to a unit that has a digital output terminal.

has a digital output termis

① Digital output terminal
(portable ←→ portable)
Purchase en optical fiber cable
(RP-CA2220, soid separately).

② Digital output terminal
(deck ←→ portable)
Purchase an optical fiber cable
(RP-CA2120, sold separately).

LINE OUT terminal

Note

Disconnect other cables from the [(PLUG IN POWER) MIC] terminal.

Connect the microphone.

(a) Stereo microphone (not included)
Purchase a stereo microphone
(RP-VC200, sold separately).

- Disconnect other cables from the [OPT/LINE IN] terminal.

 Stereo recording is made if a stereo mi-
- crophone is used.
- Release hold.
 - Main unit
 Remote control


- Open the player and insert a recordable MD.

 1) Side (OPEN) to the right.
 2) Open the ild.
 3) Insert disc with label facing upward.
 Push the diac in the center until it

locks in place.

② Close the lid.

After an MD has been inserted the player turns on, reads the information from it, then, after a minute, the power goes off again.



Recording

4 Slide [REC PAUSE] to the

right.
The unit enters the recording mode.
If you have inserted an MD with recordings already on it, the unit prepares to record from the first available space.

- 5 Press [►/II, CHARA] (main unit) or the main button (remote control) to start recording.

 Main unit

 Remote control

 Beep
- 6 Start playback on the source to be recorded or point the micro-phone at the source of the sound.

Recording level is automatically set. Changes to volume will have no effect on Changes recording.

To select the recording mode Press [MODE, DELETE] while in

recording standby mode.

Each time the button is pressed the mode changes and an indicator is shown in the following order.

Digital recording Normal (No display)→SYNC→SYNC 1

Analogue recording

Normal (No display) --> MONO --> SYNC


Recording with a microphone Normal (No display)→MONO

SYNC: Synchronized recording SYNC 1: One track synchronized recording MONO: Monaural recording

If you have selected

- Synchronized recording (SYNC) or One track synchronized recording (SYNC 1)
 Recording begins automatically when you begin playback of the source.
 Monaural recording (MONO)
 Perform steps 5 to 6 to start recording.

if you set the recording mode to "SYNC", recording begins immediately if the source is already playing.



Recording

■ To pause recording

if you have selected
•Synchronized recording (SYNC)

resynchronized recording (SYNC)
Recording pauses if the source stops or if
2 seconds of silence is detected. (Track
number increases by one.)
Recording restarts when the source starts

track synchronized recording

(SYNC 1)
The unit automatically pauses after track 1 finishes. (Track number increases by

one.)
Recording restarts when another track numbered 1 is played.

Normal recording (No display) or

monaural recording

Press [▶/II, CHARA] (main unit) or [VOL -, PLAY MODE, REC PAUSE] (remote control) while recording. 🛮

(Track number increases by one.)

Main unit
 Remote control

. №: Веер

To restart recording ☐ Press [►/II, CHARA] (main unit) or the main button (remote control).

Main unit
Remote control
B: Beep

If you set the recording mode to "SYNC" or "SYNC1", you cannot pause recording man-

■ To stop recording 19
Press [■, POWER OFF] (main unit) or main button (remote control) while recording.

Main unit
Remote control

♪: Beep

•UTOC is recorded.

•The unit will turn off automatically after about 1 minute.

■ To turn the unit off 🖸 Press [■, POWER OFF] while stopped.



Ά

UTOC Writing

Recording

Adding track marks

Digital recording

When recording from CD

When recording from CD. The track marks are put onto the MD as they are found on the CD. Each time a new track starts on the CD, the number of the tracks on the MD increases by one.

(Track marks may not be inserted accu-

(Track marks may not be inserted accor-rately in some cases.)

When recording from digital sources other than CDs

2 seconds of silence is determined as the division between tracks and a track mark is added.

To add track marks manually

Analogue recording

2 seconds of silence is determined as the di-vision between tracks and a track mark is

To add track marks manually

Note Track marks will not be added if the space track marks will not be acided if the space between tracks is short or if there is noise in the space. Track marks may be added in error if there is a silent or especially quiet portion in a track. Use the editing functions fter recording to add and remove track marks.

Recording with a microphone Add track marks manually or have the unit add the marks at selected intervals.

■ Making good recordings

■ Making good recordings
Power the unit with the AC adaptor while
recording. If you intend to use batteries,
recharge the rechargeable battery fully and
use a new dry cell battery.

If the unit turns off while recording, or when
"UTOC Writing" is on the display ("WRITE"
on the remote control), the recording will
not be correctly recorded onto the disc. 基

"IDISC ERROPI" may appear on the display
if the unit turns off while "UTOC Writing" is
on the display.

Recording


Do not open the lid or shake the unit while

recording
Be especially careful while "UTOC Writing" is on the display ("WRITE" on the remote control). If the unit is moved at this time, the recording may not be correctly recorded onto the disc. You can damage the unit or disc if you try to force open the lid.

Note
This unit has a sampling rate converter so recording from equipment (DAT deck, BS tuner, etc) with a different sampling fre-

quency is possible.
•Insert the rechargeable battery when recording on dry cell batteries.

(For United Kingdom)
Your attention is drawn to the fact that
recording pre-recorded tapes or discs or
other published or broadcast material may infringe copyright laws.



Other recording **functions**

Ways of adding track marks

Apart from auto mark mode where the unit automatically adds the track marks during recording, there are also the manual and time mark mode methods.

1 Press [EDIT, MARK MODE] while the unit is in the recording standby mode to select the required marking mode.

The mode changes each time the button is pressed.

AUTO

Track mark are added automatically when the track changes.

MANUAL

Track marks can be added manually where required.

3 MIN

Track marks inserted at 3 minute intervals.

5 MIN

Track marks inserted at 5 minute intervals.

10 MİN -Track marks inserted at 10 minute intervals.

2 Press [►/II, CHARA] (main unit) or the main button (remote con-

- trol) to start recording.

 Main unit
 Remote control
 S : Beep

■ To add track marks manually В


Fers. the jog dial (main unit) or [VOL +, EQ, T.MARK] (remote control) when a track mark is required.

Main unit

Remote control

Begin track marks are added even if "MANUAL" has not been selected.

Note "AUTO" cannot be selected when recording with a



Other recording functions

Checking the remaining time on the MD 🖾

This function allows you to check the time available for recording before you start recording or while recording is in progress.

Press [DISPLAY, CAPS LOCK] (main unit) or press and hold [▶▶], •LIGHT →DISP] (remote control) while in recording standby mode or

while in recording standby mode or during recording.

Main unit

Remote control

S: Beep

The display changes each time this is done to show elapsed recording time and the remaining recording time.

- Number of track recording
 Elapsed recording time
 Available time for recording

Adjusting recording sensitivity

You can adjust the sensitivity of the unit for

analogue recording.
Press [EQ/REC SENS, SPACE] while


in recording standby mode.

The mode changes each time the button is pressed. REC SENS L←→REC SENS H

REC SENS L: To record from stereos and radio cassette players

REC SENS H:

To record from portable equipment



Playback (Basic play)

- Release the hold function.

 Main unit
 Remote control
- 2 Connect the earphones to the remote control then insert the remote control's plug into the headphone jack (()) on the player. (Plug in firmly.)
- Open the player and Insert an MD.
 - Silde (OPEN) to the right. Open the lid.

② Open the ild.
③ Insert disc with label facing upward. Push the disc in the center until it locks in place.
④ Close the lid.
After an MD has been inserted the player turns on, reads the information from it, then, after a minute, the power goes off again. The name of the disc or song is shown on the display. The information scrolls from right to left across the display if it can not be displayed all at once.

across the display in the carrier of the carrier of the control is displayed when the disc contains no track or disc tilles.

- 4 Press [►/II, CHARA] (main unit) or the main button(remote controi) to start play.


 Main unit

 Remote control

h: Beep
The player stops automatically when all the tracks on the disc have been played.

- 5 Adjust the volume.

 - Main unit
 Remote control
- +: To increase the volume level
 -: To decrease the volume level
 Volume range is 0-25.



POWER OFF

С

Playback (Basic play)

■ To pause play ☑ Press [▶/II, CHARA] (main unit) during play. Playback restarts when pressed again.

■ To stop the disc
Press [■, POWER OFF] (main unit)

or the main button (remote control) during play.

Main unit
Remote control

h: Beep The unit powers itself off automatically in about a minute.

■ To turn the unit off ⑤
Press [■, POWER OFF] (main unit)
while stopped.

■ Resume function

The player stores the point at which play was stopped and if [>/II, CHARA] on the main unit or the main button on the remote control unit or the main button on the remote control is pressed again, play begins from that point. This does not work if the player is opened or if the battery is removed. The player starts play from the first track in these cases.


■ Monaural playback

If a disc was recorded monaurally, the unit automatically switches to monaural playback

"MONO" appears on the main units display.)

- Nate
 If the display on the remote control disappears or seems unusual, disconnect the remote control then plug it in again firmly.

 This unit is vibration resistant but sound may skip if the vibration is constant.



Other playback functions

Skip 🛭

This function skips tracks and play begins from the beginning of the selected track. Main unit
Operation is the same as for "Title search"

Remote control

Press during play.

Backward
Beep Beep Beep

⊕ Forward♪: Beep Beep

For your reference:
You can skip more than one track by repeating this operation. The first skip backwards takes you to the beginning of the current track. Pressing the button in quick succession takes you back to previous tracks.

Search 🖪

This function allows you to fast-forward or movind through tracks.

Main unit

During play, press and turn the jog dial.

Backward

Forward


Playback resumes when you release the

B Remote control
Hold down during play.
Backward

Forward

For your reference:

- You cannot fast-forward past the end of the last track. If you release the button at this point, the player stops.
- eYou cannot rewind beyond the beginning of the first track. The player starts playing the first track if the button is released at this



Other playback functions

Title search

This function allows you to begin listening from a selected track.

Main unit

- 1 Turn the jog dial to select the track while stopped or during play.

 Backward
 Forward
 Track name and track number appear on

Track name and track number appear on the display.

After about 5 seconds (or when the title finishes scrolling if it takes more than 5 seconds) the previous display is restored.

- 2 Press the jog dial to play the specified track.
- Remote control
- Select a track by pressing while stopped.

 (a) Backward

 (b): Beep Beep Beep

 Forward


 (c): Beep Beep
- 2 Press the main button.

- For your reference:

 •You can hold the button of the remote control in place to go through tracks.

 •If [I◄] on the remote control is pressed or the jog dial on the main unit is turned left while the first track is selected then the last track is selected.
- track is selected.

 ●If [▶▶I] on the remote control is pressed or the jog dial on the main unit is turned right while the last track is selected then the first track is selected.



Other playback functions

Repeat and Random play

Press [MODE, DELETE] (main unit) or [VOL -, PLAY MODE, REC PAUSE] (remote control) when the player is stopped or playing.

Main unit

Remote control

A: Reaco

↑: Beep Every time the button is pressed the mode changes and an indicator is shown on the display in the following order.

1 track repeat (1- 👛)← One track is played over and over.

All track repeat ()

Andom (RANDOM, RND)
All tracks are played randomly once each then the player stops automatically.

Normal (no indicator is shown)-

Note
If you have selected the mode while stopped, press [▶/■, CHARA] (main unit) or the main button (remote control) to start playback.

- For your reference:


 When the player is in the all-track repeat mode, you can skip (on the remote control) and search beyond the first and last track.

 You cannot skip or search back to a track that has already been played when in random mode.
- of the arrows vector project with the main unit during random play, random play begins again from that track.
- The modes are cleared after changing discs.









Other playback functions

Sound quality

Press [EQ/REC SENS, SPACE] (main unit) or [VOL +, EQ, T.MARK] when the player is stopped or playing.

Main unit
Remote control

Beep
Every time the button is pressed the mode changes in the following order.

S-XBS←


Increases the power of the bass sounds.

TRAIN

Reduces sounds that may annoy others when you are using the player in a public place.

Normal (no Indicator is shown)-

Note
If you selected the mode when stopped,
press [▶/#Ⅱ, CHARA] (main unit) or the main
button (remote control) to start playback.



Other playback functions

Change the display

Press [DISPLAY, CAPS LOCK] (main unit) or press and hold [▶▶, •LIGHT → DISP] (remote control) when the player is stopped or playina.

- Main unit
 Remote control
 : Beep
 Track number
 Track name
 Elapsed playing time
 Remaining playing time
 Remaining recording time

- ↑: Beep

 ↑: Track number

 ↑: Track name

 Elapsed playing time

 Remaining playing time

 Remaining recording time


 Discitite

 Total number of tracks

 Total playing time

A While stopped While playing

♦ Changes each time the button is pressed ♦ Changes automatically after a few seconds ("NO TITLE" (main unit) or "-y--" (remote control) is displayed when the disc contains no track or disc titles.)



Other useful **functions**

About the display

■ To light the remote control's

display
The display lights for about 5 seconds when an operation is done on the remote control. It remains lit for up to 20 seconds while a track or disc title is scrolling on the screen.

- Checking the display of the remote control ☑ Press [►►I, •LIGHT = DISP]. The display lights for 5 seconds.
- Adjusting the display's contrast 🖪
- Turn the unit on and put it in hold.
- 2 Press and hold [►/II, CHARA] on the main unit and...
- on the main unit and...

 Press [~-, + -, VOL/CURSOR]
 (main unit) or [VOL +, EQ,
 T.MARK] or [VOL -, PLAY
 MODE, REC PAUSE] (remote
 control).

 Main unit
 Remote control

 : Beep
 +: darker, -: lighter

The operation tone of the remote control 6


A tone sounds when a button on the remote

control is pressed.
The tone can be turned on and off.
Press and hold the main button until

following display appears.

To turn on
 To turn off

if the above is done during play, play stops and power automatically goes off in about 1 minute.



Editing MDs

MOVE (Moving tracks)

Rearrange the order of the tracks. The new order is recorded onto the MD so the tracks are always played in the order.

- 1 Press [EDIT, MARK MODE] while stopped.
- ① Turn the jog dial to select "MOVE?".

② Press It. Now the display is in the mode to select track to be moved.

- 3 ① Turn the jog dial to select the track to be moved.

 (a) Track number decreases
 (b) Track number increases

 - ② Press It.

© Track being moved
@ New position

Now the display is in the mode to select the new position.

- ① Turn the jog dial again to se
 - lect the new position.


 (a) Track number decreases
 (b) Track number increases

② Press it.
The display asks you to confirm your se-

5 Press [EDIT, MARK MODE]. When "UTOC Writing" goes out editing is complete and the unit stops.

To stop part way through an editing operation
Press [, POWER OFF] before confirming

the operation in step 5.



Editing MDs

- When performed while playing or paused
- Press [EDIT, MARK MODE] while the track you want to move is playing or paused.
- 2 ① Turn the Jog dial to select "MOVE?".
 - ② Press the jog dial.
- 3 ① Turn the jog dial to select the

new position.
② Press the jog dial.
The display asks you to confirm your selection.

Press [EDIT, MARK MODE]. When "UTOC Writing" goes out editing is complete and the unit stops.

ERASE (Erasing tracks)

Erase one track at a time with TRACK ERASE, or erase all the tracks on the MD with ALL ERASE. When tracks are erased with TRACK ERASE, the tracks following move back to fill in the space and the number of tracks reduces by one each time the operation is performed.

ALL ERASE

- 1 Press [EDIT, MARK MODE] while
- 2 ① Turn the log dial to select "ALL ERASE?".


② Press it. The display asks you to confirm your selection.

3 Press [EDIT, MARK MODE].
When "UTOC Writing" goes out editing is complete and the unit stops.
("BLANK DISC" appears on the display.)

To stop part way through an editing

operation
Press [■, POWER OFF] before confirming the operation in step 3.

Note ALL ERASE cannot be used while the disc is playing or paused.



Editing MDs

TRACK ERASE

- Press [EDIT, MARK MODE] while stopped.
- 2 ① Turn the jog dial to select "TRACK ERASE?".
 - ② Press it.
 Now the display is in the track selection
- mode. 3 ① Turn the jog dial to select the track to erase.
 ② Track number decreases
 ③ Track number increases
 ② Press It.
 The display asks you to confirm your selection.
- Press [EDIT, MARK MODE].
 When "UTOC Writing" goes out editing is complete and the unit stops.

To stop part way through an editing

operation
Press [■, POWER OFF] before confirming the operation in step 4.

- When performed while play-Ing or paused
- Press [EDIT, MARK MODE] while the track you want to erase is playing or paused.
- 2 ① Turn the jog dial to select "TRACK ERASE?".
- ② Press the jog dial.
 The display asks you to confirm your selection.
- Press [EDIT, MARK MODE]. When "UTOC Writing" goes out editing is complete and the unit stops.



1



2





3



Editing MDs

COMBINE (Combining 2 tracks)

Remove a track mark from between two tracks, effectively making them one track. (If you combine tracks 2 and 3, for example, the track will take the number 2 and also retain the title for track 2.)

1 Press [EDIT, MARK MODE] while playing the latter of the two tracks you want to combine (or while paused!)

- uncks you want to combine (or white paused).

 1 Turn the jog dial to select "COMBINE?".

 2 Press it.

Press it.
 track before
 track playing
 The display asks you to confirm your selection. In the example, the last eight seconds of track 2 and the first eight seconds of track 3 play repeatedly.
 Press [EDIT, MARK MODE].
 When "UTOC Writing" goes out editing is complete and the unit stops.
 To stop part way through an editing operation

operation
Press [B. POWER OFF] before confirming the operation in step 3.

- wnen performed stopped ■ When
- Press [EDIT, MARK MODE] while
- the disc is stopped.


 2 ① Turn the jog dial to select "COMBINE?".
- Press the jog dial.
 Now the display is in the mode to select the tracks to be combined. 3 ① Turn the log dial to select the
- two tracks to combine.

 ② Press the log dial.

 Press [EDIT, MARK MODE].

 When "UTOC Writing" goes out editing is complete and the unit stops.
- Note
 COMBINE does not work while playing track 1.

 •You cannot combine a track recorded nor-
- mally and a track recorded monaurally.



Editing MDs

DIVIDE (Dividing a track into two)

This allows you to add track marks, making it easy to divide a classic piece into its separate movements, for example.

- Press [EDIT, MARK MODE] while playing the track you want to di-
- 2 ① Turn the jog dial to select "Di-VIDE?".

 ② Press it at the point you want
 - to divide the track.

A 4 second segment (8 seconds if track is monaural) of the track is played repeatedly, beginning at the point selected.

To adjust the point
Turn the jog dial to adjust the point.
Adjustments can be made approximately
8 seconds (16 seconds if track is monaural)
either side of the original point.
(-128 to +127)

3 Press the log dial.
The display asks you to confirm your se-

Press [EDIT, MARK MODE]. When "UTOC Writing" goes out editing is complete and the unit stops.

To stop part way through an editing

operation
Press (■, POWER OFF) before confirming the operation in step 4.


●If you divide a track with a title, the latter track becomes untitled.

•DIVIDE cannot be used while the unit is

stopped.









Titling MDs

Titling discs and tracks

Tracks and discs can have a titles up to 100 characters long.

- 1 Press [EDIT, MARK MODE] while stopped. "TITLE?" appears on the display.
- 2 (A) When titling a disc
 - ① Press the jog dial.
 "DISC TITLE?" appears on the display.

 - play.

 ② Press it again.
 The text editing mode is entered.

 ③ When titling a track
 ① Press the jog dial.
 "DISC TITLE?" appears on the dis
 - play.
 ② Turn it to select the track
 - you want to title.

 ③ Press the jog dial.


 The text editing mode is entered.
- 3 Enter the title. (See page 62.)
- Press [EDIT, MARK MODE].
 When "UTOC Writing" goes out editing is complete.

■ After titling a disc
The display automatically shows the track titling display. Follow the steps for titling tracks.

■ To stop part way through an editing operation Press [, POWER OFF].

The normal display is restored.

Note If you start entering a title while a track is playing, the track repeats until you finish.



Titling MDs

Copying a title from one MD to another (TITLE STATION)

The unit temporarily records the titles from an MD so they can then be copied onto another MD.

- Before proceeding

 •You cannot copy titles from prerecorded MDs.
- MDs.

 You can copy the title only if both MDs have the same number of tracks.


 Any titles on the second MD are replaced when this function is used.
- 1 Insert the MD with the title.
- 2 Press [EDIT, MARK MODE] while stopped.
- 3 ① Turn the jog dial to select "TITLE COPY?".
 - ② Press It.
 "TAKEOUT DISC" is displayed when the unit has recorded the title.

Eject the MD.
"CHANGE DISC" is displayed when the lid is opened.

Insert the other MD.

After "TOC Reading" is displayed, the display asks you to confirm the opera-

6 Press [EDIT, MARK MODE]. When "UTOC Writing" goes out editing is complete and the unit stops.



Titling MDs


Entering text

1 Press [>/II, CHARA] to select the type of characters. The type changes each time the button is pressed. English capitals —

English lower case

Numerals and symbols-2 ① Turn the jog dial to move the cursor over the character you want to enter.

- Press it to enter the character. Entered text
- Press in to enter the character
 Entered text
 Characters
 The character you selected is entered.
 The cursor moves to the right and shows where the next character will be entered.
- To move the cursor 🗉 Press [---, +--, VOL/CURSOR]. +--: right ---: left
- To erase a character
- Press to move the cursor over the character you want to erase.
- Press [MODE, DELETE].
 The characters after the erased character move back to take its place.



Titling MDs


- Correcting titles
- Press [--, +-, VOL/CURSOR] to move the cursor over the char-1 acter you want to correct.
- 2 ① Turn the jog dial to move the cursor over the character you
 - want to enter.

 ② Press it to enter the character.
 The new character replaces the old one.
- To insert an extra character 🗈
- Press [---, +--, VOL/CURSOR] to move the cursor over the place you want the character to go.
- 2 Press [EQ/REC SENS, SPACE].
- 3 ① Turn the jog dial to select the character to enter.
 ② Press it to enter the character.
 The character is inserted.
- Changing capitals into lower case or lower case into capitals 🖸
- Press [---, +--, VOL/CURSOR] to move the cursor over the char-1 Press [acter you want to change.
- 2 Press [DISPLAY, CAPS LOCK].
- To exit the text editing mode part way through
 Press [■, POWER OFF].
 The normal display is restored.

Titling MDs

■ Characters available for tities.

To State	
	ABCDEFGHIJKLMNOPQRST UVWXYZ
	abcdefghijklmnopqrstuvwxyz
avoider il Vinte (il	0123456789 !"#\$%&'()++,/:;<= >?@_`^



Using the unit with optional accessories

- Read the operating instructions of the items
- •Use the recommended accessories to ensure correct operation.

■ Connection to a stereo system 🛭

You can listen to or record the sound from rou can listen to or record the sound from this unit on other audio equipment. Disconnect the earphones from the remote control and connect the stereo equipment with one of the following line cords.


if the amp's connection is; a line connection: Use the included line cord.

- a mini-phone jack:
 Obtain the optional line cord

 (a) Headphone jack
 Line cord
 (b) Amplifier
 (c) (white)

- (red)
- Turn off the power to all units before making connections.

 ■Either turn the remote control's operation
- tone off or perform the operations on the main unit.



Some useful information about MDs

Types of MDs Z

Prerecorded MDs

These discs are for playback only.

Recording MDs
 Apart from the time limitations, it is possible to record up to 254 tracks on an MD.

■ Care and storage

Label MDs only as recommended. Extra la-bels and exposed adhesive can cause malfunctions.

Do not open the shutter. Close it immediately if it accidentally opens. Never touch the disc inside the MD cartridge.

© Shutter

Protecting your recordings
Move the switch to open the write protect hole. Close the hole when you want to record or edit the MD again.

- Record protected
 Record enabled

■ Recording MDs

■ Recording MDs
MDs are different to tapes
MDs give you control over how tracks are recorded and editing functions allow you to change the contents of an MD after recording. Unlike cassettes, it is not necessary to find an empty portion to record onto. All recordings start from the first available space. The MD fills up and when the disc is full, either because the time limit has been reached or 254 tracks have been recorded, recording is no longer possible. You can use the editing functions to erase and move your recordings around within the MD.

Limitations on digital record-

ing
The serial copy management system (SCMS) prevents unlimited recording of digi-

tal material.

Digital recordings are of high quality, but to protect the rights of the producer of the original material, it is only possible to make one digital recording of a digital recording. This also applies if you record analogue material digitally. That digital recording can be recorded digitally once more, but is blocked after that

Analogue recordings are otherwise unaffect-

■ Glossary of terms

Table of contents, Information stored on the MD about the tracks and times.

User table of contents. This is Information the user can edit, such as text and track posi-

user cent was, a...
tions.
The message "UTOC Writing" appears on the display after recording and editing.

Troubleshooting guide

Before requesting service for this unit, check the chart below for a possible cause of the problem you are experiencing. Some simple checks or a minor adjustment on your part may eliminate the problem and restore proper operation. If you are in doubt about some of the check points, or if the remedies indicated in the chart do not solve the problem, refer to the directory of Authorized Service Centers (enclosed with this unit) to locate a convenient service center, or consult your dealer for instructions.

	white the state of
	●Is the hold function on? ■Is a disc loaded? ■Is the unit completely connected to the AC power source? ●Have the batteries run down? ●Is there a problem with the disc?
Retinos trainvers	Have you inserted a blank disc?
edigely is of the division of the state of t	Has the play mode been switched to "RANDOM" ("RND")? Did you stop the disc part way through the last time you listened to it?.
Cie paperi laiz dozumie Martin Kore	Have you inserted a playback disc? Is the disc write protected? Is the unit correctly connected to the other equipment? Is the digital optical signal being correctly output from the other equipment?
MINITED TO THE PARTY OF THE PAR	Are you using the player near a strong magnet, such as may be found in a television?
Phos conjultion that the state of the state	Has the volume been turned down too far? Have the plugs on the earphone and remote control been inserted correctly? (Try plugging it in again.) Are the plugs dirty? (Wipe away dirt on plug.)
Disc and fact tities are incorrectly displayed or not displayed at all:	Have you entered more text than the MD can hold? (1792 characters can be entered.)
The unit cannot be	Have the batteries run down, or is the unit incompletely connected to the AC power source?

Displays

A blank disc has been Inserted. The reason is shown on the lower line of the display. The limitations of the system sometimes mean tracks cannot be combined. The limitations of the system sometimes mean tracks cannot be divided. The limitations of the system sometimes mean tracks cannot be divided. The reason is shown on the lower line of the display. Check the digital optical fiber cable connections and try again. There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Eject the MD, reinsert it and start recording from the beginning again.
The limitations of the system sometimes mean tracks cannot be combined. The limitations of the system sometimes mean tracks cannot be divided. The reason is shown on the lower line of the display. Check the digital optical fiber cable connections and try again. There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing.
De combined. The limitations of the system sometimes mean tracks cannot be divided. The reason is shown on the lower line of the display. Check the digital optical fiber cable connections and try again. There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
be divided. The reason is shown on the lower line of the display. Check the digital optical fiber cable connections and try again. There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
Check the digital optical fiber cable connections and try again. There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
There is a problem with the disc and it needs to be replaced. The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
The maximum time or number of tracks has been reached. Either erase some tracks or record with another disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
Either erase some tracks or record with anomer disc. The write protect hole is open. Close it to enable recording and editing. A problem occurred during recording. Elect the MD, reinsert it
A problem occurred during recording. Elect the MD, reinsert it
A problem occurred during recording. Elect the MD, reinsert it
There is a problem with the magnetic head.
The hold function is on.
The batteries have run down.
A disc has not been inserted.
**Raynack Disc
You are trying to make a second copy of a digital recording.
SYSTEMBER 101 Self diagnosis function has found an error.
TOC Reading (T-READ) Reading TOC information.
TRACK NUMBER, NOT The number of titles doesn't equal the number of titles on the target disc. Make the number equal.
You are trying to enter the text beyond 100 characters.
The display appears for one of the following reasons: • The maximum number of tracks (254) has been reached; erase unneeded titles to make room. • Due to limitations of the recording system, UTOC may become full before the maximum number of tracks or time capacity is reached. Replace the MD. • The section reserved for text information is full; erase unneeded titles to make room.
UTOC Writing TWRITE UTOC is recorded.

Remote control displays indicated inside [].

Maintenance

■ If the surfaces are dirty
To clean this unit, wipe with a soft, dry cloth.

If the surfaces are extremely dirty, use a soft cloth dipped in a soap-and-water solution or a weak detergent solution.

Never use alcohol, paint thinner or benzine to clean this unit.


Before using chemically impregnated cloth, read the instructions that came with the cloth carefully.

4 Handling Precautions for Traverse Deck (Mechanism Unit)

The laser diode in the mechanism unit (optical pickup) may break down due to potential difference caused by static electricity of clothes or human body. So, be careful of electrostatic breakdown during repair of the mechanism unit (optical pickup).

4.1. Mechainsm Unit (optical pickup)

- 1. Do not subject the mechanism unit (optical pickup) to static electricity as it is extremely sensitive to electrical shock.
- Before you take off MD mechanism unit (optical pickup), short the short-land of the flexible P.C.B. by using a solder. (refer to Fig.1)
- 3. Take care not to apply excessive stress to the flexible board (FFC).
- 4. Do not turn the variable resistor (laser power adjustment). It has already been adjusted.



4.2. Caution for repairing of MD mechanism (optical pickup)

The short-land of MD mechanism (optical pickup) as replacement part is shorted with a solder build-up. Remove the

solder after you insert the flexible P.C.B. into the connector.

4.3. Grounding for electrostatic breakdown prevention

1. Human body grounding

Use the anti-static wrist strap to discharge the static electricity from your body. (As shown in Fig. 2.)

2. Work table grounding

Put a conductive material (sheet) or steel sheet on the area where the optical pickup is placed, and ground the sheet.

Caution:

The static electricity of your clothes will not be grounded through the wrist strap. So, take care not to let your clothes touch the traverse deck (optical pickup).




Fig. 2

Operation Checks and Main Component Replacement **Procedures**

- NOTE 1. This section describes procedures for checking the operation of the major printed circuit boards and replacing the main components.
 - 2. For reassembly after operation checks or replacement, reverse the respective procedures. Special reassembly procedures are described only when required.
 - 3. Select item from the following index when checks or replacement are required.

Contents

- Checking Procedures for each P.C.B.
- 1. Checking for the main P.C.B..
- 2. Checking for the rec head P.C.B..


■ Main Component Replacement Procedures


- 1. Replacement for the LCD.
- 2. Replacement for the intermedeate cabinet ass'y.
- 3. Replacement for the spindle motor ass'y.
- 4. Replacement for the traverse motor and lift motor.
- 5. Replacement for the magnetic head and optical pickup ass'y.


■ Checking Procedures for each P.C.B.

1. Checking for the main P.C.B.


(Checking for the main P.C.B. (A side))







· Check the main P.C.B. (A side) as shown below.



(Checking for the main P.C.B. (B side))


Each parts on main P.C.B. (B side) can not be checkesd directly, however, for the checking of main component parts on P.C.B., refer to the "Checking procedures of main components parts on the main P.C.B. (B side).


2. Checking for the rec head P.C.B.

• Follow the Step 1 ~ Step 4 of the item 1 in checking procedures for each P.C.B.,

Step 1


Push the open knob, and then open the disc cover ass'y.





Release the hooks of both sides, and then place the disc cover ass'y backward.


· Check the rec head P.C.B. as shown below.





■ Main Component Replacement Procedures


1. Replacement for the LCD

- Follow the Step 1 ~ Step 4 of the item 1 in checking procedures for each P.C.B..
- Follow the Step 1 ~ Step 3 of the item 2 in checking procedures for each P.C.B..











Step 7

Remove the FFCs from the connectors. (2 points)



Release the hooks, and then remove the operation P.C.B..

Step 8




NOTE

When installing the LCD, align it with hooks, and then lock it with claw.


Notice for installation of operation P.C.B. angle ass'y

 When installing the operation P.C.B. angle ass'y to the disc cover ass'y, locate the rec knob in the direction of arrow fully, and then align it with notch of rec lever.




2. Replacement for the intermediate cabinet ass'y

• Follow the Step 1 ~ Step 3 of the item 1 in checking procedures for each P.C.B..





Push the open knob, and then




Notice for installation of intermediate cabinet ass'y

 Align the claw of hold with the slot of hold lever.






2. Align the claw of open with the slot of open lever.




3. Replacement for the spindle motor

- Follow the Step 1 ~ Step 3 of the item 1 in checking procedures for each P.C.B..
- Follow the Step 1 ~ Step 3 of the item 2 in main component replacement procedures.



NOTE


Insert a short pin into the traverse unit FFC board.
(Refer to "Handling Precautions for Traverse deck".)



Remove the FFC from the connectors. (6 points)


Step 3

Release the claw, and the lift up the main P.C.B..




■ Notice of installing the main P.C.B.

 Align the boss of hold switch with the notch of hold lever.




Step 4

Release the jack from the hole of chassis, and then remove the main P.C.B..



Remove the FFC through the slot of main P.C.B. gradually to prevent damage to the surface of FFC.




4. Replacement for the traverse motor and lift motor ass'y

- Follow the Step 1 ~ Step 3 of the item 1 in checking procedures for each P.C.B..
- Follow the Step 1 ~ Step 3 of the item 2 in main component replacement procedures.
- Follow the Step 1 ~ Step 4 of the item 3 in main component replacement procedures.

Step 1


Remove the washer, and then pull out the intermediate gear.



Claw


Step 2

Release the 2 claws in the direction of arrow, and then remove the drive gear (L).






Remove the washer, and then pull out the down gear and relay gear.










Step 5

Remove the traverse motor and lift motor ass'y.



Step 6

Peel the FFC.

Traverse motor



Solder Lift motor ass'y

terminal.

Lift motor ass'y


Pull out the motor gear.

Notice for Installation motor gear


Motor gear Spring

The spring should be interfered with the end of motor gear.

Notice for installation of drive gear (L)





 Slide the drive rod in the direction of arrow fully.




5. Replacement for the magnetic head and optical pickup ass'y

- Follow the Step 1 ~ Step 3 of the item 1 in checking procedures for each P.C.B..
- Follow the Step 1 ~ Step 3 of the item 2 in checking procedures for each P.C.B..
- Follow the Step 1 , Step 2 of the item 1 in main component replacement procedures.
- Follow the Step 1 ~ Step 3 of the item 2 in main component replacement procedures.
- Follow the Step 1 ~ Step 4 of the item 3 in main component replacement procedures.







NOTE

- 1. Use care to prevent damage the optical pickup, due to the precision construction.
- 2. Do not touch the lens of the optical pickup.
- 3. Never touch the set screws for magnetic head.

6 Operating Procedures

6.1. Operating Procedures

Play

- 1. To read the signals recorded on the disc, the laser beam emitted by the laser diode (LD) strikes the disc and is reflected back and detected by the photodetector (PD).
 - For a pre-mastered disc, similar to a CD, the signals are recorded as pits on the surface of the disc, and the signals are detected by the amount of light reflected when the laser beams strikes the pits.
 - For a recordable disc, the signals are recorded by magnetizing the magnetic film on the surface of the disc and there is no variation in the amount of light that is reflected, so the signals are detected using the shifting of the polarization of the reflected light due to the Kerr effect (*1).
- 2. The detected signals are input to pins 38 and 39 of the RF IC (IC1), where they are amplified and then output from pin 32.
 - By observing the input signals (between pins 38 and 39) and the output signals (pin 32) on an oscilloscope, it is possible to check the eye pattern.
 - This unit SJ-MR100 makes the disc rotate double velocity, reading the signal from disc at double velocity. It has blank about 40 seconds till next reading after reading the signal once.
- 3. Error correction of the amplified signals is performed by the MD LSI (IC101:MN66616) using EFM demodulation and ACIRC (*2) and the signals are stored in the 16M DRAM (IC102:MNA7400CWAIT). At this time, the cycle of the signals is adjusted by the LSI's clock in order to eliminate any jitter that might result from irregular revolution of the disc.
- 4. The signals are sequentially taken from 16M DRAM (IC102) and send back to MD LSI (IC101), where they are ATRAC (*3)-decorded.

The above-mentioned items 1-4's signals are all digital.

5. Digital audio signals that are outputted from MD LSI, inputted to 15pin of AD/DA converter (IC601:AK4518), converted to analog signal and outputted from 19 (left channel) and 18 (right channel) pins.

The signal that converted to analog is amplified at POWER AMP (IC201:TA2131), outputted to HEADPHONE terminal.

• The exchange of signals between the DRAM and the MD LSI is performed using four data lines (pin 1, 2, 24 and 25 of the DRAM and pin 43, 44, 45 and 46 of the MD LSI).

Record

- 1. Analog signal that is inputted from MIC IN or LINE IN, is amplified at LINE/MIC AMP, inputs to 6 (left channel) and 3 (right channel) pins of AD/DA converter (IC601).
- 2. The analog signals input to the A/D-D/A converter (IC601) are converted to digital signals with a sampling frequency of fs=44.1kHz and then output from pin 12 to pin 65 of the MD LSI (IC3).
- 3. The signals input from OPTICAL IN are input to pin 70 of the MD LSI (IC3).
- 4. The signals input to pin 70 of the MD LSI (IC101) are converted to a sampling frequency of fs=44.1kHz by an fs converter inside the LSI. If the signals are already fs=44.1kHz, they bypass the fs converter.
- 5. The signals converted to fs=44.1kHz or the signals input to pin 65 are ATRAC-encoded and stored in the 16M DRAM (IC102).
- 6. The signals are sequentially taken from the 16M DRAM (IC102) and sent back to the MD LSI (IC101), where they are ACIRC-processed and EFM-modulated and then output from pin 73 and pin 73 to the magnetic head.
- 7. The magnetic disc records the signals onto the disc by magnetizing the magnetic film on the surface of the disc. During recording the laser diode emits its laser beam in order to raise the temperature to the Curie temperature (*4) that is required to magnetize the magnetic film. For this reason, the optical power of the laser diode is higher during recording than during playback.

In the case of this unit SJ-MR100, it is performed to write to the disc with double velocity (disc rotation is also double velocity). TOC writing is continuous movement (recording signal to magnetic head is sent with continuously).

Control

- 1. Performs the necessary controls for each operation during playback and recording and for writing of the UTOC (*5) at the end of recording.
 - · The information written in the UTOC includes the recorded track numbers and their addresses, text data, etc.
- 2. Performs the necessary displays of the text data recorded on the disc and for each operation.

The system is designed for integrated operation, so that the system control IC (IC101) on the MD servo PCB.

Clock

- The controls of the playback signal, recording signals, 4-channel driver IC, and of the RF IC (IC1) all function using the clock on the MD LSI as the master clock.
- A/D-D/A converter (IC601) is using FS384 signal of MD LSI as clock.

*1 Kerr effect

A phenomenon in which the polarization plane of laser light reflected from a material shifts in one of two directions depending upon its "plus" or "minus" magnetic polarization.

*2 ACIRC Add on interleave CIRC

The aim of Add-on interleave is to improve the resistivity in CD-ROM decoder from the burst error on the disc.

*3 ATRAC Adaptive Transform Acoustic Cording

The digital data compressing system developed for MiniDisc in which audio signals can be reproduced with only about 1/5th in the data normally required for high fidelity reproduction.


*4 Curie temperature

The temperature at which magnetism of a specific material dissipates. This temperature varies according to the material.

*5 UTOC...... User Table Of Contents

Found only on recordable MiniDiscs, this area contains subdata (track number, etc.) which can be rewritten by the user.

6.2. Block Diagram



7 Measurements and Adjsutments

Note:

If you exchange mechanism unit "RAE1620Z" when you repair, you must perform the automatic adjustment and checking of "playback-only disc" "magneto-optical disc" at the "adjustment mode".

■Instruments to prepare

- 1. Test disc (Playback-only disc)
- 2. Commercially available recordable disc (fully recorded with music) (magneto-optical disc)
- Laser power meter (Advantest TQ8210 or compatible meter)
- 4. Insulated driver for adjustment such as a ceramic driver
- 5. Remote controller


■Laser power adjustment, Playback-only disc/magnetooptical disc automatic adjustment

- · How to enter adjustment mode
- 1. Check the PC board. (Refer to the item of "Checking for the P.C.B." in "Operation Checks and Main Component Replacement Procedures").
- 2. Set the battery and connect the remote controller.
- 3. Make the optical pickup move to the center of the moving range.
 - *How to make it move.
 - a. Play the track No.4 or 5 of Playback-only disc.
 - b. Remove the battery on the playing (switch off the power).
 - c. Remove the disc. Confirm that the optical pickup's position is about in the center, and close the disc cover,
 - d. Switch on the power.


Note)

If the optical pickup does not move to the center by this method, you don't have to adjust. You must repair with refering to "Troubleshooting Guide".


- 4. Turn off the power, and switch main unit's HOLD switch off.
- 5. Turn off the power. Then, with the main unit's HOLD switch at OFF, press the VOL+, VOL-, ▶▶, and ◄◀ buttons on the remote controller within two seconds without pressing the OFF button.
 - a. Using your thumb, while pressing the VOL+ button, also press the VOL- button.
 - b. Then, while still pressing the VOL- button, release your thumb from the VOL+ and press the ▶▶ button.
 - c. While still pressing the ▶▶ button, release your thumb from the VOL- button and press the ◄◀ button. Then, while still pressing the ◄◀ button, release your thumb from the ▶▶ button and then from the ▶■ button. (a-c are shown in Fig.3)



Using your thumb, while pressing the VOL+button, also press the VOL- button.



Then, while still pressing the VOL— button, release your thumb from the VOL+ and press the ▶▶ button.



While still pressing the ▶▶ button, release your thumb from the VOL—button and press the ◄ button. Then, while still presssing the ◄ buttom, release your thumb from the ▶▶ button and then from the ◄ button.

Fig.3

6. When the adjustment mode is activated, "TA" will be displayed on the LCD of remote controller. After "TA" is displayed, select the desired adjustment item with the ▶▶ button or ▶■ button of the remote controller.

Adjustment mode	Display
Playback-only disc automatic adjustment	<u>T1</u>
Magneto-optical disc automatic adjustment	T2
Playback-only disc automatic adjustment value check	T3
Magneto-optical disc automatic adjustment value check	T4
Laser power check	T5
ADIP/EFM jitter meajurement (double velocity)	T6
ADIP error late meajurement (double velocity)	T7
Error rate measurement (double velocity)	T8
Tilt measurement (disc middle speed)	Т9
PWB inspection (audio test)	TĀ
PLAY/REC erase mode	TB
No blank disk play mode	TC
Asing mode	TD
(Spare)	TE

*In the display of T1 ~ TA shown above, you must adjust T1, T2 and T5. You must perform the adjustment by observing the order T5 \rightarrow T2 \rightarrow T1.

7.1. Laser Power Adjustment

Adjust each laser power: read power for reading (play) and write power for writing (record).

7.1.1. Set the Unit to the Adjustment Mode

Cautions

1. About handling the MD unit

- The magnetic head is a precision unit and is very fragile. Do not deform it.
- Laser diode in the optical pickup may be destroyed by the staticelectricity generated in your clothes or body. Be especially careful with the static electricity.
- The optical pickup is structured extremely precisely.
 Do not subject to the strong impact or shock. Do not touch the lens.

2. About the driver for adjusting laser power

Use only insulated driver such as a ceramic driver. With the metal driver, it is not possible to adjust properly because of the induction noise. Also, if it short-circuits with the chassis, it may destroy or damage the laser diode.

Recommended driver: VESSEL 9000 1.8 -30 (Ceramic driver)

3. Cautions on optical pickup:

- The optical pickup and the magnetic head are structured precisely; therefore, they are very fragile.
 Be careful not to touch them with the edge of the laser power meter.
- The sensor of the laser power meter is a very fine part. Be careful not to touch it to the optical pickup lens.
- Do not loosen or remove the magnetic head installing screw.
- The focus point of the laser reaches to 356°F.
 Therefore, avoid adjusting using laser power for a long time because the sensor of the laser power meter may be burned.
- · Do not allow the write power to even momentarily

- reach or exceed 5 mW. Doing so will result in damage to the optical pickup.
- Do not set the unit to the laser power adjustment mode with the MD loaded. Doing so may result in damage to the MD.

7.1.2. Adjustment Procedure

- 1. Show "T5" on the LCD by pressing the button of the remote controller.
- 2. Make the sensor cover of the laser power meter slide. (refer to Fig.4)





Fig.4


3. Set the laser power meter. (refer to Fig.5)



Laser power meter

Fig.5

- Press the PLAY key of the remote controller ("T5" changes to "LP" of the LCD).
- 5. Perfome the read power adjustment. Turn VR1 and set to 600uW±10%. (refer to Fig.6)



6. Press the key of the remote controller ("LP" changes to "BLDA" in the LCD).

Specified range (read power): 600 uW±10% or lower

Caution:

- Proceeding on to the subsequent adjustment procedure with the read power exceeding 600uW±10% will result in damage to the optical pickup.
- 7. Perfome the light power adjustment. Set the light power at 4.5mW by using VOL+ and VOL- key of the remote controller. Then, if the voltage between TP405 and TP406 devided by 1Ω is more than power supply indication of

optical pickup FPCx1.2, it is optical pickup breakdown.

8. Press the key of the remote controller ("BLDA" changes to "LP" on the LDC. At this time, the data is written to EEPROM.).

Specified range (light power): 4.5mW

Caution:

- Do not allow the write power to even momentarily reach or exceed 5 mW. Doing so will result in damage to the optical pickup.
- 9. Press the PLAY key on the remote controller ("LP" changes to "T5" on the LCD.).
- 10. Remove the laser power meter. Laser power adjustment is finished.

· Magneto-optical disc automatically adjustment

- Show "T2" on the LCD by pressing the button of the remote controller.
- 2. Set the full-recorded magneto-optical disc with the prevention erase situation.
- Press the PLAY key of the remote controller ("T2" changes to "OAADJ" on the LCD, adjustment is started.).
- 4. If it has been finished normally, "OAADJ" changes to "OAOK" on LCD. If it is abnormally, it changes to "OANG".
- Press the PLAY key ("OAOK" or "OANG" changes to "T2", magneto-optical disc adjustment is finished.).

Note

If it is displayed "OANG", check the "Troubleshooting Procedures" in the order.

· Playback-only disc automatically adjustment

- Show "T1" on the LCD by pressing the button of the remote controller.
- 2. Set the playback-only disc.
- 3. Press the PLAY key of the remote controller ("T1" changes to "OOADJ" on the LCD, adjustment is started.).
- 4. If it has been finished normally, "OAADJ" changes to "OOOK" on LCD. If it is abnormally, it changes to "OONG".
- Press the PLAY key ("OAOK" or "OANG" changes to "T1", playback-only disc adjustment is finished.

Note)

If it is displayed "OONG", check the "Troubleshooting Procedures" in the order.


After the 1.2.3. adjustment written above, remove the battery when you finish the adjustment mode.

■Checking the main unit's keys


- 1. Check the PC board. (Refer to the item of "Check for the P.C.B." in "Operation Checks and Main Component Replacement Procedures").
- 2. Set the battery and connect the remote controller.
- 3. Turn off the power. Then, with the main unit's HOLD switch at OFF, press the VOL+, VOL-, ▶▶|, and |◄◀ buttons on the remote controller within two seconds without pressing the OFF button.
 - a. Using your thumb, while pressing the VOL+ button, also

press the VOL- button.


- b. Then, while still pressing the VOL- button, release your thumb from the VOL+ and press the bid button.
- c. While still pressing the ▶▶ button, release your thumb from the VOL- button and press the ◄◀ button. Then, while still pressing the ◄◀ button, release your thumb from the ▶▶ button and then from the ▶■ button. (a-c are shown in Fig.7)



Using your thumb, while pressing the VOL+button, also press the VOL- button.



Then, while still pressing the VOL— button, release your thumb from the VOL+ and press the ▶▶ button.



While still pressing the ▶ button, release your thumb from the VOLbutton and press the ◄ button. Then, while still presssing the ◄ buttom, release your thumb from the ▶ button and then from the ▶ button.

Fig.7

- 4. When entering the main unit's key check mode, "KEYJP" will be displayed on the LCD of main unit and remote controller.
 - If it is not displayed, perform the procedures written above again.
- Confirm the display of LCD by pressing any keys on the main unit. There is no order to press the keys.

Main unit's keys	LCD display positions and letters	
HOLD OFF	1st. letter is A	
ENTER	2nd. letter is B	
SPACE	3rd.letter is C	
POWER OFF	4th. letter is D	
VOL+	5th. letter is E	
VOL-	6th. letter is F	
DELETE	7th. letter is G	
EDIT	8th. letter is H	
DISPLAY	9th. letter is I	
CHARA	10th. letter is J	
PAUSE	11th. letter is K	
JOG rotation	12th. letter is L	

- 6. Remote controller's LCD lights "KEY OK" and main unit's LCD lights all when you can detect all keys.
- 7. Perform below voltage check about the keys come under if you cannot detect the key.

Main unit's keys	Measurement points	ON	OFF
HOLD	TP428	0V	2.6V
ENTER	TP420	2.0V	2.6V
SPACE	TP420	1.3V	2.6V
POWER OFF	TP420	0.6V	2.6V
VOL+	TP420	0V	2.6V
VOL-	TP419	2.0V	2.6V
DELETE	TP419	1.3V	2.6V
EDIT	TP419	0.6V	2.6V
DISPLAY	TP419	0V	2.6V
CHARA	IC501 48pin	0V	2.5V
PAUSE	IC501 49pin	0V	2.5V
JOG rotation	IC501 59,60pin	0V	2.6V

Confirm the waveform for JOG rotation.


8. Remove the battery when you exit from this mode.

Note:

Refer to "Printed Circuit Board and Wiring Connection Diagram" for the test points.

7.2. Self-diagnosis Function


This model is equipped with a self-diagnosis function and shows, when necessary, the following indication in the LCD section of the set.




"F17"---This indication appears when the Down switch fails to turn ON since the magnetic head fails to move up/down normally (Due to trouble of the magnetic head or trouble of the magnetic head up/down motor) or the magnetic head P.C.B. is out of position or a foreign matter has mixed in or for some other reason.


In such a case, check the peripheral parts of the magnetic head, repair or replace defective parts with normal ones.

8 Troubleshooting Guide





SJ-MR100







Confirmation of the detection of the disc cover closeing.















**) When you confirm RF waveform, perform "EFM jitter meajurement" in "Adjustment mode" (refer to " 7.Meajurements and Adjustments"). And you'll be able to observe the continuous waveforms.









Start Start VES Is IC501-57 pin "H" with inserting the mic? NO Is IC501-61 pin "H" with inserting the mic? NO Start VES Is IC501-61 pin "H" with inserting the mic? NO Confirm the power supply and oscillation of IC501. Confirm the power supply of IC701.





Confirmation of remote cont. (key)

o Confirm the waveform at TP449 and the voltage when the keys are pressed.



MAIN	SUB	HOLD	VOLTAGE	VOLTAGE
PLAY	_		0.1	
				0.2948
VOL+			0.442	
				0.6405
VOL-			0.841	
				0.9048
	EQ MODE		1.11	
			1	1.1666
	PLAY MODE		1.31	
				1.4182
F-SKIP			1.5	

MAIN	SUB	HOLD	VOLTAGE	BOUNDARY VOLTAGE
				1,5783
[DISPLAY		1.69	
				1.8096
R-SKIP			1.90	_
				2.0434
(KEY-OFF)			2.19	
	L			2.3052
		HOLD	2.41	
	1			2.5085
(WITHOUT REMOTE CONT.)			2.6	

9 Checking Procedures of Main Components Parts on the Main P.C.B. (B side)

As it cannot meajure the mechanism side of MAIN P.C.B. directly, refer to the table shown below for the criterion in the time of repairing or checking.

Circuit No.	Part No.	Function	Symptom	Check point	Result and meajure
IC301	NJU7015RTE1	Ope amp for cont- rol of recharging circuit	Impossible to recharge.	Perform "Confirmation of the recharging circuit" in "Troubleshooting Gulde".	If it comes under in "Trouble- shooting Guide", check the foil around IC301 or Q304. If there are no abnormal things, change the parts that is coming under.
IC302	XC6368A261MR	DC-DC converter	No power.	1.Confirm the voltage of TP411 (1.3V). 2.Confirm the gate waveform of Q306 (oscillating or not, oscillation frequency is approx. 100kHz)	Check the foil around IC302 when the voltage of TP441 is low (about 1.2V) and there is no gate wave- form oscillation. If there are no abnormal things, change IC302.
IC303	XC6367A151MR	DC-DC converter	Impossible to play and record.	1.Confirm the voltage of TP442 (1.5V). 2.Confirm the voltage of TP441 (2.6V).	Check the foil around IC303 when the voltage of TP441 is normal nut TP442 is low (about 1.2V). If there are no abnormal things, change IC302.
IC304	XC6372C501PR	DC-DC converter	Impossible to record.	1.Confirm the voltage of TP443 (5V) 2.Confirm that IC501-74pin is "L".	Check the foil around IC304 when the voltage of TP443 is low (about 1.2V) and IC501-7pin is "L". If there are no abnormal things, change IC304.
IC601	AK4518VF-E2	AD/DA converter	No sounds. Impossible to record by analog input.	1.Digital (optical) input confirmation: Send the signals to IC201 (power amp) -21,22pins, confirm that if the sounds are heard or not. 2.Perform "Confirmation of AD/DA section" in "Trobleshooting Guide". *The voltage confirmation of IC601: Confirm the voltage of R605 (5.6ohm) that in the middle of IC601-1pin and Q305 drain.	Check the foil around IC601 if the confirmation items are OK. If there are no abnormal things, change IC601.
IC701	AN7635SH-E1	LINE/MIC AMP.	Impossible to record by analog input.	Confirm that it can record by digital (optical), if it is OK, perform "Confirmation of MIC/LINE AMP section" in "Troubleshooting Guide". *The voltage confirmation of IC701: Confirm that the leading between IC701-13pin and Q704 drain.	Check the foll around IC701 if the confirmation items are OK. If there are no abnormal things, change IC701.

10 Schematic Diagram Notes

10.1. Schemtic Diagram Notes

This schematic diagram may be modified at any time with the development of new technology.

Notes:

- · S501 : COVER OPEN det. switch.
- · S502: Hold (HOLD) switch (in "OFF" position).
- S802 : Play / record / pause / power on / character type (▶/ 🚻 , CHARA) switch.
- S803 : Recording pause / power on (REC PAUSE→) switch.
- S804 : Display, capital / lower case (DISPLAY, CAPS LOCK) switch.
- S805 : Changing edit mode, changing track mark mode, completing edit (EDIT, MARK MODE) switch,
- S806 : Play and record mode / character delete (MODE, DELETE) switch.
- S807, 808 : Volume / cursor (← , + →, VOL / CURSOR) switches.
- S809 : Stop / power off / edit cancel (, POWER OFF) switch.
- S810 : Tone / recording sensitivity / space (EQ / REC SENS, SPACE) switch.
- · S901 : Magnetic head up (M.HEAD UP) switch.
- · S1101: PROTECT det, switch.
- VR1 : Laser power adj. V.R.,
- Indicated voltage values are the standard values for the unit measured by the DC electronic circuit tester (highimpedance) with the chassis taken as standard. Therefore, there may exist some errors in the voltage values, depending on the internal impedance of the DC circuit tester.

No mark: MD STOP

(): MD play [1kHz, L+R, 0dB]

Important safety notice:

Components identified by Δ mark have special characteristics important for safety.

Furthermore, special parts which have purpose of fireretardant (resistors), high-quality sound (capacitors), low-noise (resistors), etc. are used. When replacing any of components, be sure to use only manufacture's specified parts shown in the parts list.

Caution!

IC and LSI are sensitive to static electricity.

Secondary trouble can be prevented by taking care during repair.

Cover the parts boxes made of plastics with aluminum foil.

Ground the soldering iron.

Put a conductive mat on the work table.

Do not touch the legs of IC or LSI with the fingers directly.

Voltage and signal line

: Positive voltage line
: Playback signal line


: Recording signal "digital" line
: Recording signal "analog" line


: Mic signal line


10.2. Type Illustration of IC's, Transistors and Diodes


A	C74ACT04FSE 14PIN K4518VF-E2 24PIN N7635SH-E1 24PIN JU7015RTE1 8PIN	AK93C45BH-L	MNA7400CWA1T	MN BD	166616RB1 100PIN 1101CF32GCA 80PIN 6604KVT 80PIN 8772FHKEBV 48PIN
TA2131FL	XC61FC2012MR	XC6372C501PR	XC6368A261MR XC6367A151MR	2SK1764KYTR XP161A1355PR	XP151A12A2MR XP152A12C0MR
18 12 7 19 24 1	152	3 2 1	1 2 3	a D s	G S D
B E	2SB1462STX 2SB1295-6-TB DTC144TETL 2SD2216STX DTC144EETL	UMG6NTR UMG2NTR	XP4601TX	MA741WATX Anode Cathode Cathode	RB491DT146 ZHCS1006TA
F1J2ETP	MA133TX	MA2S111TX			
Cathode Ca	Cathode Anode Cathode	Cathode Ca Anode A			


11 Schematic Diagram


























12 Printed Circuit Board Diagram







G H J J K L





		Α	_	<u> </u>	В	إ		С			D			E			F
		■ El EO	TRICAL	 PARTS LO)CATION				7						T		
4		Ref. No.	Ło. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.	Ref. No.	Lo. No.
1		AMAIN IC301	P.C.B. "SI 3B	IDE: B"	4E	TP108	3C	TP136	3D	R318	2B	B711	6D	C303	ars	T 0007	- FD
		IC302 IC303	3D 3E	L203 L301	6E 2C	TP109 TP110	3C 3C	TP137 TP138	4B 6D	R320 R321	4D 3D	R712 R714	6C 6C	C304 C305	2D 3D 4B	C607 C608 C609	5D 4D 4D
_	 -	IC304 IC601 IC701	4B 4D 5D	L302 L303 L304	2D 5B 4B	TP111 TP112 TP113	3C 3B 3C	TP139 TP140 TP141	6E 6E	R322 R323	3D 2D	C2 C3	3C 3C	C306 C307	3D 2D	C610 C611	4D 4D
2		Q1 Q3 Q203 Q305 Q307 Q308 Q309 Q310 Q701 Q702	38 38 7E 3C 2D 3D 3D 3D 6C 6C	L305 L402 L403 L404 L405 L406 L407 L501 L701 L705	2B 58 58 58 58 5B 5C 5E 6D 78	TP114 TP115 TP116 TP117 TP118 TP119 TP120 TP121 TP122 TP123	3C 3C 3C 4B 3B 6B 6B 6B 6B	TP142 TP143 R5 R10 R11 R12 R14 R18 R19 R20	7F 7E 7D 3B 3C 3B 3B 3B 3B 3B	R325 R326 R402 R405 R406 R407 R506 R516 R601 R602 R604	3D 3E 5C 6C 6C 5E 5D 4D 5D	C8 C11 C12 C13 C14 C17 C18 C27 C28 C29 C30	3C 3C 3C 3C 4B 2B 3B 2C 2C 2B	C308 C310 C311 C401 C402 C407 C408 C411 C419 C420 C421	2B 3B 5B 6B 5B 5C 5C 6B 6B 6B	C612 C613 C614 C615 C702 C703 C704 C705 C706 C707	5D 4D 4D 5D 6D 5D 5D 6D 6D 6D
3		Q703 Q704 Q705 D301 D303 D304 D305 D311 TH1 L1 L101	6E 6D 6C 3B 3C 3D 4B 3B 3B 3B 3B 3B 3B	L706 L707 Z301 JK301 JK702 TP101 TP102 TP103 TP104 TP105 TP106 TP106 TP107	7B 5E 5B 5B 5B 5B 5B 6B 4B 3C 3B	TP124 TP125 TP126 TP127 TP128 TP129 TP130 TP131 TP131 TP132 TP133 TP134 TP135	6B 6B 6B 6C 5D 4E 2B 4B 5B 6B	R35 R207 R208 R209 R303 R306 R309 R311 R312 R313 R314	2C 7E 7F 3B 3B 2B 3B 3B 3B 3B	R605 R606 R607 R702 R703 R704 H705 R706 R707 R708 R709 R710	5C 5D 6C	C31 C32 C33 C34 C35 C36 C39 C41 C214 C215 C218 C301	2C 2C 2C 2C 3C 3C 5E 6E 7F 2C	C423 C424 C429 C430 C431 C513 C601 C602 C603 C604 C605 C606	5C 6C 6B 6B 5D 5D 5D 5D 5D 5D	C710 C711 C715 C716 C717 C718 CX315 CX316 CX405	5C 6D 5D 5D 6D 6D 3D 3D 7B
			P.C.B. "SI	DE: A			·			1		0001		0000		<u> </u>	
4		IC1 IC101 IC102 IC201 IC402 IC501 IC502 IC503	3K 3H 8H 5J 5H 4G 4I	S501 S502 CN1 CN401 CN402 CN403 CN404 CN701	5G 5G 3J 7G 6L 6L 6I 6K	TP422 TP423 TP424 TP425 TP426 TP427 TP428 TP429	4J 4J 4I 4I 5H 5H 6G	TP454 TP455 TP456 TP457 TP458 R1 R2 R13	7J 5H 7K 7K 7K 3K 3K 4K	R204 R205 R206 R211 R301 R302 R304 R307	6H 6H 6H 3K 3K 3K 3L	R715 RX103 RX503 C1 C4 C5 C6 C7	5J 2H 3K 3K 4L 3J 3J	C110 C111 C112 C113 C114 C115 C116 C117	4H 4H 3I 3I 2J 2J 2J 2J	C404 C409 C410 C412 C413 C414 C415 C416	6H 5K 5K 5L 5K 5K 5K 6K
_	_	Q2 Q201 Q202 Q301 Q302	4L 6G 7H 3L 3L	JK201 (JK301) JK701 TP401 TP402	7I 2L 7J 5K 5K	TP430 TP431 TP432 TP433 TP434	7K 6K 2L 2L 3L	R15 R16 R21 R22 R23	4L 4L 3K 3K 3K	R308 R310 R315 R317 R319	3L 3L 2K 2K 3L	C10 C15 C16 C19 C20	3K 4K 3K 3K 3K	C118 C120 C201 C202 C203	2J 2H 6G 6G 6G	C417 C418 C425 C426 C427	6K 6K 6J 6K 6K
5		Q303 Q304 Q306 Q312 Q405 Q406	3L 2J 2J 5K 5K	TP403 TP404 TP405 TP406 TP407 TP408	5L 5L 4K 3K 2K 3J	TP435 TP436 TP437 TP438 TP439 TP440	4L 4L 4K 4K 4K	R24 R25 R28 R29 R30 R31	2K 2K 2K 2K 2K 2K	R324 R401 R408 R501 R502 R504	21 4L 6K 51 5H	C21 C22 C23 C24 C37 C38	3K 3K 2K 2K 2K 2J	C204 C205 C206 C207 C208 C209	6G 6G 55 55 55 65	C501 C502 C503 C504 C505 C506	51 51 51 5J 41
_	_	Q407 Q408 Q409 D1 D501 D502	5L 4K 4K 3L 4G 4G	TP409 TP410 TP411 TP412 TP413 TP414	2J 2I 2I 2I 3J	TP441 TP442 TP443 TP444 TP445 TP446	2J 21 4L 6H 6H	R32 R33 R34 R102 R107 R108	2J 2K 2I 3I 3I	R505 R507 R508 R509 R510 R511	4J 4H 4H 4H 5H 51	C40 C42 C43 C44 C101 C102	3J 3J 3J 2K 2I 2I	C210 C211 C212 C213 C216 C217	6H 6H 6H 6H 6H	C507 C508 C509 C510 C511 C512	41 5H 5G 4H 5H 5H
6		VR1 L201 L202 L702 L703 X101 X501	3K 6H 6H 7J 7J 3J 4I	TP415 TP416 TP417 TP418 TP419 TP420 TP421	3I 4I 4I 6K 5I 5I 5J	TP447 TP448 TP449 TP450 TP451 TP452 TP453	6G 7H 6I 6I 5J 6J	R110 R111 R113 R114 R201 R202 R203	3I 2I 2I 3J 6G 6H 6H	R512 R513 R514 R515 R603 R701 R713	5I 4H 4H 5H 5H 6J 6J	C103 C104 C105 C106 C107 C108 C109	2i 3J 4H 2H 4I 4I 4I	C219 C220 C302 C309 C312 C313 C403	6H 6H 2J 3L 2L 2J 6H	C701 C708 C712 C713 C714 C719	6J 6I 5J 6I 6I 7K
_	_		CH P.C.B.	SIDE: A"								0100					
7	[B SWITCH P.C.B. "SIDE : A" B SWITCH P.C.B. "SIDE : B"															
+	_					S1101	_				5		(A)				
8					20 (REP28	58AB 28A-M))										


13 Block Diagram















14 Wiring Connection Diagram



15 Terminal Function of IC's

15.1. IC1 (AN8772FHKEBV): RF AMP

Pin No.	Mark	I/O Division	Function
1	CENVD	I	D signal det. capacitor input terminal
2	LDO	0	Laser amp output terminal
3	APCPD	ı	Photo diode light quantity det. input terminal
4	LD IN		Laser amp reverse input terminal

	Pin No.	Mark	I/O Division	Function
ľ	5	APC REF		APC amp reference voltage input terminal
	6	TEMP IN		Temperature sensor amp input terminal

Pin No. Mark No. Division Function 7 TEMP O Temperature sensor amp output terminal 8 ADIP O ADIP signal output terminal 9 TOFS I Tracking error offset adjustment terminal 10 TBAL I Tracking error signal output terminal 11 TE O Tracking perror signal output terminal 12 CRS IN I Tracking signal output terminal 13 TGAIN I Tracking signal output terminal 14 LNP O Lens position signal output terminal 15 AB GAIN I APP compensation signal gain adjustment input terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I ST envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to power supply through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/foff track signal output terminal 28 NRFLD I Serial command data signal input terminal 30 RFCK I Serial command data signal input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I Reference voltage input terminal 35 ARFO O RF amp. output terminal 36 SYREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equilzer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A-D signal input terminal 45 CENVC I Beam E signal detection capac	10	0			
Serial command Seri			Mark		Function
9 TOFS I Tracking error offset adjustment terminal 10 TBAL I Tracking ballance adjustment input terminal 11 TE O Tracking perror signal output terminal 12 CRS IN I Track cross input terminal 13 TGAIN I Tracking gain adjustment input terminal 14 LNP O Lens position signal output terminal 15 AB GAIN I APP compensation signal gain adjustment terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3W) 27 NRFDET/ O NRFDET/off track signal output terminal 28 NRFLD I Serial command data signal input terminal 30 RFCK I Serial command data signal input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ IND I Reference voltage input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF3 signal input terminal 44 A I APP compensation LPF capacitor input terminal 45 CLPF1 I Main beam A-D signal input terminal		7	TEMP	0	
terminal Tacking ballance adjustment input terminal	ļ			0	ADIP signal output terminal
terminal TE				1	
12 CRS IN I Track cross input terminal 13 TGAIN I Tracking gain adjustment input terminal 14 LNP O Lens position signal output terminal 15 AB GAIN I APP compensation signal gain adjustment terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/STMON signal output terminal 19 AS/MON3T O AS/STMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O Off track detection signal output terminal 24 GND GFT IN Off track detection signal input terminal 25 OFT IN Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/Off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC RFAGC Capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SYREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 RF1 Signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 RF2 signal input terminal 43 CLPF2 RF2 signal input terminal 44 A F2 I PF2 signal input terminal 45 CLPF2 RF2 signal input terminal 46 CLPF2 RF3 GRAFC I Main beam A~D signal input terminal				l 	terminal
13 TGAIN I Tracking gain adjustment input terminal 14 LNP O Lens position signal output terminal 15 AB GAIN I APP compensation signal gain adjustment terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A P Main beam A~D signal input terminal	-				
terminal LNP O Lens position signal output terminal AB GAIN I APP compensation signal gain adjustment terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O BDO/Track cross signal output terminal 23 OFT O O Off track detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command data signal input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SYREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal	ļ				
15 AB GAIN I APP compensation signal gain adjustment terminal 16 FE O Focus error signal output terminal 17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 30 RFCK I Serial command data signal input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ Input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor connection terminal (Connected to power supply through resistor) 44 A PA I Main beam A~D signal input terminal					terminal
adjustment terminal 17	ŀ				
17 AS GAIN I AS gain adjustment input terminal 18 FBAL I Focus ballance adjustment input terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor) 44 A CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 48 CENVC I Beam E signal detection capacitor		15	AB GAIN	-	APP compensation signal gain adjustment terminal
18	L	16	FE	0	Focus error signal output terminal
terminal 19 AS/MON3T O AS/3TMON signal output terminal 20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor) 44 A O D 48 CENVC I Beam E signal detection capacitor		17	AS GAIN		
20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal (Connected to GND through capacitor) 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR DATA I Serial command latch signal input terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command clock input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SYREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 AP O Hamber Signal detection capacitor		18	FBAL	Ï	
20 CEA I 3T envelope det. capacitor connection terminal (Connected to power supply through capacitor) 21 BDO/TRCR O BDO/Track cross signal output terminal (Connected to GND through capacitor) 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR DATA I Serial command latch signal input terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command clock input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SYREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 AP O Hamber Signal detection capacitor		19	AS/MON3T	0	AS/3TMON signal output terminal
21 BDO/TRCR S O BDO/Track cross signal output terminal 22 CBD O O BDO detection capacitor connection terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR Details of the terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor) 44 A O Main beam A~D signal input terminal		20	CEA	1	3T envelope det. capacitor connection terminal (Connected to
terminal (Connected to GND through capacitor) 23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ OFTR DETA O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 40 F1 I F1 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor) 44 A CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal		21	/	0	BDO/Track cross signal output
23 OFT O O Off track detection signal output terminal 24 GND — GND terminal 25 OFT IN I Off track detection signal input terminal 26 VCC I Power supply terminal (+3V) 27 NRFDET/ O NRFDET/off track signal output terminal 28 NRFLD I Serial command latch signal input terminal 29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal (Connected to power supply through resistor) 44 A 47 ~D 48 CENVC I Beam E signal detection capacitor		22	CBD O	0	terminal (Connected to GND through
25 OFT IN 1 Off track detection signal input terminal 26 VCC 27 NRFDET/OFTR 28 NRFLD 30 RF DATA 30 RFCK 31 Serial command latch signal input terminal 31 NRFSTBY 32 OUT RF 33 CRF AGC 34 EQ IN 35 ARFO 36 SVREF 37 RFD 38 RF1 39 RF2 30 RFC 31 Reference voltage input terminal 39 RF2 30 RFC 31 Reference voltage input terminal 35 ARFO 36 SVREF 37 RF2 Signal input terminal 38 RF1 39 RF2 30 RFC 30 RFC 31 Reference voltage input terminal 35 ARFO 36 SVREF 37 RF2 Signal input terminal 38 RF1 39 RF2 30 RF2 40 RF3 40 RF4	_	23	OFTO	0	Off track detection signal output
terminal 26	Γ	24	GND	_	GND terminal
Power supply terminal (+3V)		25	OFT IN	1	
27	Γ	26	VCC	<u> </u>	Power supply terminal (+3V)
Serial command latch signal input terminal	ľ	27		0	NRFDET/off track signal output
29 RF DATA I Serial command data signal input terminal 30 RFCK I Serial command clock input terminal 31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A CLPF2 I Main beam A~D signal input terminal	ľ	28	NRFLD	ı	
31 NRFSTBY I Standby control signal input terminal 32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A CLPF2 I Main beam A~D signal input terminal		29	RF DATA	ı	
Standby control signal input terminal	Γ	30	RFCK	1	Serial command clock input terminal
32 OUT RF O EFM signal output terminal 33 CRF AGC — RFAGC capacitor connection terminal (Connected to GND through capacitor) 34 EQ IN EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A I Main beam A~D signal input terminal 48 CENVC Beam E signal detection capacitor	Γ	31	NRFSTBY		
RFAGC capacitor connection terminal (Connected to GND through capacitor) 34	Г	32	OUT RF	0	
34 EQ IN I EQ input terminal 35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor		33	CRF AGC	_	RFAGC capacitor connection terminal (Connected to GND through
35 ARFO O RF amp. output terminal 36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	34	EQ IN		
36 SVREF I Reference voltage input terminal 37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A A A A A A A A A A B A A A A A A	Ľ	35	ARFO		
37 VREF I Reference voltage input terminal 38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A A A A A A A	Ĺ	36	SVREF		
38 RF1 I RF1 signal input terminal 39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	37			
39 RF2 I RF2 signal input terminal 40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	38	RF1		
40 F1 I F1 signal input terminal 41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	39	RF2		
41 F2 I F2 signal input terminal 42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	40			
42 CLPF1 I APP compensation LPF capacitor input terminal 43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor	Ĺ	41	F2	<u> </u>	F2 signal input terminal
43 CLPF2 — RF equalizer adjustment resistor connection terminal (Connected to power supply through resistor) 44 A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor		42	CLPF1	Ī,	APP compensation LPF capacitor
44 A I Main beam A~D signal input terminal 48 CENVC I Beam E signal detection capacitor		43	CLPF2		RF equalizer adjustment resistor connection terminal (Connected to
The second of th				ı	Main beam A~D signal input terminal
		48	CENVC		

15.2. IC101 (M6616RB1): ATRAC ENCORDER/DECORDER, SERVO SIGNAL PROCESSOR

	, - -		
Pin No.	Mark	I/O Division	Function
1	ADIP	<u> </u>	ADIP FM signal input terminal
2	LNP	 	Lens position signal input terminal
3	FE	l i	Focus error signal input terminal
4	TE	 	Tracking error signal input terminal
5	AS	 	AS signal input terminal
6	DRMONI	 	
7		 	Drive voltage monitor input terminal
8	BAT	<u> </u>	Battery power supply terminal
8	AMONI	_	Servo analog monitor signal output (Not used, open)
9	VREFI	1	Reference voltage input terminal
10	TOFS	0	Tracking off-set adjustment output
<u> </u>			terminal
11	FBAL	0	Focus balance adjustment output terminal
12	TBAL	0	Tracking balance adjustment output
13	TOAIN		terminal
13	TGAIN	0	TE error gain adjustment output terminal
14	ASGAIN	0	Main beam amp gain adjustment
L			output terminal
15	ABGAIN	0	APP adjustment output terminal
16	AV _{DD} 1	1	Power supply terminal
17	AV _{ss} 1	_	GND terminal
18	TRDP	0	Tracking drive (+) PWM signal output terminal
19	TRDM	0	Tracking drive (-) PWM signal output terminal
20	FODP	0	Focus drive (+) PWM signal ouutput
21	FODM	0	terminal Focus drive (-) PWM signal/focus,
		_	tracking ON/OFF signal output
			terminal
22	SPDP	Ō	Spindle drive (+) PWM signal output terminal
23	DIR	0	Spindle drive (-) PWM signal output
	D) (o	 ,	terminal
24	DV _{DD} 0	- !	Power supply terminal
25	FG		FG input terminal
26	STPO0	0	Stepper drive signal 0 output terminal
27	STPO1	0	Stepper drive signal 1 output terminal
28	IVDD0	ī	Power supply terminal for I/O pad
29	DVss0	<u> </u>	GND terminal
30	RAD12	0	DRAM address output terminal (Not
31	RAD11	~	used, open)
32	RAD10	ō	DRAM address output terminal
~42	~RAD0	~	Pro un address output terminal
43	RDT3	1/0	DRAM data input/output terminal
_~46	~RDT0	., -	and any any output territorial
47	NRAS	ō	DRAM row address strobe output terminal
48	NCAS	0	DRAM culum address strobe output terminal
49	NWE		DRAM write enable output terminal
50	NRST	-	Reset signal input terminal
51	SELAD	<u> </u>	MSP/MDA,I/F address select input
			terminal ("H" Address)
52	SSCK		MSP/MDA,I/F clock input terminal
53	SSDW		MSP/MDA,I/F write data input terminal
54	SSDR	0	MSP/MDA,I/F read data output terminal
55	MDISY		Leader synchronous signal output
			oymornonous signar surput

Pin No.	Mark	I/O Division	Function
56	SCTSY	0	ADIP synchronous noise output terminal
57	SGSYNC	0	Frame synchronous signal output terminal
58	DVDD1	- 1	Power supply terminal
59	IVDD1		Power supply terminal for I/O pad
60	DVss1	-	GND terminal
61	FS384	0	384 Fs output terminal
62	SCL	0	Bit clock output terminal
63	sws	0	Word clock output terminal
64	SDAP	0	Audio data output terminal
65	SDAR		Audio data input terminal
66	STPI1		Stepper status 1 input terminal
67	STPI2		Stepper status 2 input terminal
68	STPI0	1	Stepper status 0 input terminal
69	STPO2	0	Stepper drive signal 2 output terminal
70	RX1	l 	Digital audio interface signal 1 input terminal
71	NRECP	l 	Amp. Play/Rec switching signal input terminal
72	NREFM	0	EFM modulation inverted output
73	REFM	0	EFM modulation inverted output terminal
74	MONI3	0	Monitor signal output (Not used)
75	MONI2	0	Monitor signal output (Not used)
76	MONI1	0_	Monitor signal output (Not used)
77	MONI0	0	Monitor signal output (Not used)
78	TS3		Not used, connected to GND
79	TS2		Not used, connected to GND
80	TS1		Not used, connected to GND
81	TS0		Not used, connected to GND
82	EXSYSCK	ļ , ļ	External system clock input terminal (Not used, connected to GND)
83	DVDD	<u> </u>	Power supply terminal
84	XI		Crystal oscillator input terminal (F=16.9344MHz) Crystal oscillator output terminal
85	ХО	0	(F=16.9344MHz)
86	VDss2	<u> </u>	GND terminal RF serial data output terminal
87	RFDAT	- 0	RF serial clock output terminal
88	RFCK	<u> </u>	RF serial load output terminal
89	NRFLD	<u> </u>	Track cross input terminal
90	TRCRS	 	Off-track signal input terminal
91	OFTR APCD		Laser power PWM output terminal
92	EXEFMCK		External FM clock input terminal (No used, connected to GND through registor)
94	PEFM1	0	EFM loop filter output terminal
95	EFMIREF		EFM PLL reference current inputerminal
96	EFMPLLF	0	EFM PLL filter output terminal
97	PEFMS	1	EFM signal input terminal
98	AV _{DD} 0	Ī.	Power supply terminal
99	AVss0		GND terminal
100	TEESEL		Tracking error signal output terminal

15.3. IC301 (BD6604KVT): FOCUS/TRACKING COIL, TRAVERSE MOTOR DRIVE, SPINDLE MOTOR DRIVE, ROTARY DETECTOR

Pin	Mark	I/O Division	Function
No.	S GND	DIVISION	GND terminal
2	AS GND		GND terrimina
3	PW IN 1		Not used, connected to GND
4	PW IN 2		Half birdge input terminal
5	FG	0	Speed pulse output terminal
6	BRK-		Brake comparater- input terminal
7	BRK+	Ī	Brake comparater+ input terminal
			(Connected to GND and power supply through resistor)
8	CSL2		Slope capacitor connect terminal
9	CSL1		(Connected to GND through capacitor)
10	CST	Ī	Connected to GND through capacitor
11	SP PG2	-	GND terminal
12	SP W OUT	0	Spindle motor coil (W) output
			terminal
13	SP VM2		Power supply terminal for part of spindle power
14	NC		Not used, open
15	SP V OUT	0	Spindle motor coil (V) output terminal
16	NC		Not used, open
17	SP PG1		GND terminal
18	NC	<u> </u>	Not used, open
19	SP U OUT	0	Spindle motor coil (U) output terminal
20	SP VM1	l	Power supply terminal for part of spindle power
21	SP COM	I I	Spindle motor coil center input terminal
22	SP W IN	ı	Roter position detect comparater (W) input terminal
23	SP V IN	ī	Roter position detect comparater (V) input terminal
24	SP U IN	1	Roter position detect comparater (U) input terminal
25	H2 PG2	 	GND terminal
26	NC	<u> </u>	Not used, open
27	H2 R OUT	I	H bridge 2 reverse output terminal
28	NC		Not used, open
29	H2 VM	1	Power supply terminal
30	NC		Not used, open
31	H2 F OUT	0	H bridge 2 forward output terminal
32	NC NC		Not used, open
33	H2 PG1	 	GND terminal
34	H1 PG2	 	<u> </u>
35_	NC	ļ <u>-</u>	Not used, open
36	H1 R OUT	<u> </u>	H bridge 1 reverse output terminal
37	NC _	-	Not used, open
38	H1 VM	 	Power supply terminal H bridge 1 forward output terminal
39	H1 F OUT	 ° _	GND terminal
40	H1 PG1	+ =	Power supply terminal
41_	VCC1	┤	Fower supply terminal
42	VCC2	 -	H bridge 1 forward input terminal
43	IN 1F	1 1	H bridge 1 reverse input terminal
44 45	IN 1R IN 2F	⊣ '	Tribildge i reverse input terrisiai
46	IN 2F	 	H bridge 2 reverse input terminal
46	EXT CLK	 	Not used, open
41	EVICEN		rtot dood, oport

Tracking error signal output terminal

10	0			
	Pin	Mark	1/0	Function
ĺ	No.	<u> </u>	Division	, 3,7,51,51
	48	C1P		Charge pump capaciter 1(+) connect terminal
	49	C1M		Charge pump capaciter 1(-) connect terminal
	50	C2P		Charge pump capaciter 2(+) connect terminal
	51	C2M	-	Charge pump capaciter 2(-) connect terminal
	52	VG	0	Charge pump output terminal (Connected to GND through capacitor)
Ţ	53	STALL		Stand by input terminal
L	<u>54</u>	STHB	I	H1, H2 bridge mute terminal
L	55	S1	1	Stepping decoder 1 input terminal
L	56	S2	<u> </u>	Stepping decoder 2 input terminal
L	57	S3	l	Stepping decoder 3 input terminal
	58	BEMF U	0	Step detect comparater (U) output terminal
	59	BEMF V	0	Step detect comparater (V) output terminal
	60	BEMF W	0	Step detect comparater (W) output terminal
	61	SL COM		Step motor coil center input terminal
Ĺ	62	SL VM1	ı	Power supply terminal
L	63	NC		Not used, open
L	64	SL U OUT	1	Stepping motor (U) input terminal
L	65	SL PG1		GND terminal
L	66	NC		Not used, open
L	67	SL V OUT		Stepping motor (V) input terminal
L	68	NC NC	—	Not used, open
L	69	SL VM2		Power supply terminal
L	70	SL W OUT	0	Stepping motor (W) output terminal
L	71	SL PG2		GND terminal
L	72	NC		Not used, open
L	73	PW1VM		Power supply terminal
L	74	NC		Not used, open
L	75	PW1 OUT		Half bridge 1 output terminal
L	76	NC		Not used, open
L	77	PW PG	T	GND terminal
L	78	NC		Not used, open
L	79	PW2 OUT		Half bridge 2 output terminal
L	80	PW2 VM		Power supply terminal

15.4. IC501 (MN101CF32GCA): SYSTEM CONTROL

Pin	Mark	1/0	Function
No.		Division	
1	VREF-	1	Reference voltage input terminal
2	REM KEY	l	Remote cont. key input terminal
3	KEY IN1		Unit key1 input terminal
4	KEY IN2	!	Unit key2 input terminal
5	BATT1	1	Battery voltage det. input terminal
6	AN4		Connected to reference voltage
7	TEMP		Temperature sensor input terminal
8	DOCTOR	_	Doctor mode input terminal
_ 9	AN7		Connected to power supply
10	VREF+	1	Reference voltage input terminal
_ 11	VDD	ı	Power supply terminal
12	OSC2	I	System clock input terminal (f=10.02MHz)
13	OSC1	Ö	System clock output terminal (f=10.02MHz)
14	VSS		GND terminal
15	ΧI	1	Sub clock input terminal (Not used, connected to GND)
16	хо	0	Sub clock output terminal (Not used, open)


Pin No.	Mark	I/O Division	Function
17	MMOD	DIVISION	Memory mode select input terminal
			(Connected to GND)
18	REM DATA	0	LCD driver data output terminal
19	RXD	1 "	Connected to GND through
20	NC NC	 	capacitor
21	SSDW	0	Not used
21	3300	"	MSP/MDA interface writing data output terminal
22	SSDR		MSP/MDA interface reading data
,	<u> </u>		input terminal
23	SSCLK	. 0	MSP/MDA interface data forward clock output terminal
24	BUZZER	0	Buzzer output trminal
25	RST	l i	Reset signal input terminal
26	SELAD	0	MSP/MDA interface address signal
	<u> </u>	ļ	output terminal
27	NC	<u> </u>	Not used, open
28	LCD STB	0	LCD driver strobe signal output
29	REC	0	terminal
23	SENSE	"	REC sensitivity select output terminal
30	MONO/ST	0	REC amp monaural/stereo select
			terminal
31	WAKEUP	1	Micro computer wake up signal input
32	MDISY		terminal
02	WDIST	,	Leader synchronize signal from IC101 input terminal
33	SCTSY	- I	ADIP/sub A synchronize signal from
			IC101 input terminal
34	CFSYNC	ı	MDA synchronize signal from IC101
35	OPENSW		input trminal (11.6ms pulse) Disc cover open/close switch det.
•	OI LIVOV		input terminal ("H":open, "L":close)
36	LCD DATA	0	LCD driver data output terminal
37			Connected to GND
38	LCD CK	1	LCD driver clock input terminal
39 ~41	NC		Not used, open
42	CHARGE1	-0	Dooleaning control of the
43	NRECP	-6	Recharging control output terminal Track jump det. output terminal
44	EEPCS	-	EEPROM chip select output terminal
45	EEPCK	0	EEPROM clock output terminal
46	EEPDATA0		EEPROM data output terminal
47	EEPDATAI	Ī	EEPROM data input terminal
48	PLAY KEY	ī	PLAY/PAUSE KEY input terminal
49	REC KEY		REC/PAUSE KEY input terminal
50	DC IN		DC IN wake up input terminal
<u> </u>	WAKEUP		
51_	REG		Area selection input terminal
52 53	MHEAD UP PROTECT		Magnetic head down input terminal
ບວ	PROTECT		Erase prevention switch input terminal
54	JITTER OK		Connected to power supply through
			resistor
55	HOLD SW	1	HOLD switch input terminal
56	DCINDET		("H":OFF, "L":ON) DC IN det. input terminal
57	MIC DET		Mic det. input terminal
58	INSEL		INPUT select det. input terminal
59	JOGA		JOG pulse A input terminal
60	JOGB		JOG pulse B input terminal
61	MIC/LINE		MIC/LINE select output terminal
62	LOAD0	0	Magnetic head movement control 0
62	I CAD4		output terminal
63	LOAD1	0 [Magnetic head movement control 1 putput terminal
64	HFON1		HF module ON 1 input terminal
65	MUTEA		Analog mute A output terminal
66	MUTEB		Analog mute B output terminal
67	NRFSTBY		RF amp standby output terminal

Pin	Mark	1/0	Function
No.		Division	
68	ADC OFF	0	ADC OFF output terminal
69	LOW BST	0	VMS select output terminal
70	DEO	0	DE enphasis output terminal
71	DAC OFF	0	DAC off output terminal
72	RECCNT2	0	REC control 2 output terminal
73	RFCNT	0	RF power supply control output terminal
74	RECCNT1	0	REC control 1 output terminal

Pin No.	Mark	I/O Division	Function
75	PWRCNT	0	Power supply control output terminal
76	EL ON	ı	EL display control input terminal
77	PC	0	4ch driver standby output terminal
78	STBY2	0	FD/TR coil power supply control output terminal
79	NC		Not used, open
80	MSP RST	0	MSP reset output terminal

16 Caution in Use of Rechargeable Battery Ass'y

- Take Rechargeable Battery Ass'y out of Battery Carrying Case and use it.
- Be sure to carry Rechargeable Battery Carrying Case. If not, it may either heat or ignite by shorting with a metal. (as shown in Fig.9)




17 Supply of Rechargeable Battery Ass'y as Replacement Parts


Please take note of the following points relating to Battery Carrying Case to be used for protection of Rechargeable Battery Ass'y from shorting. Replacement Parts:


- Rechargeable Battery Ass'y (RFKFBP140HSY) supplied will be provided with Battery Carrying Case (RFA0475-Q).
- No replacement parts will be supplied for Rechargeable Battry Ass'y without Battery Carrying Case.
- Replacement parts will be supplied for Battery Carrying Case (RFA0475-Q) without Rechargeable Battery Ass'y.
- To your customers, delivery Rechargeable Battery Ass'y together with Battery Carrying Case to prevent shorting accidents that may occur when Rechargeable Battery Ass'y is carried about Battery Carrying Case. (as shown in Fig.8)

· Remove two screws



18 Resolution Procedure and Parts Format of Remote Controller's Clip Unit





Note)

As removed screws are not supplied as replacement parts, be careful not to lose it.

19 Replacement Parts List

Notes:

*Important safety notice:

Components identified by \triangle mark have special characteristics important for safety.

Funrthermore, special parts which have purposes of fireretardant (resistors), high-quality sound (capacitors), lownoise (resistors), etc. are used.

When replacing any of components, be sure to use only manufacture's specified parts shown in the parts list.

*Warning: This product uses a laser diode. Refer to caution statements.

*ACHTUNG:Die lasereinheit nicht zerlegen.Die lasereinheit darf nur gegen einc vom hersteller spezifizierte einheit ausgetauscht werden.

*Capacity values are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)

*Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM), 1M=1,000K (OHM)

*The marking <RTL> indicates that the Retention Time is limited for this item. After the discontinuation of this assembly in production, the Item will continue to be available for a specific period of time. The retention period of availability is dependant on the type of assembly, and in accordance with the laws governing part and product retention. After the end of this period, the assembly will no longer be available.

*"<IA>" "<IB>" marks in Remarks indicate languages of instruction manuals.

[<IA>:English/Spanish/French/German/Netherlands/Swedish/Italian/Danish, <IB>:English/Chinese]

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
1	RXM0070-3	LINK UNIT	1	
1-1	RMB0622	SPRING	1	
2	RGK1158-S	INTERMEDIATE ORNAMENT	1	
3	RGU1769-S	BUTTON OPERATION	1	
4	RGV0250-R1	REC KNOB	1	
5	RHE5155YA	SCREW	9	· · · · · · · · · · · · · · · · · · ·
6	RHQ0083-S	SCREW	6	
7	RJB2104A	FPC	1	
8	RMN0536-1	LCD HOLDER	1	
9	RMZ0492	SHEET	1	
10	RMZ0505	LCD SPACER(C)	1	
11	RMZ0506	LCD SPACER(D)	1	
13	RYF0518-S	DISC COVER ASS'Y	1	
14	RYK0936A-S	CABINET ASS'Y	1	(EB,EG)
14	RYK0936B-S	CABINET ASS'Y	1	(GR)
15	RGK1157-S	INTERMEDIATE CABI.ASS'Y	1	(GII)
L5-1	RGV0248-S	HOLD KNOB	1	
L5-2	RGV0249-S	OPEN KNOB	1	
16	RHD14076-S	SCREW	6	
17	RKK0129-S1	BATTERY COVER	1	
L8 ∆	RAE1620Z	MD MECHANISM UNIT	1	
8-1	RDG0446	INTERMEDIATE GEAR	1	
18-2	RHD14067	SCREW	1	
.8-3	RHW11011	WASHER	1	
.8-4	RMC0379	SPRING	1	
8-5	RMA1219-3	HOLDER	1	
8-6	RMB0546	EJECT SPRING	1	
8-7	RML0550	LIFTER	1	-
8-8	RMM0215-2	CONNECTION ROD	1	
			- ,	

Ref. No	. Part No.	Part Name & Description	Po	s Remarks
18-9	RMM0216	EJECT ROD	1	
18-10	RDG0450	MOTOR GEAR	1	
18-11	HPX13NA1C	SPINDLE MOTOR	1	
18-12	RDG0451	RELAY GEAR	1	
18-13	RDG0452-1	DRIVE GEAR	_ 1	
18-14	RDG0453-1	DOWN GEAR	1	
18-15	BQL1A1CWF	TRAVERSE MOTOR	1	
18-17	RHD14072	SCREW	_ 3	
18-18	RHD14073	SCREW	1	
18-19	XQN14+C18FN	SCREW	1	
18-20	RHW09001	WASHER	1	
18-21	RMG0525-K	STOPPER RUBBER	1	
18-22	RMC0381	MOTOR SPRING	1_	
18-23	RMM0217	DRIVE ROD	_ 1	
18-24	RMX0147	STOPPER RUBBER	3	
18-25	RJB2075A	SWITCH FPC	1	
18-26	XQN14+C12FZ	SCREW	1	
18-27	RHD12001	SCREW	2	
18-28	REM0082	LIFT MOTOR UNIT	1	
18-29	RMB0635-1	SPRING	1	
18-30	RMX0159	SHEET	1	
18-31	RMZ0510	SHEET	1	
19	RHD14057-K	SCREW	1	
20	RHD14073	SCREW	1	
21	RHD14075	SCREW	4	
23	RJB2105A	FPC	1	
24	RJC99033-1	R.BATTERY	ı	
		TERMINAL (+)		
25	RJR0183	BATTERY SHAFT	1	
6	RMG0515-A	FLOATING RUBBER	4	
7	RMN0537	BATTERY HOLDER	1	
8	RHQ0083-S	SCREW	2	
9	RMA1244-1	CHASSIS	1	
30	RXQ0638-1	LOCK UNIT	1	
31	RXQ0639	R.BATTERY TERMINAL (-)	1	
3	RMQ0916	TAPE	1	
4	RMF0274	SHEET	1	
5	RMG0526-K	SHEET	1	
	 		+	
1	RFKFBP140HSY	RECHARGE BATTERY	1	
1-1	RFA0475-Q	RECHARGEABLE BATTERY CASE	1	
2	RFA1320-S	BATTERY CASE	1	
3	RFC0056-K	CARRYING CASE	1	
4	RFEA003B-S	AC ADAPTOR	1	(EB)
<u></u>	RFEA002E-S	AC ADAPTOR		
1	RFEA004H-S		1	(EG)
<u>.</u>		AC ADAPTOR	1	(GH)
	RFEV023P-SM	WIRED REMOTE CONTROL	1	
<u>5-1</u>	RYQ0287-H	CLIP	1	
<u> </u>	RFEV319P-SA	STEREO EARPHONES	1	
/	RJL2P007X08 RQT5119-B	LINE CABLE INSTRUCTION	1	(ED EG) 4775
	RQT5121-G	MANUAL		(EB EG) <ia></ia>
		INSTRUCTION MANUAL	1	(GH) < IB>
	RQA0117	WARRANTY CARD	1_	
.0	RQCB0169	SERVICENTER LIST	1	
	ECUE1H221KBQ	50V 220P	1	
,3	ECUVNA224KBV		1	-
	ECUE1C153KBQ	— — —		
			1 1	
. 6	RESTORATOR	TV AVU	1 1	
, 6	RCSTOGZ106RG ECUENA104KBO		+	
, 6	ECUENA104KBQ	10V 0.1U	1	
, 6		10V 0.1U 16V 0.015U	+	

Ref. No.	Part No.	Part Name &	Pcs	Remarks
	ECUENA104KBQ	Description 10V 0.1U	1	
C13	RCST0GZ106RG	4V 10U	1	
C14	ECUVNA224KBV	10V 0.22U	1	
C15	ECUVNJ105KBV	63V 1U	1 -	
<u>C16</u>	ECUE1H181KBQ	50V 180P	1	
C17	ECUE1C223KBQ	16V 0.022U 50V 100P	1	
C18	ECUE1H101KBQ ECUE1H102KBQ	50V 100P	3	
C19-21 C22	ECUE1E682KBQ	25V 6800P	1	
C23	ECUENA393KBQ	10V 0.039U	1	
C24	ECUE1E332KBQ	25V 3300P	1	
C27	ECUENA104KBQ	10V 0.1U	_ 1	
C28	ECUE1E332KBQ	25V 3300P	1	
C29-32	ECUE1H102KBQ	50V 1000P	4	
C33	ECUVNA224KBV	10V 0.22U	1	
C34	ECUE1C103KBQ	16V 0.01U	1	
C35	ECUV1C823KBQ		2	
C36,37	ECUENA104KBQ	10V 0.1U	1	
C39	RCST0GZ226RG		1	
C40	ECUE1H102KBQ		1	
C41	ECUE1C183KBQ	16V 0.018U	1	
C42	ECUV0J474KBV	6.3V 0.47U	1	<u> </u>
C43	ECUVNJ105KBV	63V 1U	1	
C44	ECUE1E332KBQ		1	
C101	RCST0GZ106RG		1	
C102,03	ECUENA104KBQ		2	
C104	ECUE1H102KBQ	1 2	1	
C105	ECUE1C103KBQ	T	1	
C106	ECUENA104KBQ		1	
C107	RCST0GZ106RG ECUENA104KBQ	***	1	
C108	RCST0GZ106RG		1	
C110,11	ECUENA104KBQ		2	
C112,13	ECUE1H120JCQ		2	
C114	ECUENA104KBQ	4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	1_	_
C115	ECUE1C123KBQ	16V 0.012U	1	
C116	ECUE1H221KBQ	50V 220P	1_	
C117	ECUENA473KBC		1	ļ <u> </u>
C118	ECUENA104KBQ		1	
C120	ECUENA104KBC		1	
C201	ECUENA104KBQ		1	
C202	RCST0GZ106RG		1	
C203	RCSTOGZ475RG	· 	1	
C205	RCSTOGZ106RG		1	
C206	ECUVNJ274KBV		1	
C207	RCST0GZ475RC		1	
C208	ECUVNJ274KBV	7 6.3V 0.27U	1	
C209	ECUENA104KB	10V 0.1U	1	<u> </u>
C210	RCSTOGZ106R		1	
C211-13	ECUENA104KB		3_	
C214,15	RCST0EX227RI		2	
C216,17	ECUVNA224KB		1	
C218	ECUE1H101KB		2	-
C219,20 C301	EEFCD0J470R		1	
C302	ECUE1C103KB		1	
C302	EEFCD0J470R		1	
C304	ECUE1E332KB	Q 25V 3300P	1	
C305	RCST0JY156R		1	_ ·
C306	ECUENA104KB	Q 10V 0.1U	_ 1	
C307	EEVMC0G221P		1	
C308-10	ECUENA104KB		3	
C311	RCST0GZ226R		1	
C312,13	ECUE1C103KB		1	
C401	RCSTOGZ106R		1	
C402	ECUE1H102KE		2	
C403,04	RCST0GZ106F		1	
C407	ECUENA104KE		4	
C412,13	ECUE1H221KE		2	
C414	RCST0GZ226F		_ 1	
				

Ref. No.	Part No.	Part Name &	Pcs	Remarks
		Description	 - 	
		63V 1U	3	
		50V 2200P	3	
		10V 1U	1 1	
		4V 47U 10V 1U	1	
		16V 0.027U	2	
C425,26 C427		10V 0.22U	1	
		16V 0.033U	3	
C501,02		50V 100P	2	
C503		16V 0.01U	1	
C504		50V 1000P	1	
C505	RCST0GZ106RG	4V 10U	1	
C506	ECUENA104KBQ	10V 0.1U	1	
C507	ECUE1C103KBQ	16V 0.01U	1	
C508	ECUVOJ474KBV	6.3V 0.47U	1	
C509	ECUE1C103KBQ	16V 0.01U	1	
C510		10V 0.1U	-11	
C511,12		50V 1000P	2	
C513	ECUENA104KBQ	10V 0.1U	1	
C601	RCST0GZ475RG	4V 4.7U	1	
C602,03	ECUENA104KBQ	10V 0.1U	1	
C604	RCSTOGZ475RG	4V 4.7U	1	
C605	RCST0GZ226RG	4V 22U 50V 2200P	- <u>-</u> -	
C606,07	RCSTOGZ226RG	4V 22U	1	
C608	ECUENA104KBQ	10V 0.1U	1	
C609	RCST0GZ475RG	4V 4.7U	1	
C610	ECUENA104KBQ	10V 0.1U	1	-
C612	RCST0GZ226RG	4V 22U	1	
C613	ECUENA104KBQ	10V 0.1U	1	
C614,15	ECUVNA105KBN	10V 1U	2	
C701	ECUENA104KBQ	10V 0.1U	1	
C702,03	ECUE1C103KBQ	16V 0.01U	2	
C704	ECUVNA224KBV	10V 0.22U	1	
C705	RCST0GZ106RG	4V 10U	1	
C706	ECUVNA224KBV	10V 0.22U	1_	
C707	RCST0GZ106RG	4V 10U	1	
C708-12	ECUVNJ335KBN	63V 3.3U	- 5	ļ
C713	RCSTOGZ106RG		1	
C714	RCST0GZ475RG		1	
C715	RCST0GZ226RG		1	
C716	ECUENA104KBQ	- 	1	-
C717	RCST0GZ225RG	T	- 1	-
C718	RCSTOGZ106RG		1	
C719	ECUE1H471KBQ		1	
C801	ECUENC333KBQ		1	
C802	ECUE1H101KBQ		1	
C803	RCSTOGZ106RG		$-\frac{1}{1}$	
C901 C902	ECUVNC104KBV		1	
C903	ECUV1E473KBN		1	
C904	ECUVNC104KBV		1	
C905	ECUV1H150KCV		1	
CN1	RJS2A7126T	CONNECTOR (26P)	1	
CN401	RJS2A7104T	CONNECTOR (4P)	1	
CN402	RJS2A7108T	CONNECTOR (8P)	1	<u> </u>
CN403	RJS2A7106T	CONNECTOR (6P)	1	
CN404	RJS2A7104T	CONNECTOR (4P)	1_	
CN701	RJS2A7111T	CONNECTOR (11P)	1	
CN901	RJS2A7108T	CONNECTOR (8P)	1_1	
CN902	RJS2A7104T	CONNECTOR (4P)	<u>1</u> _	
		COMPONED (117)		
CP801	RJS2A7411T	CONNECTOR (11P)	- 1	-
CP802	RJS2A7107T_	CONNECTOR (7P)		
0V215 15	RCST0GZ226R0	3 4V 22U	2	
CX315,16	ECUE1H101KB		1	-
CX405	THE OWNER OF THE		 -	
D1	MA2S111TX	DIODE	1	
D301	MA133TX	DIODE	1	
D303,04	F1J2ETP	DIODE	2	
D305,01	RB491DT146	DIODE	_ 1	
	1			


100				
Ref. No.	Part No.	Part Name & Description	Pc	s Remarks
D311	MA2S111TX		 -	
D501,02		DIODE	_ 1	
	MA741WATX	DIODE	2	·
D901,02	ZHCS1006TA	DIODE	2	
IC1	AN8772FHKEB	V IC	1	
IC101	MN66616RB1	IC	1	
IC102	MNA7400CWA1			
IC201	 		1_	
— —	TA2131FL	IC	1	
IC301	NJU7015RTE1	IC	1	
1C302 ⚠	XC6368A261MI	R IC	1	
IC303 ⚠	XC6367A151M	RIC	1	
1C304 ⚠	XC6372C501PE	R IC	1	
IC402	BD6604KVT	IC	1	
IC501	MN101CF32GCF	IC	1	
IC502	AK93C45BH~L	IC	=	
IC503			1	
	XC61FC2012MF	IC	1	
IC601_	AK4518VF-E2	IC	1	
IC701	AN7635SH-E1	IC	1	_
IC901	TC74ACT04FSE	IC	1	
JK702	D.T.T24D07 **	73.07	_	
UK/UZ	RJJ34R01-H	JACK MIC	1	
Li	RLQP100MT-W	COIL	1	
L101	RLQP100MT-W	COIL	1	
L103,04	RLQP100MT-W			
		COIL	2	<u> </u>
L201,02	RLBV601V-W	COIL	. 2	
L203	RLQP100MT-W	COIL	1	
L301_	RLZ0041T-T	COIL	1	
L302	RLZ0040T-T	COIL	1	
L303	ELJEA470KF	COIL	1	
L304	RLQP100MT-W		-	
		COIL	1	
L305	RLM9Z006T-D	COIL	1	
L402-06	RLQP100MT-W	COIL	5	
L407	ELJEA470KF	COIL	1	
L501	RLQP100MT-W	COIL	1	
L701-03	RLBV601V-W	COIL	3	
L705.06	RLBV601V-W	COIL	2	
L707	RLQP100MT-W	 		ļ. <u> </u>
L901		COIL	1	
11901	ELJEA100KF	COIL	1	
LCD801	RSL5239-C	TCD	1	<u> </u>
P1	RPK1292	FACKING CASE	1	
P2	RPQ0991	PAD	1	
P3	RPF0257-1	PROTECTION BAG	1	
PCB1	REP2837A-S	OPERATION P.C.B.		
PCB2			1	<rtl></rtl>
	REP2808A	SWITCH P.C.B.		<rtl></rtl>
PCB3	REP2828A-M	HEAD P.C.B.	1	<rtl></rtl>
PCB4	REP2836B-M	MAIN P.C.B.	1	<rtl></rtl>
Q1	2SB1295-6-TB	TRANSISTOR	1	
Q2	2SB1462STX	TRANSISTOR	1	
Q2 Q3	2SB1462STX DTC144TETL		+ - +	
		TRANSISTOR TRANSISTOR	1	
Q3	DTC144TETL DTC144EETL	TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1	
Q3 Q201 Q202	DTC144TETL DTC144EETL 2SB1295-6-TB	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1	
Q3 Q201 Q202 Q203	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1	
Q3 Q201 Q202 Q203 Q301	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XF4601TX	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XF4601TX	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	1 1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12C0MR XP161A1355PR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 2	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12C0MR XP161A1355PR XP161A1355PR 2SB1462STX	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 2 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12C0MR XP161A1355PR XP161A1355PR XP161A1355PR XP161A1355PR XP161A1355PR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 1 2 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308 Q309	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12C0MR XP161A1355PR 2SB1462STX XP151A12A2MR DTC144TETL	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 2 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308 Q309 Q310	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12COMR XP161A1355PR 2SB1462STX KP151A12A2MR DTC144TETL KP152A12COMR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 1 2 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308 Q309 Q310 Q312 Q405-08	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12C0MR XP161A1355PR 2SB1462STX XP151A12A2MR DTC144TETL	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 2 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308 Q309 Q310 Q312 Q405-08	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12COMR XP161A1355PR 2SB1462STX KP151A12A2MR DTC144TETL KP152A12COMR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
Q3 Q201 Q202 Q203 Q301 Q302 Q303 Q304 Q305 Q306,07 Q308 Q309 Q310 Q312 Q405-08	DTC144TETL DTC144EETL 2SB1295-6-TB 2SD2216STX 2SD2216STX XP151A12A2MR XP4601TX XP161A1355PR XP152A12COMR XP161A1355PR 2SB1462STX XP151A12A2MR DTC144TETL XP152A12COMR XP151A12A2MR XP151A12A2MR XP151A12A2MR XP151A12A2MR XP151A12A2MR XP151A12A2MR XP151A12A2MR XP151A12A2MR XMG6NTR	TRANSISTOR	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

Q703					
Q703	Ref. No	. Part No.	_	Pcs	Remarks
2704 XP152A12COMR TRANSISTOR 1	0702	TTRECTORING .			
Q901-04 ZSEZ16STX					
Q901-04 ZSK1764KYTR				-	<u> </u>
R1	·				
R2 ERJ2GEJ22X 1/4W 10X 1 R5 ERJ2GEJ103X 1/4W 10X 1 R11 ERJ2GEJ10X 1/4W 10X 1 R11,12 ERJ2GEJ103X 1/4W 10X 2 R13 ERJ2GEJ03X 1/4W 10X 2 R13 ERJ2GEJ03X 1/4W 10X 2 R13 ERJ2GEJ103X 1/4W 470 1 R14 ERJ2GEJ11X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R19,20 ERJ2GEJ473X 1/4W 470 1 R19,20 ERJ2GEJ104X 1/4W 10X 1 R22 ERJ2GEJ223X 1/4W 22X 1 R21 ERJ2GEJ23X 1/4W 22X 1 R22 ERJ2GEJ473X 1/4W 47K 1 R23 ERJ2GEJ473X 1/4W 47K 1 R23 ERJ2GEJ72X 1/4W 2.7K 2 R28 ERJ2GEJ72X 1/4W 2.7K 2 R28 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ333X 1/4W 33K 1 R33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ333X 1/4W 33K 1 R33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ33X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R35 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R35 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R31 ERJ2GEJ623X 1/4W 1X 1 R10 ERJ2GEJ623X 1/4W 1X 1 R110 ERJ2GEJ623X 1/4W 22K 1 R111 ERJ2GEJ623X 1/4W 1X 1 R204 ERJ2GEJ102X 1/4W 1X 1 R204 ERJ2GEJ102X 1/4W 1X 1 R205 ERJ2GEJ102X 1/4W 1X 1 R206 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ12X 1/4W 22K 1 R208 ERJ2GEJ22X 1/4W 22K 1 R209 ERJ2GEJ22X 1/4W 22K 1 R201 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ104X 1/4W 100K 1 R208 ERJ2GEJ104X 1/4W 100K 1 R209 ERJ2GEJ104X 1/4W 100K 1 R209 ERJ2GEJ104X 1/4W 100K 1 R201 ERJ2GEJ103X 1/4W 10K 1 R201 ERJ2GEJ103X 1/4W 10K 1 R202 ERJ2GEJ103X 1/4W 10K 1 R203 ERJ2GEJ103X 1/4W 10K 1 R204 ERJ2GEJ103X 1/4W 10K 1 R205 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W	Q901-04	ZSKI/64KYTR	TRANSISTOR	4	
R2 ERJ2GEJ22X 1/4W 10X 1 R5 ERJ2GEJ103X 1/4W 10X 1 R11 ERJ2GEJ10X 1/4W 10X 1 R11,12 ERJ2GEJ103X 1/4W 10X 2 R13 ERJ2GEJ03X 1/4W 10X 2 R13 ERJ2GEJ03X 1/4W 10X 2 R13 ERJ2GEJ103X 1/4W 470 1 R14 ERJ2GEJ11X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R15 ERJ2GEJ473X 1/4W 470 1 R19,20 ERJ2GEJ473X 1/4W 470 1 R19,20 ERJ2GEJ104X 1/4W 10X 1 R22 ERJ2GEJ223X 1/4W 22X 1 R21 ERJ2GEJ23X 1/4W 22X 1 R22 ERJ2GEJ473X 1/4W 47K 1 R23 ERJ2GEJ473X 1/4W 47K 1 R23 ERJ2GEJ72X 1/4W 2.7K 2 R28 ERJ2GEJ72X 1/4W 2.7K 2 R28 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ333X 1/4W 33K 1 R33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ333X 1/4W 33K 1 R33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ33X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEG000X 1/4W 0 1 R32,33 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R35 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R35 ERJ2GEJ73X 1/4W 47K 1 R31 ERJ2GEJ623X 1/4W 22K 1 R31 ERJ2GEJ623X 1/4W 1X 1 R10 ERJ2GEJ623X 1/4W 1X 1 R110 ERJ2GEJ623X 1/4W 22K 1 R111 ERJ2GEJ623X 1/4W 1X 1 R204 ERJ2GEJ102X 1/4W 1X 1 R204 ERJ2GEJ102X 1/4W 1X 1 R205 ERJ2GEJ102X 1/4W 1X 1 R206 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ12X 1/4W 22K 1 R208 ERJ2GEJ22X 1/4W 22K 1 R209 ERJ2GEJ22X 1/4W 22K 1 R201 ERJ2GEJ104X 1/4W 100K 1 R207 ERJ2GEJ104X 1/4W 100K 1 R208 ERJ2GEJ104X 1/4W 100K 1 R209 ERJ2GEJ104X 1/4W 100K 1 R209 ERJ2GEJ104X 1/4W 100K 1 R201 ERJ2GEJ103X 1/4W 10K 1 R201 ERJ2GEJ103X 1/4W 10K 1 R202 ERJ2GEJ103X 1/4W 10K 1 R203 ERJ2GEJ103X 1/4W 10K 1 R204 ERJ2GEJ103X 1/4W 10K 1 R205 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W	<u> </u>		 		
R5			1/4W 4.7K	1	
R10				1	
R11,12			1/4W 10K	1	
R13			1/4W 1	1	
R14				2	
R15		ERJ2GE0R00X	1/4W 0	1	
R16	<u> </u>		1/4W 470	_ 1	
R18		ERJ2GEJ473X	1/4W 47K	1	
R19,20 ERJZGEJ104X 1/4W 100K 2 R21 ERJZGEJ223X 1/4W 2ZK 1 R22 ERJZGEJ223X 1/4W 47K 1 R23 ERJZGEJ273X 1/4W 47K 1 R24,25 ERJZGEJ272X 1/4W 47K 1 R24,25 ERJZGEJ272X 1/4W 47K 1 R28 ERJZGEJ273X 1/4W 47K 1 R30 ERJZGEJ333X 1/4W 33K 1 R30 ERJZGEJ473X 1/4W 47K 1 R31 ERJZGEJ473X 1/4W 47K 1 R31 ERJZGEJ473X 1/4W 47K 2 R33 ERJZGEJ473X 1/4W 47K 2 R34 ERJZGEJ273X 1/4W 47K 2 R35 ERJZGEJ473X 1/4W 47K 2 R36 ERJZGEJ273X 1/4W 47K 1 R31 ERJZGEJ23X 1/4W 0 1 R107 ERJZGEJJ05X 1/4W 1M 1 R108 ERJZGEJ263X 1/4W 68K 1 R111 ERJZGEJ683X 1/4W 6.R 1 R114 ERJZGEJ683X 1/4W 6.R 1 R114 ERJZGEJ692X 1/4W 1K 1 R114 ERJZGEJ473X 1/4W 1K 1 R201 ERJZGEJ104X 1/4W 100K 1 R202 ERJZGEJ104X 1/4W 100K 1 R202 ERJZGEJ102X 1/4W 100K 1 R203 ERJZGEJ102X 1/4W 1X 1 R201 ERJZGEJ104X 1/4W 100K 1 R204 ERJZGEJ223X 1/4W 22K 1 R205 ERJZGEJ102X 1/4W 100K 1 R206 ERJZGEJ104X 1/4W 100K 1 R207 ERJZGEJ104X 1/4W 10OK 1 R208 ERJZGEJ104X 1/4W 10OK 1 R209 ERJZGEJ104X 1/4W 10OK 1 R201 ERJZGEJ104X 1/4W 10OK 1 R201 ERJZGEJ471X 1/4W 47O 1 R208 ERJZGEJ103X 1/4W 22K 1 R301 ERJZGEJ103X 1/4W 21 1 R301 ERJZGEJ103X 1/4W 10OK 1 R302 ERJZGEJ103X 1/4W 10OK 1 R303 ERJZGEJ103X 1/4W 10OK 1 R304 ERJZGEJ103X 1/4W 10OK 1 R306 ERJZGEJ103X 1/4W 10OK 1 R307 ERJZGEJ103X 1/4W 10OK 1 R308 ERJZGEJ103X 1/4W 10OK 1 R309 ERJZGEJ103X 1/4W 10OK 1 R309 ERJZGEJ103X 1/4W 10OK 1 R301 ERJZGEJ103X 1/4W 10OK 1 R301 ERJZGEJ103X 1/4W 10OK 1 R301 ERJZGEJ103X 1/4W 10OK 1 R302 ERJZGEJ103X 1/4W 10OK 1 R303 ERJZGEJ104X 1/4W 10OK 1 R304 ERJZGEJ104X 1/4W 10OK 1 R305 ERJZGEJ104X 1/4W 10OK 1 R306 ERJZGEJ104X 1/4W 10OK 1 R307 ERJZGEJ104X 1/4W 10OK 1 R308 ERJZGEJ103X 1/4W 10OK 1 R309 ERJZGEJ104X 1/4W 10OK 1 R309 ERJZGEJ104X 1/4W 10OK 1 R301 ERJZGEJ104X 1/4W 10OK 1 R302 ERJZGEJ105X 1/4W 10OK 1 R303 ERJZGEJ103X 1/4W 10OK 1 R304 ERJZGEJ103X 1/4W 10OK 1 R305 ERJZGEJ103X 1/4W 10OK 1 R306 ERJZGEJ103X 1/4W 10OK 1 R307 ERJZGEJ103X 1/4W 10OK 1 R308 ERJZGE	R16	ERJ2GEJ472X	1/4W 4.7K	1	
R21	R18	ERJ2GEJ474X	1/4W 470K	1	
R22 ERJ2GEJ102X 1/4W 1K 1 R23 ERJ2GEJ473X 1/4W 47K 1 R24,25 ERJ2GEJ473X 1/4W 47K 1 R28 ERJ2GEJ473X 1/4W 47K 1 R29 ERJ2GEJ333X 1/4W 33K 1 R30 ERJ2GEJ473X 1/4W 47K 1 R31 ERJ2GED60X 1/4W 0 1 R32,33 ERJ2GEJ473X 1/4W 47K 2 R34 ERJ2GEJ2473X 1/4W 47K 2 R35 ERJ2GEJ473X 1/4W 47K 1 R363 ERJ2GEJ473X 1/4W 47K 1 R373 ERJ2GEGJ223X 1/4W 22K 1 R374 ERJ2GEGJ223X 1/4W 22K 1 R375 ERJ2GEJ05X 1/4W 0 1 R107 ERJ2GEJ05X 1/4W 1M 1 R108 ERJ2GEJ05X 1/4W 1M 1 R108 ERJ2GEJ683X 1/4W 68K 1 R111 ERJ2GEJ683X 1/4W 68K 1 R111 ERJ2GEJ683X 1/4W 1K 1 R113 ERJ2GEJ103X 1/4W 1K 1 R201 ERJ2GEJ103X 1/4W 100K 1 R202 ERJ2GEJ103X 1/4W 100K 1 R202 ERJ2GEJ103X 1/4W 22C 1 R203 ERJ2GEJ102X 1/4W 1X R204 ERJ2GEJ102X 1/4W 1X R204 ERJ2GEJ103X 1/4W 1X R205 ERJ2GEJ103X 1/16W 2.2M 1 R206 ERJ2GEJ103X 1/16W 2.2M 1 R207 ERJ2GEJ10X 1/16W 10 R207 ERJ2GEJ10X 1/16W 10 R207 ERJ2GEJ10X 1/16W 10 R208 ERJ2GEJ10X 1/16W 10 R209 ERJ2GEJ10X 1/16W 10 R207 ERJ2GEJ10X 1/16W 10 R208 ERJ2GEJ10X 1/16W 10 R209 ERJ2GEJ10X 1/16W 10 R209 ERJ2GEJ10X 1/16W 10 R209 ERJ2GEJ10X 1/16W 33K 1 R300 ERJ2GEJ10X 1/16W 33K 1 R300 ERJ2GEJ10X 1/16W 33K 1 R301 ERJ2GEJ10X 1/16W 10K 1 R306 ERJ2GEJ10X 1/16W 10K 1 R307 ERJ2GEJ10X 1/16W 10K 1 R308 ERJ2GEJ10X 1/16W 10K 1 R309 ERJ2GEJ10X 1/16W 10K 1 R309 ERJ2GEJ10X 1/16W 10K 1 R309 ERJ2GEJ10X 1/16W 10K 1 R311 ERJ2GEJ10X 1/16W 10K 1 R313 ERJ2GEJ10X 1/16W 10K 1 R314 ERJ2GEJ10X 1/16W 10K 1 R315 ERJ2GEJ10X 1/16W 10K 1 R316 ERJ2GEJ10X 1/16W 10K 1 R317 ERJGEJ10X 1/16W 10K 1 R318 ERJ2GEJ10X 1/16W 10K 1 R319 ERJ2GEJ10X 1/16W 10K 1 R322 ERJ2GEJ10X 1/16W 10K 1 R324 ERJ2GEJ10X 1/16W 10K 1 R324 ERJ2GEJ10X 1/16W 10K 1 R325 ERJ2GEJ03X 1/16W 10K 1 R326 ERJ2GEJ03X 1/1	R19,20	ERJ2GEJ104X	1/4W 100K	2	_
R23	R21	ERJ2GEJ223X	1/4W 22K	1	
R24,25	R22	ERJ2GEJ102X	1/4W 1K	1	
R24,25	R23	ERJ2GEJ473X	1/4W 47K	1	
R28 ERJ2GEJ473X 1/4W 47K 1 R29 ERJ2GEJ333X 1/4W 33K 1 R31 ERJ2GEJ333X 1/4W 47K 1 R31 ERJ2GEJ473X 1/4W 47K 2 R31 ERJ2GEJ473X 1/4W 47K 2 R34 ERJ2GEJ473X 1/4W 47K 2 R34 ERJ2GEJ473X 1/4W 47K 1 R35 ERJ2GEJ473X 1/4W 47K 1 R363 ERJ2GEJ473X 1/4W 0 1 R373 ERJ2GEJ473X 1/4W 0 1 R374 ERJ2GEJ223X 1/4W 22K 1 R35 ERJ2GEJ473X 1/4W 10M 1 R102 ERJ2GEJ00X 1/4W 1M 1 R103 ERJ2GEJ223X 1/4W 22K 1 R104 ERJ2GEJ223X 1/4W 22K 1 R110 ERJ2GEJ682X 1/4W 68K 1 R111 ERJ2GEJ682X 1/4W 68K 1 R111 ERJ2GEJ682X 1/4W 68K 1 R111 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ104X 1/4W 10N 1 R202 ERJ2GEJ104X 1/4W 10N 1 R202 ERJ2GEJ104X 1/4W 10N 1 R203 ERJ2GEJ102X 1/4W 22 1 R204 ERB24V255X 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 22K 1 R206 ERB24V1000X 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 47O 1 R208 ERJ2GEJ773Y 1/16W 27K 1 R208 ERJ2GEJ773Y 1/16W 27K 1 R209 ERB28V103JX 1/32W 10K 1 R211 ERB24V332JX 1/16W 330K 1 R301 ERB24V33AJX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R305 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ103X 1/4W 10K 1 R308 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ104X 1/4W 100K 1 R301 ERJ2GEJ105X 1/4W 10K 1 R301 ERJ2GEJ105X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ104X 1/4W 100K 1 R301 ERJ2GEJ105X 1/4W 10K 1 R301 ERJ2GEJ104X 1/4W 100K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ104X 1/4W 100K 1 R304 ERJ2GEJ104X 1/4W 100K 1 R305 ERJ2GEJ104X 1/4W 100K 1 R306 ERJ2GEJ104X 1/4W 100K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ104X 1/4W 100K 1 R309 ERJ2GEJ104X 1/4W 100K 1 R318 ERJ2GEJ104X 1/4W 100K 1 R319 ERJ2GEJ104X 1/4W 100K 1 R319 ERJ2GEJ103X 1/4W 10K 1 R319 ERJ2GEJ103X 1/4W 10K 1 R319 ERJ2GEJ103X 1/4W 10K 1 R319 ERJ2GEJ103	R24,25	ERJ2GEJ272X			_
R29	R28	ERJ2GEJ473X	+		
R30 ERJ2GEJ473X 1/4W 47K 1 R31 ERJ2GED473X 1/4W 0 1 R32,33 ERJ2GEJ473X 1/4W 47K 2 R34 ERJ2GEJ223X 1/4W 22K 1 R35 ERJ2GEJ473X 1/4W 47K 1 R102 ERJ2GED105X 1/4W 0 1 R107 ERJ2GEJ105X 1/4W 1M 1 R108 ERJ2GEJ223X 1/4W 22K 1 R110 ERJ2GEJ683X 1/4W 68K 1 R111 ERJ2GEJ683X 1/4W 6.9K 1 R111 ERJ2GEJ683X 1/4W 6.9K 1 R113 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ102X 1/4W 18K 1 R203 ERJ2GEJ102X 1/4W 18K 1 R204 ERS24V225JX 1/4W 22K 1 R205 ERJ2GEJ221X 1/4W 22K 1 R206 ERS24V100JX 1/16W 20 1 R207 ERJ2GEJ473X 1/4W 47O 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 ERS28V103JX 1/16W 27K 1 R301 ERS24V332JX 1/16W 3.3K 1 R301 ERS24V332JX 1/4W 10K 1 R302 ERJ2GEJ104X 1/4W 10K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ103X 1/4W 10K 1 R308 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W 10K 1 R302 ERJ2GEJ103X 1/4W 10K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R305 ERJ2GEJ104X 1/4W 100K 1 R307 ERJ2GEJ105X 1/4W 10K 1 R318 ERJ2GEJ104X 1/4W 10K 1 R319 ERJ2GEJ104X 1/4W 10K 1 R311 ERJ2GEJ104X 1/4W 10K 1 R312 ERJ2GEJ104X 1/4W 10K 1 R313 ERJ2GEJ104X 1/4W 10K 1 R314 ERJ2GEJ104X 1/4W 10K 1 R315 ERJ2GEJ104X 1/4W 10K 1 R316 ERJ2GEJ104X 1/4W 10K 1 R317 ERJ3GED105X 1/4W 10K 1 R318 ERJ2GEJ104X 1/4W 10K 1 R319 ERJ2GEJ105X 1/4W 10K 1 R320 ERJ2GEJ105X 1/4W 10K 1 R320 ERJ2GEJ105X 1/4W 1	R29				
R31	R30				_
R32,33 ERJ2GEJ473X 1/4W 47K 2 R34 ERJ2GEJ223X 1/4W 47K 1 R35 ERJ2GEJ473X 1/4W 47K 1 R102 ERJ2GEJ105X 1/4W 0 1 R107 ERJ2GEJ105X 1/4W 1M 1 R108 ERJ2GEJ223X 1/4W 22K 1 R110 ERJ2GEJ683X 1/4W 68K 1 R111 ERJ2GEJ682X 1/4W 6.9K 1 R111 ERJ2GEJ62X 1/4W 1K 1 R111 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ102X 1/4W 10K 1 R202 ERJ2GEJ21X 1/4W 220 1 R203 ERJ2GEJ223X 1/4W 220 1 R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 22K 1 R206 ERJ2GEJ223X 1/4W 27K 1 R207 ERJ2GEJ471X 1/4W 47O 1 R208 ERJ3GEYD273V 1/16W 10 1 R209 EKB2EV103JX 1/32W 10K 1 R211 EXB24V334JX 1/16W 330K 1 R301 ERJ2GEJ103X 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R305 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ103X 1/4W 10K 1 R308 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R301 ERJ2GEJ103X 1/4W 10K 1 R311 ERJ2GED105X 1/4W 10K 1 R312 ERJ2GED105X 1/4W 10K 1 R313 ERJ2GED105X 1/4W 10K 1 R314 ERJ2GEJ103X 1/4W 10K 1 R315 ERJ2GED105X 1/4W 10K 1 R316 ERJ2GEJ103X 1/4W 10K 1 R317 ERJGRSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 10K 1 R319.0 ERJ2GEJ105X 1/4W 10K 1 R319.0 ERJ2GEJ105X 1/4W 10K 1 R319 ERJ2GED105X 1/4W 10K 1 R319 ERJ2GEJ103X 1/4W 10K 1 R319 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 47K 2	R31				
R34	R32.33				
R35		T — —		-	
R102					
R107 ERJ2GEJ105X 1/4W 1M 1 R108 ERJ2GEJ223X 1/4W 22K 1 R110 ERJ2GEJ683X 1/4W 68K 1 R111 ERJ2GEJ682X 1/4W 68K 1 R111 ERJ2GEJ682X 1/4W 68K 1 R111 ERJ2GEJ102X 1/4W 1K 1 R114 ERJ2GEJ102X 1/4W 10W 1 R201 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ104X 1/4W 100K 1 R203 ERJ2GEJ102X 1/4W 1K 1 R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ23X 1/16W 2.2M 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ23X 1/16W 10 1 R208 ERJ3GEVD273V 1/16W 10 1 R209 EXB28V103JX 1/32W 10K 1 R209 EXB28V103JX 1/32W 10K 1 R209 EXB28V103JX 1/16W 330K 1 R211 EXB24V332JX 1/16W 330K 1 R2301 EXB24V334JX 1/16W 330K 1 R301 EXB24V334JX 1/16W 330K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ103X 1/4W 10K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R301 EXB24V34JX 1/4W 10K 1 R301 EXB2GEJ104X 1/4W 10OK 1 R301 ERJ2GEJ104X 1/4W 10OK 1 R311 ERJ2GED513X 1/4W 10 1 R312 ERJ2GEJ104X 1/4W 10OK 1 R313 EXB24V104JX 1/4W 10OK 1 R314 ERJ2GEJ104X 1/4W 10OK 1 R315 ERJ2GEJ104X 1/4W 10OK 1 R316 ERJ2GEJ104X 1/4W 10OK 1 R317 ERJ6RSJR1OV 1/10W 0.1 1 R318 ERJ2GEJ104X 1/4W 10OK 1 R319,20 ERJ2GEJ105X 1/4W 1M 1 R319,20 ERJ2GEJ105X 1/4W 10OK 1 R319,20 ERJ2GEJ105X 1/4W 10OK 1 R319,20 ERJ2GEJ105X 1/4W 10OK 1 R319,20 ERJ2GEJ103X 1/4W 10OK 1 R319,20 ERJ2GEJ103X 1/4W 10OK 1 R310 ERJ2GEJ103X 1/4W 10OK 1 R311 ERJ2GEJ103X 1/4W 10OK 1 R312 ERJ2GEJ103X 1/4W 10OK 1 R322 ERJ2GEJ			+		
R108					
R110 ERJ2GEJ683X 1/4W 68K 1 R1111 ERJ2GEJ682X 1/4W 1K 1 R113 ERJ2GEJ102X 1/4W 1K 1 R114 ERJ2GEJ102X 1/4W 1K 1 R201 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ102X 1/4W 1K 1 R202 ERJ2GEJ102X 1/4W 1K 1 R203 ERJ2GEJ102X 1/4W 1K 1 R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 22K 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 33K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ104X 1/4W 100K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ104X 1/4W 100K 1 R301 ERJ2GEJ104X 1/4W 100K 1 R310,11 ERJ2GED1513X 1/4W 51K 2 R311 ERJ2GED105X 1/4W 1M 1 R311 ERJ2GED105X 1/4W 100K 1 R311 ERJ2GED105X 1/4W 100K 1 R312 ERJ2GED105X 1/4W 100K 1 R314 ERJ2GEJ104X 1/4W 100K 1 R315 ERJ2GED105X 1/4W 100K 1 R316 ERJ2GEJ105X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ105X 1/4W 100K 1 R319,20 ERJ2GEJ105X 1/4W 100K 1 R322 ERJ2GED105X 1/4W 1M 1 R3232 ERJ2GED105X 1/4W 100K 1 R3232 ERJ2GEJ103X 1/4W 100K 1 R402 ERJ2GEJ103X 1/4W 100K 1 R403 ERJ2GEJ103X 1/4W 100K 1 R404 ERJ2GEJ103X 1/4W 100K 1 R405 ERJ2GEJ103X 1/4W 100K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1					
R111					
R113 ERJ2GEJ102X 1/4W 1K 1 R114 ERJ2GEJ473X 1/4W 47K 1 R201 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ102X 1/4W 220 1 R203 ERJ2GEJ102X 1/4W 1K 1 R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 2.2M 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R201 ERB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 3.3K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ33X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ103X 1/4W 10K 1 R308 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ105X 1/4W 10K 1 R311 ERJ2GEJ513X 1/4W 390K 1 R312 ERJ2GEJ154X 1/4W 100K 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ155X 1/4W 10 R315 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ105X 1/4W 100K 1 R317 ERJ2GEJ104X 1/4W 100K 1 R318 ERJ2GEJ154X 1/4W 100K 1 R319 ERJ2GEJ154X 1/4W 100K 1 R311 ERJ2GEJ154X 1/4W 100K 1 R312 ERJ2GEJ105X 1/4W 100K 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GED105X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324 ERJ2GEJ105X 1/4W 100K 1 R325 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ105X 1/4W 1M 1 R327 ERJ2GEJ25X 1/4W 2.2M 1 R328 ERJ2GEJ105X 1/4W 1M 1 R329 ERJ2GEJ105X 1/4W 1M 1 R321 ERJ2GEJ105X 1/4W 1M 1 R321 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324 ERJ2GEJ105X 1/4W 1M 1 R325 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ103X 1/4W 10K 1 R327 ERJ2GEJ103X 1/4W 10K 1 R328 ERJ2GEJ103X 1/4W 10K 1 R329 ERJ2GEJ103X 1/4W 10K 1 R320 ERJ2GEJ103X 1/4W 10K 1 R321 ERJ2GEJ103X 1/4W 10K 1 R322 ERJ2GEJ103X 1/4W 10K 1 R323 ERJ2GEJ103X 1/4W 10K 1 R324 ERJ2GEJ103X 1/4W 10K 1 R326 ERJ2GEJ103X 1/4W 10K 1 R327 ERJ2GEJ103X 1/4W 10K 1 R328 ERJ2GEJ103X 1/4W 10K 1 R329 ERJ2GEJ103X 1/4W 10K 1 R320 ERJ2GEJ103X 1/4W 10K 1 R321 ERJ2GEJ103X 1/4W 10K 1 R322 ERJ2GEJ103X 1/4W 10K 1 R323 ERJ2GEJ103X 1/4W 10K 1 R324 ERJ2GEJ103X 1/4W 10K 1					
R114				_ 1 _	
R201 ERJ2GEJ104X 1/4W 100K 1 R202 ERJ2GEJ221X 1/4W 22O 1 R203 ERJ2GEJ102X 1/4W 1K 1 R204 ERB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 22K 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ103X 1/4W 10K 1 R308 ERJ2GEJ104X 1/4W 10OK 1 R309 ERJ2GEJ103X 1/4W 10K 1 R301 EXB24V334JX 1/4W 10K 1 R301 EXB2GEJ103X 1/4W 10K 1 R301 EXB2GEJ103X 1/4W 10K 1 R303 ERJ2GEJ103X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R305 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ104X 1/4W 10OK 1 R317 ERJ2GEJ104X 1/4W 10OK 1 R318 ERJ2GEJ104X 1/4W 10OK 1 R319 ERJ2GEJ104X 1/4W 10OK 1 R311 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 10OK 1 R314 ERJ2GEJ154X 1/4W 10OK 1 R315 ERJ2GEJ104X 1/4W 10OK 1 R316 ERJ2GEJ104X 1/4W 10OK 1 R317 ERJGRSTR10V 1/10W 0.1 1 R318 ERJ2GEJ104X 1/4W 10OK 1 R319 ERJ2GEJ105X 1/4W 1M 1 R319 ERJ2GEJ105X 1/4W 1M 1 R319 ERJ2GEJ105X 1/4W 10OK 1 R321 ERJ2GEJ104X 1/4W 10OK 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R324 ERJ2GEJ105X 1/4W 1M 1 R3252 ERJ2GEJ25X 1/4W 2.2M 1 R326 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1			·	1.	
R202 ERJ2GEJ221X 1/4W 1K 1 R203 ERJ2GEJ102X 1/4W 1K 1 R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 2ZK 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB26V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R2301 EXB26V33JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 3.3K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ104X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R309 ERJ2GEJ104X 1/4W 100K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R3110,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 100K 1 R314 ERJ2GEJ104X 1/4W 100K 1 R315 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ2GEJ104X 1/4W 100K 1 R318 ERJ2GEJ104X 1/4W 100K 1 R319 ERJ2GEJ104X 1/4W 100K 1 R311 ERJ2GEJ104X 1/4W 100K 1 R312 ERJ2GEJ105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJGRSJR10V 1/10W 0.1 1 R319 ERJ2GEJ104X 1/4W 100K 1 R319 ERJ2GEJ105X 1/4W 1M 1 R319 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R322 ERJ2GEJ104X 1/4W 100K 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324 ERJ2GEJ105X 1/4W 1M 1 R325 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ105X 1/4W 1M 1 R327 ERJ2GEJ105X 1/4W 1M 1 R328 ERJ2GEJ105X 1/4W 1M 1 R329 ERJ2GEJ105X 1/4W 1M 1 R320 ERJ2GEJ103X 1/4W 10K 1			T	1	
R203			1/4W 100K	1	
R204 EXB24V225JX 1/16W 2.2M 1 R205 ERJ2GEJ223X 1/4W 22K 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 33K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ104X 1/4W 10K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 10OK 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ104X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 390K 1 R311 ERJ2GED513X 1/4W 10K 1 R312 ERJ2GED105X 1/4W 10 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ105X 1/4W 1M 1 R319,20 ERJ2GEJ393X 1/4W 390K 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3319,20 ERJ2GEJ325X 1/4W 2.2M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R323 ERJ2GED105X 1/4W 1M 1 R324 ERJ2GEJ105X 1/4W 1M 1 R325 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ105X 1/4W 1M 1 R327 ERJ6RSJR10V 1/10W 0.1 1 R328 ERJ2GEJ105X 1/4W 1M 1 R329 ERJ2GEJ105X 1/4W 1M 1 R3210 ERJ2GEJ105X 1/4W 1M 1 R3211 ERJ2GEJ105X 1/4W 1M 1 R3212 ERJ2GEJ105X 1/4W 1M 1 R3213 ERJ2GEJ105X 1/4W 1M 1 R3214 ERJ2GEJ105X 1/4W 1M 1 R3215 ERJ2GEJ105X 1/4W 1M 1 R3216 ERJ2GEJ105X 1/4W 1M 1 R3217 ERJ6RSJR10V 1/10W 0.1 1 R3218 ERJ2GEJ105X 1/4W 1M 1 R3219,20 ERJ2GEJ474X 1/4W 470K 2 R3211 ERJ2GEJ105X 1/4W 1M 1 R3212 ERJ2GEJ105X 1/4W 1M 1 R3222 ERJ2GEJ25X 1/4W 2.2M 1 R3224 ERJ2GEJ103X 1/4W 10K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R403 ERJ2GEJ103X 1/4W 10K 1 R404 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1 R2006 ERJ2GEJ473X 1/4W 47K 1			1/4W 220	1	
R205 ERJZGEJ223X 1/4W 22K 1 R206 EXB24V100JX 1/16W 10 1 R207 ERJZGEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R301 ERJZGEJ104X 1/4W 100K 1 R303 ERJZGEJ103X 1/4W 33K 1 R304 ERJZGEJ103X 1/4W 10K 1 R306 ERJZGEJ103X 1/4W 10K 1 R307 ERJZGEJ103X 1/4W 10K 1 R308 ERJZGEJ474X 1/4W 470K 1 R309 ERJZGEJ533X 1/4W 390K 1 R310,11 ERJZGEJ533X 1/4W 51K 2 R312 ERJZGEJ15X 1/4W 10M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJZGEJ154X 1/4W 100K 1 R315 ERJZGEJ104X 1/4W 100K 1 R316 ERJZGEJ104X 1/4W 100K 1 R317 ERJGRSJR10V 1/4W 100K 1 R318 ERJZGEJ104X 1/4W 100K 1 R319,20 ERJZGEJ474X 1/4W 470K 2 R322 ERJZGEJ25X 1/4W 390K 1 R322 ERJZGEJ105X 1/4W 1M 1 R3319,20 ERJZGEJ474X 1/4W 470K 2 R322 ERJZGEJ105X 1/4W 1M 1 R323 ERJZGEJ105X 1/4W 1M 1 R324 ERJZGEJ105X 1/4W 100K 1 R325 ERJZGEJ104X 1/4W 100K 1 R326 ERJZGEJ104X 1/4W 100K 1 R327 ERJGRSJR10V 1/10W 0.1 1 R328 ERJZGEJ105X 1/4W 1M 1 R329 ERJZGEJ474X 1/4W 470K 2 R320 ERJZGEJ474X 1/4W 470K 2 R320 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ105X 1/4W 1M 1 R322 ERJZGEJ25X 1/4W 2.PM 1 R322 ERJZGEJ25X 1/4W 2.PM 1 R322 ERJZGEJ103X 1/4W 10K 1 R402 ERJZGEJ103X 1/4W 10K 1 R403 ERJZGEJ103X 1/4W 10K 1 R404 ERJZGEJ103X 1/4W 10K 1 R405 ERJZGEJ103X 1/4W 10K 1 R406,07 ERJZGEJ473X 1/4W 47K 2 R408 ERJZGEJ473X 1/4W 47K 1		ERJ2GEJ102X	1/4W 1K	1	
R206 EXB24V100JX 1/16W 10 1 R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R311 ERJ2GEJ105X 1/4W 10M 1 R312 ERJ2GEJ105X 1/4W 10M 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ2GED105X 1/4W 10 1 R318 ERJ2GEJ104X 1/4W 100K 1 R319,20 ERJ2GEJ104X 1/4W 100K 1 R319,20 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ104X 1/4W 100K 1 R3217 ERJGRSJR10V 1/10W 0.1 1 R3218 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ255X 1/4W 2.2M 1 R3232 ERJ2GEJ255X 1/4W 2.2M 1 R3232 ERJ2GEJ255X 1/4W 1.2M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R3254,25 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ473X 1/4W 47K 1		EXB24V225JX	1/16W 2.2M	1	
R207 ERJ2GEJ471X 1/4W 470 1 R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ474X 1/4W 470K 1 R310,11 ERJ2GED513X 1/4W 390K 1 R3110,11 ERJ2GED513X 1/4W 10M 1 R312 ERJ2GEJ104X 1/4W 100K 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ154X 1/4W 100K 1 R317 ERJGRSJR10V 1/10W 0.1 1 R318 ERJ2GEJ104X 1/4W 100K 1 R319,20 ERJ2GEJ394X 1/4W 390K 1 R321 ERJ2GED105X 1/4W 1M 1 R321 ERJ2GED105X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ105X 1/4W 1M 1 R3219,20 ERJ2GEJ105X 1/4W 1M 1 R3219,20 ERJ2GEJ474X 1/4W 470K 2 R322 ERJ2GEJ255X 1/4W 2.2M 1 R3232 ERJ2GEJ255X 1/4W 2.2M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R3254,25 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ473X 1/4W 47K 1	R205	ERJ2GEJ223X	1/4W 22K	1	
R208 ERJ3GEYD273V 1/16W 27K 1 R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ33X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 10OK 1 R309 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ154X 1/4W 100K 1 R316 ERJ2GEJ164X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ15X 1/4W 1M 1 R321 ERJ2GEJ15X 1/4W 1M 1 R321 ERJ2GEJ15X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ15X 1/4W 470K 2 R323 ERJ2GEJ15X 1/4W 470K 2 R324 ERJ2GEJ15X 1/4W 470K 2 R325 ERJ2GEJ103X 1/4W 10K 1 R326 ERJ2GEJ103X 1/4W 10K 1 R326 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ103X 1/4W 10K 1	3206	EXB24V100JX	1/16W 10	1	
R209 EXB28V103JX 1/32W 10K 1 R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 3.3K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 10K 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R3112 ERJ2GED105X 1/4W 1M 1 R3114 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ154X 1/4W 100K 1 R316 ERJ2GEJ164X 1/4W 100K 1 R317 ERJ2GEJ104X 1/4W 100K 1 R318 ERJ2GEJ104X 1/4W 100K 1 R3214 ERJ2GEJ154X 1/4W 100K 1 R3215 ERJ2GEJ104X 1/4W 100K 1 R3216 ERJ2GEJ104X 1/4W 100K 1 R3217 ERJ6RSJR10V 1/10W 0.1 1 R3218 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ103X 1/4W 10K 1	207	ERJ2GEJ471X	1/4W 470	1	
R211 EXB24V332JX 1/16W 3.3K 1 R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 10K 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R314 ERJ2GED105X 1/4W 100K 1 R315 ERJ2GEJ154X 1/4W 100K 1 R316 ERJ2GEJ154X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ394X 1/4W 390K 1 R321 ERJ2GEJ155X 1/4W 1M 1 R321 ERJ2GED105X 1/4W 1M 1 R321 ERJ2GED105X 1/4W 1M 1 R321 ERJ2GED105X 1/4W 100K 1 R321 ERJ2GEJ154X 1/4W 100K 1 R321 ERJ2GEJ154X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ104X 1/4W 100K 1 R321 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ155X 1/4W 1M 1 R323 ERJ2GEJ155X 1/4W 2.2M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R3254,25 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 2 R402 ERJ2GEJ103X 1/4W 10K 1 R403 ERJ2GEJ103X 1/4W 10K 1 R404 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ473X 1/4W 47K 1	208	ERJ3GEYD273V	1/16W 27K	1	
R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GEJ333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ474X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 1M 1 R3112 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ473X 1/4W 47K 1	209	EXB28V103JX	1/32W 10K	1	
R301 EXB24V334JX 1/16W 330K 1 R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 10K 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 1M 1 R3112 ERJ2GED105X 1/4W 1M 1 R312 ERJ2GED105X 1/4W 100K 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GED105X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ105X 1/4W 1M 1 R319,20 ERJ2GEJ105X 1/4W 1M 1 R3212 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R3232 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R325 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ105X 1/4W 1M 1 R327 ERJ2GEJ105X 1/4W 1M 1 R328 ERJ2GEJ105X 1/4W 1M 1 R329 ERJ2GEJ105X 1/4W 1M 1 R320 ERJ2GEJ105X 1/4W 1M 1 R3214 ERJ2GEJ105X 1/4W 1M 1 R3224 ERJ2GEJ105X 1/4W 1M 1 R3225 ERJ2GEJ105X 1/4W 1M 1 R3244,25 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ103X 1/4W 10K 1 R500 ERJ2GEJ103X 1/4W 10K 1	211	EXB24V332JX	1/16W 3.3K	1	
R302 ERJ2GEJ104X 1/4W 100K 1 R303 ERJ2GED333X 1/4W 33K 1 R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ104X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R3112 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED105X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ104X 1/4W 10M 1 R3214 ERJ2GEJ15X 1/4W 1M 1 R3215 ERJ2GED105X 1/4W 1M 1 R3216 ERJ2GEJ104X 1/4W 100K 1 R3217 ERJ6RSJR10V 1/10W 0.1 1 R3218 ERJ2GEJ105X 1/4W 1M 1 R322 ERJ2GEJ105X 1/4W 1M 1 R3225 ERJ2GEJ105X 1/4W 1M 1 R3226 ERJ2GEJ105X 1/4W 1M 1 R3227 ERJ2GEJ105X 1/4W 1M 1 R3228 ERJ2GEJ105X 1/4W 1M 1 R3229 ERJ2GEJ105X 1/4W 1M 1 R3220 ERJ2GEJ105X 1/4W 1M 1 R3220 ERJ2GEJ105X 1/4W 1M 1 R3221 ERJ2GEJ105X 1/4W 1M 1 R3222 ERJ2GEJ105X 1/4W 1M 1 R3223 ERJ2GEJ103X 1/4W 10K 1 R4001 EXB24V474JX 1/16W 470K 1 R4002 ERJ2GEJ103X 1/4W 10K 1 R4005 ERJ2GEJ103X 1/4W 10K 1 R4006,07 ERJ2GEJ473X 1/4W 47K 2	301	EXB24V334JX		1	
R303	302	ERJ2GEJ104X	1/4W 100K		
R304 ERJ2GEJ103X 1/4W 10K 1 R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ474X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GEJ154X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R3217 ERJ2GEJ15X 1/4W 1M 1 R3218 ERJ2GEJ104X 1/4W 100K 1 R3219,20 ERJ2GEJ474X 1/4W 470K 2 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R3254,25 ERJ2GEJ105X 1/4W 1M 1 R3264 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1	303	ERJ2GED333X			· -
R306 ERJ2GEJ103X 1/4W 10K 1 R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ474X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 100K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ15X 1/4W 1M 1 R321 ERJ2GEJ15X 1/4W 1M 1 R321 ERJ2GEJ15X 1/4W 1M 1 R322 ERJ2GEJ25X 1/4W 1M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ103X 1/4W 1M 1 R326 ERJ2GEJ103X 1/4W 10K 1 R400 ERJ2GEJ473X 1/4W 47K 2	304				
R307 ERJ2GEJ104X 1/4W 100K 1 R308 ERJ2GEJ474X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R3112 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GEJ105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ394X 1/4W 2.2M 1 R323 ERJ2GEJ105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1	306	ERJ2GEJ103X			
R308 ERJ2GEJ474X 1/4W 470K 1 R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ105X 1/4W 1M 1 R326 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R406 ERJ2GEJ103X 1/4W 10K 1 R407 ERJ2GEJ103X 1/4W 10K 1 R408 ERJ2GEJ103X 1/4W 10K 1	307			 	
R309 ERJ2GEJ394X 1/4W 390K 1 R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ103X 1/4W 10K 1	308				
R310,11 ERJ2GED513X 1/4W 51K 2 R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 10K 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R408 ERJ2GEJ103X 1/4W 10K 1 ERJ2GEJ103X 1/4W 10K 1 R408 ERJ2GEJ103X 1/4W 10K 1	309				
R312 ERJ2GED105X 1/4W 1M 1 R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ103X 1/4W 10K 1				+	
R313 EXB24V104JX 1/4W 100K 1 R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R322 ERJ2GEJ25X 1/4W 1M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ00X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ473X 1/4W 47K 1					
R314 ERJ2GEJ154X 1/4W 150K 1 R315 ERJ2GED104X 1/4W 100K 1 R316 ERJ2GEJ104X 1/4W 100K 1 R317 ERJ6RSJR10V 1/10W 0.1 1 R318 ERJ2GED105X 1/4W 1M 1 R319,20 ERJ2GEJ474X 1/4W 470K 2 R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ25X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEJ103X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1 ERJ2GEJ473X 1/4W 47K 1					
R315 ERJZGED104X 1/4W 100K 1 R316 ERJZGEJ104X 1/4W 100K 1 R317 ERJGRSJR10V 1/10W 0.1 1 R318 ERJZGED105X 1/4W 1M 1 R319,20 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ394X 1/4W 390K 1 R322 ERJZGEJ25X 1/4W 2.2M 1 R323 ERJZGEJ105X 1/4W 1M 1 R324,25 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ103X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJZGEJ103X 1/4W 10K 1 R405 ERJZGEJ103X 1/4W 10K 1 R406,07 ERJZGEJ473X 1/4W 47K 2 R408 ERJZGEJ103X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1 R408 ERJZGEJ103X 1/4W 10K 1					
R316 ERJZGEJ104X 1/4W 100K 1 R317 ERJGRSJR10V 1/10W 0.1 1 R318 ERJZGED105X 1/4W 1M 1 R319,20 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ394X 1/4W 390K 1 R322 ERJZGEJ25X 1/4W 2.2M 1 R323 ERJZGEJ105X 1/4W 1M 1 R324,25 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ103X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJZGEJ103X 1/4W 10K 1 R405 ERJZGEJ103X 1/4W 10K 1 R406,07 ERJZGEJ473X 1/4W 47K 2 R408 ERJZGEJ103X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1 R501 ERJZGEJ473X 1/4W 47K 1					
R317 ERJGRSJR10V 1/10W 0.1 1 R318 ERJZGED105X 1/4W 1M 1 R319,20 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ394X 1/4W 390K 1 R3222 ERJZGEJ225X 1/4W 2.2M 1 R3233 ERJZGED105X 1/4W 1M 1 R324,25 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEJ103X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJZGEJ103X 1/4W 10K 1 R405 ERJZGEJ103X 1/4W 10K 1 R406,07 ERJZGEJ473X 1/4W 47K 2 R408 ERJZGEJ103X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1 R501 ERJZGEJ473X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1 ERJZGEJ103X 1/4W 10K 1				+	
R318 ERJZGED105X 1/4W 1M 1 1 R319,20 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ394X 1/4W 390K 1 R322 ERJZGEJ225X 1/4W 2.2M 1 R323 ERJZGED105X 1/4W 1M 1 R3234,25 ERJZGED105X 1/4W 1M 1 R324,25 ERJZGED105X 1/4W 470K 2 R326 ERJZGED105X 1/4W 0 1 R524V474JX 1/16W 470K 1 R524V474X 1				+	
R319,20 ERJZGEJ474X 1/4W 470K 2 R321 ERJZGEJ394X 1/4W 390K 1 R322 ERJZGEJ225X 1/4W 2.2M 1 R323 ERJZGED105X 1/4W 1M 1 R324,25 ERJZGEJ474X 1/4W 470K 2 R326 ERJZGEOROOX 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJZGEJ103X 1/4W 10K 1 R405 ERJZGEJ103X 1/4W 10K 1 R406,07 ERJZGEJ473X 1/4W 47K 2 R408 ERJZGEJ103X 1/4W 10K 1 R501 ERJZGEJ473X 1/4W 47K 1				 	
R321 ERJ2GEJ394X 1/4W 390K 1 R322 ERJ2GEJ225X 1/4W 2.2M 1 R323 ERJ2GED105X 1/4W 1M 1 R324,25 ERJ2GEJ474X 1/4W 470K 2 R326 ERJ2GEOR00X 1/4W 0 1 R401 EXB24V474JX 1/16W 470K 1 R402 ERJ2GEJ103X 1/4W 10K 1 R405 ERJ2GEJ103X 1/4W 10K 1 R406,07 ERJ2GEJ473X 1/4W 47K 2 R408 ERJ2GEJ103X 1/4W 10K 1 R501 ERJ2GEJ473X 1/4W 47K 1					
1322 ERJ2GEJ225X 1/4W 2.2M 1 1323 ERJ2GED105X 1/4W 1M 1 1324,25 ERJ2GEJ474X 1/4W 470K 2 1326 ERJ2GEOROOX 1/4W 0 1 1401 EXB24V474JX 1/16W 470K 1 1402 ERJ2GEJ103X 1/4W 10K 1 1405 ERJ2GEJ103X 1/4W 10K 1 1406,07 ERJ2GEJ473X 1/4W 47K 2 1408 ERJ2GEJ103X 1/4W 10K 1 1501 ERJ2GEJ473X 1/4W 47K 1					
1323 ERJ2GED105X 1/4W 1M 1 1324,25 ERJ2GEJ474X 1/4W 470K 2 1326 ERJ2GEOR00X 1/4W 0 1 1401 EXB24V474JX 1/16W 470K 1 1402 ERJ2GEJ103X 1/4W 10K 1 1405 ERJ2GEJ103X 1/4W 10K 1 1406,07 ERJ2GEJ473X 1/4W 47K 2 1408 ERJ2GEJ473X 1/4W 10K 1 1501 ERJ2GEJ473X 1/4W 47K 1					
A324,25 ERJ2GEJ474X 1/4W 470K 2 A326 ERJ2GEOROOX 1/4W 0 1 A401 EXB24V474JX 1/16W 470K 1 A402 ERJ2GEJ103X 1/4W 10K 1 A405 ERJ2GEJ103X 1/4W 10K 1 A406,07 ERJ2GEJ473X 1/4W 47K 2 A408 ERJ2GEJ103X 1/4W 10K 1 ERJ2GEJ473X 1/4W 10K 1 ERJ2GEJ473X 1/4W 47K 1					
1326 ERJZGEOROOX 1/4W 0 1 1401 EXB24V474JX 1/16W 470K 1 1402 ERJZGEJ103X 1/4W 10K 1 1405 ERJZGEJ103X 1/4W 10K 1 1406,07 ERJZGEJ473X 1/4W 47K 2 1408 ERJZGEJ403X 1/4W 10K 1 1501 ERJZGEJ473X 1/4W 47K 1				1	
1401 EXB24V474JX 1/16W 470K 1 1402 ERJ2GEJ103X 1/4W 10K 1 1405 ERJ2GEJ103X 1/4W 10K 1 1406,07 ERJ2GEJ473X 1/4W 47K 2 1408 ERJ2GEJ103X 1/4W 10K 1 1501 ERJ2GEJ473X 1/4W 47K 1				2	
A402 ERJ2GEJ103X 1/4W 10K 1 A405 ERJ2GEJ103X 1/4W 10K 1 A406,07 ERJ2GEJ473X 1/4W 47K 2 A408 ERJ2GEJ103X 1/4W 10K 1 501 ERJ2GEJ473X 1/4W 47K 1			1/4W 0	1	
405 ERJ2GEJ103X 1/4W 10K 1 406,07 ERJ2GEJ473X 1/4W 47K 2 408 ERJ2GEJ103X 1/4W 10K 1 501 ERJ2GEJ473X 1/4W 47K 1				1	
406,07 ERJ2GEJ473X 1/4W 47K 2 408 ERJ2GEJ103X 1/4W 10K 1 501 ERJ2GEJ473X 1/4W 47K 1			1/4W 10K	1	
408 ERJ2GEJ103X 1/4W 10K 1 501 ERJ2GEJ473X 1/4W 47K 1		ERJ2GEJ103X	1/4W 10K	1	
501 ERJ2GEJ473X 1/4W 47K 1			1/4W 47K	2	
E02		ERJ2GEJ103X	1/4W 10K	1	
502 ERJ2GEJ103X 1/4W 10K 1	501	ERJ2GEJ473X	1/4W 47K	1	
	302	ERJ2GEJ103X	1/4W 10K	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R504	EXB28V334JX	1/32W 330K	1	
3505	ERJ2GEJ104X	1/4W 100K	1	
R506	EXB24V103JX	1/4W 10K	1	
R507	EXB28V224JX	1/32W 220K	1	
R508	EXB28V103JX	1/32W 10K	1	
R509	ERJ2GEJ223X	1/4W 22K	1	
R510	EXB24V104JX	1/4W 100K	1	
R511	ERJ2GEJ103X	1/4W 10K	1	
R512	ERJ2GE0R00X	1/4W 0	1	
R513	EXB28V334JX	1/32W 330K	1	
R514	ERJ2GEJ334X	1/4W 330K	1	
R515	EXB24V224JX	1/4W 220K	1	
R516	EXB24V221JX	1/4W 220	1	
R601	EXB24V102JX	1/4W 1K	1	
R602	ERJ2GEJ220X	1/4W 22	1	
R603	EXB24V123JX	1/4W 12K	1	
R604	ERJ2GEJ332X	1/4W 3.3K	1	
R605	ERJ2GEJ5R6X	1/4W 5.6	1	
R606	ERJ2GEJ332X	1/4W 3.3K	1	
R607	EXB24V222JX	1/4W 2.2K	1	
R701	ERJ2GEJ102X	1/4W 1K	1	
R702	ERJ2GEJ103X	1/4W 10K	1	
R703	EXB24V104JX	1/4W 100K	1	
R704	EXB24V333JX	1/4W 33K	1	
R705	EXB24V102JX	1/4W 1K	1	
R706	EXB24V471JX	1/4W 470	1	
R707	ERJ2GEJ394X	1/4W 390K	1	
R708	ERJ2GEJ104X	1/4W 100K	1	
R709	ERJ2GEJ473X	1/4W 47K	1	
R710	ERJ2GEJ474X	1/4W 470K	1	
R711	ERJ2GEJ104X	1/4W 100K	1	
R712	ERJ2GEJ473X	1/4W 47K	1	
R713	ERJ2GEJ101X	1/4W 100	1	

Ref. No.	Part No.	Part Name & Description	Pcs	Remarks
R714	ERJ2GEJ473X		1	
R715	ERJ3GEYJ335V		1	
R801	ERJ3GEYJ332V		1	
R802	ERJ3GEYJ682V		1	
R803			1	
R804	ERJ3GEYJ332V	1/16W 3.3K	1	
R805	ERJ3GEYJ682V		1	
R806	ERJ3GEYJ223V	1/16W 22K	1	
R807,08	ERJ2GEJ473X	1/4W 47K	2	
R909	ERJ6GEYJ6R8V	1/10W 6.B	1	
RX103	ERJ2GEJ104X	1/4W 100K	1	
RX503	ERJ2GEJ334X	1/4W 330K	1	
<u> </u>		<u></u>		_
S501	ABC1112P	SW OPEN DET.	1	
S502	RSS2A010-1A	SW HOLD	1	
S802	RSG0038-P	SW PLAY/REC/PAUSE ETC.	1	
S803	ABC1111P	SW, REC	1	
SB04-10	RSG0038-P	SW PUSH	7	
S901	RSP1A015-A	SW M.HEAD UP	1	
S1101	RSH1A036-A	SW PROTECT DET.	1	
mv.1	RRSP33J103CW	THERMISTOR	1	<u> </u>
TH1	RRSF330103CH	IIIIIIIIII	-	
VR1	EVM3WSX80B53	VR. LASER POWER	1	
x101	RSXC16M9R01T	QUARTS CRYSTAL	1	
X501	RSXY10M0M02T		1	
Z301	RJH9209-1	BATT.CASE	1	
		JOG DIAL ENTER	1	
Z801	EAOMK0001	JOG DIAL ENTER	4	

20 Cabinet Parts Location



Note : We do not supply those items of parts marked $*$.

Ref.No	Description
3	■ , POWER OFF/ ►/ II , CHARA/← -, + →/VOL/CURSOR/DISPLAY,
L	CAPS LOCK/EDIT, MARK MODE/EQ/REC SENS, SPACE/MODE, DELETE

21 Packaging

