MODELS A9740, A9825 Chassis 69U

ALLIED RADIO CORP.

Alignment, Coils

Lack of sensitivity, selectivity or poor tone quality may be due to any one or a combination of causes such as weak or defective tubes or speaker, open or grounded bias resistor, bypass condenser, inadequate or excessively long antenna, etc. Never attempt to realign set until all other possible sources of trouble have been first thoroughly investigated and definitely proven not to be the cause.

NOTE: BE SURE TO FOLLOW PROCEDURE CAREFULLY WHEN ALIGNING, OTHERWISE THE RECEIVER WILL BE INCORRECT.

IT IS ABSOLUTELY NECESSARY THAT AN ACCURATELY CALIBRATED TEST OSCILLATOR WITH SOME TYPE OF OUTPUT MEASURING DEVICE BE USED WHEN ALIGNING THE RECEIVER.


ALIGNING 1720-535 KILOCYCLE BAND:


- (a) Connect the ground lead of the test oscillator to the rotor frame of the gang condenser and the other test oscillator lead to the receiver antenna lead through a .00025 Mfd. series condenser.
- (b) Check tuning dial adjustment by turning gang condenser until plates touch maximum capacity stop, (completely in mesh) at which point the dial needle must be exactly even with the last line at the low frequency end of the dial calibration. If the dial needle does not point exactly to the last line, move needle to correct position.
- (c) Adjust band selector switch for operation on 1720-535 kilocycle band, set test oscillator frequency and receiver dial to 1400 kilocycles.
- (d) Adjust trimmers mounted on top of gang condenser for maximum 1400 kilocycle test oscillator signal output.
- (e) Check dial calibration and sensitivity at 1000 kilocycles, 700 kilocycles and 600 kilocycles. If gang condenser plates have not been bent and if antenna and R.F. coils are in good condition the gang condenser will properly track all over the band. If sensitivity is low and dial calibration incorrect, it may be necessary to bend the condenser plates at above frequencies to properly align the receiver.

IMPORTANT: Bending of plates is to be avoided if at all possible.

ALIGNING 1.67-5.7 MEGACYCLE BAND:

- (a) Replace 00025 Mfd. test oscillator lead series condenser with a 400 ohm resistor. Adjust band selector switch for operation on 1.67 to 5.7 megacycle band and tune receiver dial and set test oscillator frequency to EXACTLY 4.5 megacycles.
- (b) Adjust the two trimmers mounted on the antenna and R.F. coil, one of which is located underneath the chassis, and one on top of the chassis for maximum 4.5 megacycle test oscillator signal response.
- (c) Check dial calibration at 3 megacycles and 1.7 megacycles, BUT DO NOT BEND GANG CONDENSER PLATES ON THIS BAND.
- (d) To assure adequate sensitivity regeneration is present on this band. Receiver should oscillate around 2.5 megacycles when the volume control is at maximum volume position. If oscillation cannot be controlled with volume control, oscillation may be reduced by spreading out or uncoiling a few turns of the coupling coil, which is located underneath the chassis between the wave switch and volume control.





Illus. Part No. No. Part Name	.83 .92 2.65 1.50 .75	20 16 21 85 22 12 23 26 24 26 25 26 27 31 22 31	No. Part Name Part Name Resistor Resist	Description List Price Price Carbon 250,000 Ohm 1/3 Watt .19 Carbon 4 Meg. Ohm 1/3 Watt .19 Carbon 25,000 Ohm 1/3 Watt .19 Carbon 35,000 Ohm 1/3 Watt .19 Carbon 35,000 Ohm 1/2 Watt .19 Line with Tube Type Occal Base Marked L-32-B .75 Dynamic (3") 4.75 Dynamic (3") 4.75 Dynamic (3") 4.75 Dynamic (3") 5.25 Band Selector 5.25 Band Selector 5.25 Garden Selector 5.25 Carbon Sel
-------------------------------	-----------------------------------	---	--	--