



OPTONICA

SERVICE MANUAL



MODEL SM-3000H

"In the interests of user-safety the set should be restored to its original condition and only parts identical to those specified be used."

SPECIFICATIONS

GENERAL

Power source.....AC 110/220/240V, 50/60Hz
 Power consumption.....270W
 Semiconductors.....1-IC (Integrated circuit), 47-Transistors, 24-Diodes, 1-LED
 Dimensions.....442(W) x 144(H) x 380(D) mm
 Weight.....14.5 kg

MAIN AMPLIFIER

Circuit.....Two-step differential amplifier, pure complementary system, OCL (Output Condenser-Less)
 Continuous power output
 2 x 50W/4-ohms.....Both channels drive, at 1kHz
 2 x 35W/8-ohms.....Both channels drive, at 1kHz
 Total harmonic distortion.....0.02% at 25W
 Intermodulation distortion.....0.05% at 25W
 Damping factor.....More than 25 (at 1kHz, 4-ohms)
 Power band width.....7Hz ~ 70kHz at 0.3% distortion, 25W
 Frequency response.....15Hz ~ 90kHz (± 1.5 dB)
 Input sensitivity and input impedance.....800mV/50k ohms

PRE AMPLIFIER

Circuit.....Three-step direct coupled equalizer circuit whose first step serves as differential amplifier.
 Type "NF" tone control circuit.

Input sensitivity and input impedance

PHONO 1.....2.5mV, 5mV/47k ohms
 PHONO 2.....2.5mV/22k ohms, 47k ohms, 100k ohms

AUX 1 and 2.....150mV/47k ohms

TAPE PLAYBACK

1 and 2.....150mV/47k ohms

TAPE PLAYBACK 1 and 2 (DIN socket) 1 and 2.....150mV/47k ohms

Output level and loaded impedance

REC 1 and 2.....150mV/47k ohms
 REC 1 and 2

(DIN socket).....30mV/80k ohms

Max. allowable input

for PHONO.....300mV(RMS, 1kHz)
 850mV(P-P, 1kHz)

Deflection of "RIAA" curve for equalizer circuit from standard

"RIAA" curve..... ± 0.3 dB

Frequency response.....15Hz ~ 90kHz (TUNER, AUX, TAPE PLAYBACK)

Tone control

Bass..... ± 10 dB at 100Hz, turnover....600Hz
 ± 10 dB at 60Hz, turnover.....300Hz

Treble..... ± 9 dB at 10kHz, turnover.....1.5kHz
 ± 9 dB at 20kHz, turnover.....3kHz

Filter

Low cut.....30Hz, 12dB/oct

High cut.....7kHz, 6dB/oct

CABINET TOP REMOVAL (Refer to Figure 1)

- ① Remove 8 screws attached to washer located at side decoration panel of cabinet.
- ② Remove 2 screws attached to washer of CABINET TOP.
- ③ Gently lift up the CABINET TOP.

OPERATION PLATE REMOVAL (Refer to Figure 1)

- ④ Remove all knobs provided at the OPERATION PLATE.
- ⑤ Remove 6 screws located at OPERATION PLATE.




Figure 1


BOTTOM PLATE REMOVAL (Refer to Figure 2)

Figure 2

Remove 12 screw of CABINET BOTTOM

Caution: These (●) mark of two screws are 4φ x 8 mm.
Another ten screws are 3φ x 6 mm.

PREPARATION FOR USE**MAINS VOLTAGE SELECTION (Refer to Figure 3)**

Be sure to check the pre-set voltage selector before operating the set. If the voltage is different from your local voltage, change it in the following manner:

1. Loosen a screw and slide the cover as illustrated in Figure 3.
2. Put a fuse in the fuse holder which has an indication of your local voltage.

Note:

- In case the local voltage is 110V, two pieces of fuses should be used.
3. Replace the cover in its original position.





Figure 3

CIRCUIT DESCRIPTION**EQUALIZER AMPLIFIER**

The equalizer circuit is driven by three kinds of power sources. The transistor at the final stage is given a high voltage of 70V to assure the amplifier of satisfactory dynamic range.

The equalizer circuit consists of high-precision parts (resistor, capacitor etc.) so that RIAA deviation is limited to the maximum (within ±0.3dB) and the impedance of RIAA elements is kept high to suppress possible distortion at the high frequency band.



MAIN AMPLIFIER

The main amplifier consists of all-stage direct-coupled pure complementary output capacitorless circuit.

FEATURE OF PURE COMPLEMENTARY OCL CIRCUIT

Since this circuit is not using output capacitor, the frequency characteristic is kept uniform even at very low frequency band and the output impedance is low in any of frequency bands resulting in that the value of damping factor is made larger so that the braking efficiency of speaker is increased. With this circuit, since a 100 percent NF is assured when the frequency of signal is zero and the value of NF is determined at only one place when the frequency of signal is at low band, the function of circuit is stabilized.

CIRCUIT DESCRIPTION

The main amplifier is OCL circuit in which the class "A" drive circuit consists of 2 stage differential amplifier circuit. The signal coming from the filter circuit is amplified by differential amplifier (Q502, Q503) via R502 and C504. Since this differential amplifier consists of PNP type low noise transistor (2SA836D), a high value of S/N ratio is assured. And this amplifier functions to keep zero the center voltage (speaker terminal voltage) as well as to amplify signals. The zero adjustment of potential is to be made by using semi-variable resistor (VR501). Signal thus amplified by the differential amplifier is further amplified by differential amplifier (Q504 and Q505). Moreover, the signal is amplified for the half cycle at the driver amplifier stage consisting of Q510 (NPN type transistor) and Q511 (PNP type transistor). Then, the signal is further amplified for the half cycle at Q901 (NPN type transistor) and Q902 (PNP type transistor) to be supplied to the speaker. Q501 and Q506 is constant-current circuit and its amperage is determined by D501. Q501 functions to protect the differential amplifier (Q502 and Q503) against fluctuations of temperature and voltage resulting in that the center voltage (speaker terminal voltage) is kept constant. Q506 is constant-current circuit to supply constant current so that the load applied to the class "A" driver Q505 will be reduced thus the gain being increased. As a result of the gain of Q505 being increased by Q506, plenty of NF is produced and so the distortion is lessened. NF factor of NF circuit is determined by R520 and R517, and the higher NF factor, the higher is the gain. NF factor at the low frequency band is determined by C511 and R517. Q507 and D506 are to cause the bias of class "B" drive stage and to produce idling current of 30 ~ 80 mA so that cross-over distortion due to class "B" operation is eliminated. The idling current is to be adjusted by semi-variable resistor (VR502). Q508, Q509, D502 and D503 are short circuit, etc. at the output section and they detect voltage which will be caused at R528 and R531 (emitter resistor) if current runs excessively – if the detected voltage is higher than as rated, the collector-emitter of Q508(Q509) becomes conductive. D502(D503) and Q508(Q509) are being located between the base of Q510(Q511) and the center (speaker output) and serve as constant-current circuit, and this results in that the power transistor (Q901, Q902) is assured of a rating current.

SLAD (Spike-less Amplifier Design) CIRCUIT

This circuit is a unique circuit out of those in this unit and it actually consists of D504, D505, R527 and R529. In the case of power transistor of class "B" amplifier operation, the most part of input signal is cut off for the half cycle and there arises charge or discharge at the junction according to its capacitance. Therefore, spike-like voltage is generated or the switching time is disordered against the high frequency signal resulting in that cross-distortion of high frequency band is enlarged. SLAD circuit is for the purpose to prevent such phenomenon as above.




Figure 7

PROTECTIVE CIRCUIT (Relay Circuit)

This circuit is a speaker protection circuit displaying three functions as follows.

CIRCUIT DESCRIPTION

1. If DC voltage is produced at the speaker terminal, it enters to the base of Q801 via R813 and R814. When DC voltage is positive, Q801 becomes conductive and when it is negative, Q802 becomes conductive. As a result, a current runs in R807 and the base voltage of Q804 is decreased so that Q804 becomes conductive. Then the base voltage of Q805 is increased and Q805 loses its conductivity, resulting in that no current runs in the relay. With no current running in the relay, the relay switch is put in "OFF" mode, thus no current running in the speaker.
2. When the power switch is set to "ON", voltage is applied to the base of Q804. Since this base voltage is made lower when C805 is being charged, no current runs in the relay and the relay switch is put in "OFF" mode (no current runs in the speaker). The duration of charging is determined by the values of C805, R807, R808 and R809.
3. The base of Q803 is given positive voltage by R802 and negative voltage by D801 and R801 as a result of which the base voltage is made to be -3.5V. When the power switch is set to "OFF", since positive capacitance is larger than negative capacitance, the positive voltage is maintained for a while. Thus, the base voltage of Q803 is gradually increased from negative (-3.5V) to positive, Q803 is made conductive, the base voltage of Q804 is decreased, no current runs in the relay to put the relay switch in "OFF" mode and thus the speaker is cut off. It takes about one second for the speaker to be cut off after the power switch is turned off.




Figure 8

AF ALIGNMENT

PROCEDURE NUMBER	Alignment	Meter	Output Indicator	Setting	Adjustment	Remarks
1	Output DC Voltage (Offset Voltage)	100mV DC Voltmeter	Voltmeter is connected between speaker terminal and ground	Volume is minimum position. Other knobs are in normal position	VR501A VR501B	0 V
2	Idle Current	100mV DC Voltmeter	Voltmeter is connected between Emitter of Q901 ~ Q904 and speaker terminal	Volume is minimum position. Other knobs are in normal position	VR502A VR502B	35mV




Figure 9

If it is necessary to replace audio output transistors, then follow these procedures to prevent reoccurrence of transistor failure.

1. Carefully remove transistor and mica isolator and clean all the silicone grease off the mica and the mounting area on the chassis. If the mica is damaged, then it must be replaced.
2. Remove the defective transistor and clean out the transistor mounting hole.
3. Put new silicone grease on the transistor mounting area of the chassis and on both side of the mica isolator. Mount the new transistor, being careful to tighten each transistor mounting screw evenly.

Driving one screw tightly and then the other is likely-to-cause metal filings which may damage the mica or prevent necessary heat dissipation on chassis.

4. Before applying power to the new transistor, with an ohmmeter check to see that there is no short between the transistor case and chassis.
5. As transistor VS2SA757-B/-1 and VS2SC897-B/-1 are almost similar in the shape. So pay attention to the mark of transistor when replacing the power transistor.

RIPPLE FILTER TRANSISTOR REPLACEMENT




Figure 10

DRIVER TRANSISTOR REPLACEMENT






Figure 11

TROUBLE SHOOTING GUIDE

ALL OPERATIONAL MODES (1)



ALL OPERATIONAL MODES (2)






Figure 12 TAPE 1/TAPE 2/PRE MAIN/INPUTS CONNECTION BOARD WIRING SIDE





Figure 14 MAIN AMP./EQUALIZER AMP./AC & RELAY UNIT BOARD WIRING SIDE






Figure 15 SCHEMATIC DIAGRAM




Figure 16 EQUIVALENT CIRCUIT




Figure 17 MISTAKABLE LEAD WIRE HOLDER




Figure 18 MISTAKABLE PLUG

REPLACEMENT PARTS LIST

"HOW TO ORDER REPLACEMENT PARTS"

To have your order filled promptly and correctly, please furnish the following informations.

1. MODEL NUMBER
2. REF. NO.
3. PART NO.
4. DESCRIPTION

REF. NO.	PART NO.	DESCRIPTION	CODE	REF. NO.	PART NO.	DESCRIPTION	CODE
MISCELLANEOUS							
	GCAB-3001AFSA	Cabinet	AZ		PSPA9004AGZZ	Washer, Retaining, Transistor	AA
	GCOVA1053AFSA	Guide, Lever Switch	AB		PZETF0101AFZZ	Insulator, Partition	AA
	GFTA03050AFZZ	Plate, Bottom	AN		QACCN0001AGZZ	Cord, Mains Supply	AP
	GLECP0002SG00	Leg	AD		QACCS9001SE00	Cord, Mains Supply	AG
	HDECW0050AFSB	Board, Right & Left Hand Side	AR		QACCV0001AGZZ	Cord, Mains Supply	AN
					QACCC0002TA0F	Cord, Mains Supply	AG
	HPNLC3219AFSA	Plate, Operation	BB	PG1, PG2, PG3, PG6	QCNCM051CAFZZ	Plug, 3 Pin	AC
	JKNBN0272AFSA	Knob, VOLUME	AP				
	JKNBN0273AFSA	Knob, FUNCTION	AN	PG24, PG25, PG26	QCNCM053EAFZZ	Plug, 5 Pin	AD
	JKNBN0274AFSA	Knob, SPEAKERS/BASS/TREBLE/BALANCE/MODE/TAPE MONITOR	AL	PG7, PG8, PG(30 ~ 32), PG4	QCNCM054FAFZZ	Plug, 6 Pin	AD
	JKNBP0058AFSA	Knob, POWER/TURNOVER/LOWCUT/HIGHCUT/LOUDNESS/MUTING	AH		QCNCM055GAFZZ	Plug, 7 Pin	AE
	LANGQ0439AFSA	Bracket, Terminal	AT		QCNCM063FAFZZ	Plug, 6 Pin	AF
	LANGR0350AFZZ	Bracket, Operation Plate	AK		QCNCM064GAFZZ	Plug, 7 Pin	AG
	LANGT0451AFZZ	Bracket, Strengthen, Left & Right Hand Side	AE		QCNCM066JAFZZ	Plug, 9 Pin	AH
	LANGT0452AFZZ	Bracket, Printed Wiring Board	AC	PG34, PG35	QCNCM073EAFZZ	Plug, 5 Pin	AC
	LANGT0453AFZZ	Bracket,	AC	SO9, SO11, SO13, SO14, SO18, SO20, SO23	QCNCM074FAFZZ	Plug, 6 Pin	AC
	LANGT0456AFZZ	Bracket, PHONO Terminal P.W.B.	AB				
	LBSC00004AFZZ	Bushing, Mains Supply Cord	AC		QCNCW050PAFZZ	Socket, 2 Pin	AC
	LBSC00007AFZZ	Bushing, Mains Supply Cord	AB				
	LCHSM0201AFZZ	Plate, Mounting	AR				
	LHLDW1027AGZZ	Holder, Lead Wire	AA				
	LHLDW1050AFZZ	Holder, Lead Wire	AB				
	LHLDW1051AFZZ	Holder, Lead Wire	AB				
	LHLDW1052AFZZ	Holder, Lead Wire	AA				
	LHLDW9003CEZZ	Holder, Lead Wire	AA				
	LHLDZ9050AF00	Holder, LED	AV		QCNCW051CAFZZ	Socket, 3 Pin	AC
	LX-NZ3030SEFN	Nut, Headphones/AUX 2 Jack	AA	SO10, SO15, SO17, SO19			
	LX-WZ3017CEFN	Washer, GND Terminal	AA				
	PCOVS3050AF00	Cover, Shield, Front	AP	SO16	QCNCW052DAFZZ	Socket, 4 Pin	AC
	PCOVS3051AF00	Cover, Shield, Rear	AM	SO25, SO26	QCNCW053EAFZZ	Socket, 5 Pin	AC
	PCOVS3052AFZZ	Bracket, Partition, Power Switch	AD				
	PCOVW3101AFZZ	Cover, Fuse Holder, Acrylic	AF	SO7, SO8, SO12, SO21, SO30, SO31, SO32	QCNCW054FAFZZ	Socket, 6 Pin	AC
	PRDAR0038AGZZ	Heatsink, Small, Transistor (Q807, Q808)	AA				
	PRDAR0100AF00	Heatsink, Large, Power Transistor	AW				
	PRDAR0101AFFW	Heatsink, Small, Transistor	AB				
	PSHEF0048AG00	Felt, Cabinet	AA	SO4	QCNCW055GAFZZ	Socket, 7 Pin	AC
	PSHEF0110AFZZ	Felt, Masking, Lever Switch	AA	SO36, SO39	QCNCW063FAFZZ	Socket, 6 Pin	AE
	PSPAN0004AF09	Spacer, Headphone Jack, AUX 2 Jack	AB				
	PSPAP0012AGZZ	Washer, Headphone Jack, AUX 2 Jack	AA	SO37, SO38, SO40, SO41	QCNCW065HAFZZ	Socket, 8 Pin	AF
	PSPA90050AFZZ	Insulator, Power Transistor	AB				

PARTS LIST

PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	CODE	REF. NO.	PART NO.	DESCRIPTION	CODE
SO42	QCNCW066JAFZZ	Socket, 9 Pin	AF	TM903,	QTANZ0450AFZZ	Terminal, SPEAKERS	AN
SO34	QCNCW071EAFZZ	Socket, 5 Pin	AE	TM904			
SO35	QCNCW072FAFZZ	Socket, 6 Pin	AE		XWHG081-05125	Washer, Rubber Headphone Jack	AA
	QCNCW080FAFZZ	Socket,	AC		QTIPZ0050AFZZ	Tip, Socket, Small	AA
F801 ,	QFS-D161AAGNI	Fuse, 160mA	AE		QTIPZ0052AFZZ	Tip, Socket, Large	AA
F802							
	QFS-C252CAGNI	Fuse, 2.5A, RATED LINE VOLTAGE	AE				
	QFSDH1001AGZZ	Holder, Fuse	AB				
	QHWS-3001AGFN		AA				
J902	QJAKZ0021AGZZ	Jack, AUX 2	AH				
J901	QJAKE0027AGZZ	Jack, HEADPHONES	AF	C441,	VCAAU1EB224K	.22MFD, 25V, +10 -10%, Aluminum Electrolytic	AC
	QLUGL0411CEZZ	Lug Terminal, 4 Pin	AC	C442			
	QLUGP0105AGZZ	Lug Terminal, Test Point	AA	C901,	VCP0AT3AC333M	.033MFD, 1000V, +20 -20%, Oil	AE
	QLUGP0111CEFW	Lug Terminal	AA	C902			
	QPLGA0205AGZZ	Plug, Mains Supply Cord	AK	C903,	VCEABD1HB109M	10000MFD, 50V, +20 -20%, Electrolytic	AX
	QPLGS0150AFZZ	Plug, Short Circuit, PHONO 1/ PHONO 2	AC	C904			
	QPWBE0052AFZZ	Printed Wiring Board, Power Amp.	AM				
	QPWBE0053AFZZ	Printed Wiring Board, TONE Amp.	AP				
	QPWBE0054AFZZ	Printed Wiring Board, Volume	AN				
	QPWBE0055AFZZ	Printed Wiring Board, Equalizer	AH				
	QPWBE0060AFZZ	Printed Wiring Board, Power Supply	AL				
	QPWBF0352AFZZ	Printed Wiring Board, PRE/ MAIN CONNECTION	AD				
	QPWBF0353AFZZ	Printed Wiring Board, TAPE-1/ TAPE-2	AD				
	QPWBF0354AFZZ	Printed Wiring Board, IMP./ PHONO-2/PHONO-1/ATT	AD				
	QPWBF0423AFZZ	Printed Wiring Board, Fuse	AD				
SO901,		Socket, PRE/MAIN CON-					
SO906,	QSOCJ2450AFZZ	NECTION, PHONO-1/ PHONO-2	AG				
SO907							
SO904,	QSOCJ2451AFZZ	Socket, TUNER/AUX	AG				
SO905							
	QSOCJ2451AFZZ	Socket, TUNER/AUX	AG				
	QSOCJ2350AFZZ	Socket, Power Transistor	AD				
SO902,							
SO903	QSOCZ2450AFZZ	Socket, TAPE-1/TAPE-2	AK				
SW401	QSW-B0050AFZZ	Switch, TURNOVER, 300Hz/600Hz	AL				
SW402	QSW-B0050AFZZ	Switch, TURNOVER, 1.5kHz/3kHz	AL				
SW403	QSW-B0051AFZZ	Switch, VARIABLE/DEFEAT	AK				
SW404	QSW-B0051AFZZ	Switch, LOUDNESS	AK				
SW405	QSW-B0051AFZZ	Switch, MUTING	AK				
SW406	QSW-B0051AFZZ	Switch, LOWCUT	AK				
SW407	QSW-B0051AFZZ	Switch, HIGHCUT	AK				
SW901	QSW-B9059AFZZ	Switch, POWER	AK				
SW302	QSW-R0101AFZZ	Switch, MODE	AN				
SW408							
(A, B)	QSW-R0102AFZZ	Switch, TAPE MONITOR	AS				
SW905	QSW-R0104AFZZ	Switch, SPEAKERS	AL				
SW301							
(A, B, C)	QSW-R0117AFZZ	Switch, FUNCTION	AK				
SW902	QSW-S0150AFSA	Switch, NORMAL/ SEPARATED	AF				
SW904	QSW-S0150AFSA	Switch, ATT	AF				
SW903	QSW-S0151AFSA	Switch, IMP	AG				
TM901,							
TM902	QTANZ0150AFSA	Terminal, GND	AD				

REF. NO.	PART NO.	DESCRIPTION	CODE	REF. NO.	PART NO.	DESCRIPTION	CODE
Q303,	VS2SC1345-E-1	Equalizer, Differential Amp.	AE				
Q304							
Q305,	VS2SC1345-E-1	Equalizer, Differential Amp.	AE				
Q306							
Q307,	VS2SC1345-E-1	Equalizer, Emitter Follower Circuit	AE				
Q308							
Q309,	VS2SC1212WAB4	Equalizer, Class "A" Amp.	AH				
Q310							
Q401,	VS2SC1345-E-1	Lowcut Filter, Emitter Follower Circuit	AE				
Q402							
Q501	VS2SA673AB/-1	Power Amp, Constant Current Circuit	AG				
(A, B)							
Q502	VS2SA836-D/-1	Power Amp, Differential Amp., 1st	AE				
(A, B)							
Q503	VS2SA836-D/-1	Power Amp, Differential Amp., 1st	AE				
(A, B)							
Q504	VS2SC1212WAB4	Power Amp., Differential Amp., 2nd	AH				
(A, B)							
Q505	VS2SC1212WAB4	Power Amp., Differential Amp., 2nd	AH				
(A, B)							
Q506	VS2SA743AB/-4	Power Amp., Constant Current Circuit	AL				
(A, B)							
Q507	VS2SC1213AE-1	Power Amp., Bias Circuit	AF				
(A, B)							
Q508	VS2SC1213AB-1	Power Amp., Voltage Detector	AF				
(A, B)							
Q509	VS2SA673AB/-1	Power Amp., Voltage Detector	AG				
(A, B)							
Q510	VS2SC1213WAB4	Power Amp., Driver Amp.	AH				
(A, B)							
Q511	VS2SA743AB/-4	Power Amp., Driver Amp.	AL				
(A, B)							
Q801,	VS2SC1213AB-1	Protection Circuit, Speaker Output	AF				
Q802							
Q803	VS2SC1213AB-1	Protection Circuit, Power Off	AF				
Q804	VS2SA673AB/-1	Protection Circuit, Switching	AG				
Q805	VS2SA673AB/-1	Protection Circuit, Switching	AG				
Q806	VS2SA673AB/-1	Protection Circuit, Switching	AG				
Q807	VS2SA743B/-1	Mains Supply Circuit, Ripple Filter	AK				
Q808	VS2SC1212WB-1	Mains Supply Circuit, Ripple Filter	AH				
Q809	VS2SC1212WAB4	Mains Supply Circuit, Ripple Filter	AH				
Q901,							
Q903	VS2SC897-B/-1	Power Amp.	AR				
Q902,							
Q904	VS2SA757-B/-1	Power Amp.	AT				

DIODES

REF. NO.	PART NO.	DESCRIPTION	CODE
D301,	VHVHV46-G//-1	Equalizer, Constant Current Circuit	AD
D302			
D501	VHVHV46-G//-1	Constant Current Circuit	AD
(A, B)			
D502	VHD1S2076//-1	Voltage Detector	AG
(A, B)			
D503	VHD1S2076//-1	Voltage Detector	AG
(A, B)			
D504	VHD1S2348-H-1	Spike-less Amp.	AD
(A, B)			
D505	VHD1S2348-H-1	Spike-less Amp.	AD
(A, B)			
D506	VHVMV203Y//-1	Bias Circuit	AD
(A, B)			
D801	VHD1S2076//-1	Detector	AG
D802	VHD1S2076//-1	Surge Current Provention	AG
D803,	VHVHV46-G//-1	Ripple Filter Circuit	AD
D804			
D805	VHDSS-3////-F	Rectifier	AM
D806	VHDSS-3R////-F	Rectifier	AM
D807	VHD1S1887//-1	Rectifier	AD
D808	VHD1S1941//-1	Rectifier	AD
ZD801,	VHEBZ140////-1	Ripple Filter Circuit	AG
ZD802			
D901	VHPGL50RG//-1	Indicator	AE

COILS

REF. NO.	PART NO.	DESCRIPTION	CODE
L501	RCILZ0050AFZZ	.8μH	AD
(A, B)			
L801,	VP-LH470M0000	47μH	AB
L802			

TRANSFORMER

REF. NO.	PART NO.	DESCRIPTION	CODE
T901	RTRNP0395AFZZ	Power	BP

INTEGRATED CIRCUIT

REF. NO.	PART NO.	DESCRIPTION	CODE
IC401	RH-IX0427AGZZ	Tone Amp.	AP

RELAY

REF. NO.	PART NO.	DESCRIPTION	CODE
REY 801 (A, B)	RRLYZ0050AFZZ		AW

CAPACITORS

REF. NO.	PART NO.	DESCRIPTION	CODE
C441,	VCAAU1EB224K	.22MFD, 25V, +10 -10%, Aluminum Electrolytic	AC
C442			
C901,	VCP0AT3AC333M	.033MFD, 1000V, +20 -20%, Oil	AE
C902			
C903,	VCEABD1HB109M	10000MFD, 50V, +20 -20%, Electrolytic	AX
C904			

RESISTORS

REF. NO.	PART NO.	DESCRIPTION	CODE
R319,	RR-NZ0006AFZZ		AD
R320			
R337,	RR-NZ0007AFZZ		AD
R338			
R822	VRC-MT2HG471K	470 ohm, 1/2W, +10 -10%, Solid	AA
R810	VRC-MT2HG272K	2.7K ohm, 1/2W, +10 -10%, Solid	AA
R816,	VRS-PT3AB221K	220 ohm, 1W, +10 -10%, Oxide Film	AB
R819			
R329,	VRS-PT3AB272K	2.7K ohm, 1W, +10 -10%, Oxide Film	AB
R330			
R927,	VRS-PT3DB271K	270 ohm, 2W, +10 -10%, Oxide Film	AB
R928			
R503	VRW-KT3DD100K	10 ohm, 2W, +10 -10%, Wire Wound	AC
(A, B)			
R507	VRW-KT3DD2R2K	2.2 ohm, 2W, +10 -10%, Wire Wound	AC
(A, B)			
R528			
(A, B)			
R531	VRW-KT3HDR47K	.47 ohm, 5W, +10 -10%, Wire Wound	AD
(A, B)			

CONTROLS

REF. NO.	PART NO.	DESCRIPTION	CODE
VR301	RVR-C0004AGZZ	BALANCE	AL
(A, B)			
VR302	RVR-B0114AFZZ	VOLUME	AL
(A, B)			
VR303	RVR-C0050AFZZ	BASS	AL
(A, B)			
VR304	RVR-C0050AFZZ	TREBLE	AL
(A, B)			
VR502	RVR-M0065AGZZ	Idle Current Adjust	AF
(A, B)			
VR501	RVR-M0072AGZZ	Center Voltage Adjust	AG
(A, B)			

TRANSISTORS

REF. NO.	PART NO.	DESCRIPTION	CODE
Q301,	VS2SA836-D/-1	Equalizer, Constant Current Circuit	AE
Q302			