




LEFT CHANNEL



RIGHT CHANNEL



©hscott.com

- INPUT SELECTION SW**
- 1. CERAMIC
 - 2. TAPE HEAD
 - 3. PHONO
 - 4. NAB TAPE
 - 5. EXTRA
- STEREO SELECTOR SW**
- 1. FRONT
 - 2. REAR
- EQUALIZATION SW**
- 1. RIAA
 - 2. PHONO
 - 3. NAB TAPE

- THE FOLLOWING CONTROLS IN LEFT CHANNEL ARE MECHANICAL, IF SHARED WITH IDENTICAL CONTROLS IN RIGHT CHANNEL**
- 1. INPUT SELECTOR
 - 2. SCRATCH FILTER
 - 3. TREBLE CONTROL
 - 4. VOLUME CONTROL
 - 5. BALANCE
 - 6. PHASE SWITCH

UNITS NUMBERED 20B146 TO 20B695 INCLUSIVE USE TRANSFORMER TR12-3 & GRID POWER RESISTOR RWS 20 160 (R20C). ALL OTHER UNITS USE TRANSFORMER TR12 IS ANU POWER RESISTOR RWS 10-20.

TYPE 222D STEREO AMPLIFIER

SCALE: ---	CIRCUIT DIAGRAM	6-18-63
H. H. SCOTT, INC. MAYNARD, MASS. U.S.A.		
DR. <i>[Signature]</i>	1/16" 1/8" 1/4" 1/2" 1"	DWG. NO. 222D-C1 SUB D